

Instruction- and Maintenance Manual SUPER BOOM LIFT

Document Number:
ED.03906.00.001.ENG
rev01

Status:
Final

Original instructions

SBL500
SBL900
SBL1100



ENERPAC 
HEAVY LIFTING TECHNOLOGY 

www.enerpac.com

Revisions

Rev	Description	Date	Author	Checked	Approved by
00	First release This document is a merge of the manuals of the SBL500, SBL900 and the SBL1100. New developments are integrated: <ul style="list-style-type: none">• Top swivel• Free wheel• Rotation anchor• Sling anchor Minimum requirement of the oil. Warning for use of local control more precise formulated.	03 Feb 2020	Rosier	Jansen	Broenink
01	Sling guide added	19 March 2021	Rosier	Westerhof	Broenink

Preface

Dear customer,

This is the manual for assembling, operating and maintaining the Super Boom Lifts SBL500, SBL900 and the SBL1100. Differences between the are indicated clearly, if applicable. Within this manual, the machines are referred to by the term “**System**”. The manual is part of the handbook of the System and is meant to be used by operators and by maintenance engineers.



NB: It is essential that the user reads this manual completely **before** start working with the System.



- All information, illustrations and technical data in this manual are applicable to the System as it was at the **time of issuing** of this manual.
- We continuously **improve** our products and therefore reserve the right to implement improvements and **changes** whenever it is necessary and possible to do so, without any obligation to apply improvements or changes to models purchased previously. Nevertheless, when the system is improved due to serious **safety issues**, you as a customer will be informed.
- If this manual becomes **unreadable**, in whole or in part, you can order a copy by providing us the number given on the front cover.
- Even though the fact that this manual has been drafted with great care, we **cannot guarantee** that it does not contain any errors.
- The use and interpretation of all information in this manual and the possible consequences through improper use of the system are wholly the **responsibility of the user**. Enerpac shall under no circumstances accept any responsibility for such improper use.

Pictures and illustrations in this manual may differ from reality.

Within this document use is made of **structured text**. The following conventions are applied:

- Procedural steps are numbered. Execute the steps sequentially. Do not skip any step.
- Responses of the system are written on the next line in italic font.
- Choices are indicated with bullets.

Example:

1.	Press the green button. <i>The motor starts running.</i>	
2.	Select one of the options: <ul style="list-style-type: none"> • Use the red button to stop the motor. • Use the blue button to pause the machine. 	

We are interested in improving our documentation, and we welcome your comments and suggestions. If you have any difficulties using this manual, discover an error, or just want to provide some feedback, contact us. Please include the handbook code as shown at the front page.

We hope this manual will help you to use the System properly.

Enerpac

© All rights reserved. Nothing in this publication may be duplicated, stored in an automated database or made public in any form or in any manner, whether electronic, mechanical, by photocopying, recording or any other means, without prior written approval by Enerpac.

Contents

1	INTRODUCTION	8
1.1	MANUFACTURER ADDRESS.....	8
1.2	DECLARATION	8
1.3	REFERENCED DOCUMENTS	8
1.4	IDENTIFICATION	9
1.5	LIABILITY	9
1.6	INTENDED USE.....	9
1.7	MODIFICATIONS.....	10
1.8	PERSONNEL AND RESPONSIBILITIES.....	10
1.8.1	THE OWNER OF THE SYSTEM	10
1.8.2	THE USER OF THE SYSTEM.....	11
1.8.3	THE SITE SUPERVISOR.....	11
1.8.4	THE SYSTEM DIRECTOR	11
1.8.5	THE OPERATORS	12
1.9	HAND SIGNALS	13
1.10	LIFETIME	14
1.11	WARNING SYMBOLS USED WITHIN THIS DOCUMENT	14
2	GENERAL SAFETY ASPECTS	15
2.1	MANDATORY PROTECTIVE GEAR	15
2.2	GENERAL SAFETY REGULATIONS	15
2.3	SYMBOLS APPLIED TO THE SYSTEM	16
2.4	WELDING WORK	17
2.5	WORKING ON THE ELECTRICAL SYSTEM	17
2.6	WORKING ON THE HYDRAULIC SYSTEM.....	17
2.7	FIRE	17
2.8	WORKING WITH HAZARDOUS SUBSTANCES	18
2.9	ASSEMBLY AND DISASSEMBLY	19
2.10	TRANSPORT, LOADING AND UNLOADING OF THE SYSTEM.....	19
2.11	DEALING WITH HOSES	20
2.11.1	COMMON DIRECTIONS	20
2.11.2	MAIN PROCEDURE FOR CONNECTING HOSES.....	21
3	SYSTEM OVERVIEW.....	22
3.1	GENERAL	22
3.2	MAIN PARTS	23
3.2.1	THE UNIT	25
3.2.2	HEADER BEAMS.....	28
3.2.3	THE SKID TRACKS	29
3.2.4	SIDE SHIFT UNITS.....	29
3.2.5	OPTIONS FOR SIDE SHIFT UNITS.....	30
3.2.6	THE LIFTING LUGS.....	33
3.2.7	THE REMOTE-CONTROL CONSOLE	34
3.3	SYSTEM SPECIFICATIONS	35
3.3.1	MAIN SPECIFICATIONS	35
3.3.2	FUNCTIONAL SPECIFICATIONS	36
3.3.3	SIDE SHIFT UNITS.....	37
3.3.4	MECHANICAL LOCKING SYSTEM	37
3.3.5	ROTATION ANCHOR	37
3.3.6	SLING GUIDES	37
3.3.7	DIMENSIONS AND MASSES	37
3.4	SYSTEM CONFIGURATIONS.....	38
3.4.1	HEADER BEAM CONFIGURATIONS	38
3.4.2	SIDE SHIFT UNITS AND HEADER BEAMS	39
3.5	POSITION OF THE LOAD	39
3.6	SERVICE CONDITIONS	40

4	PLAN AN OPERATION	41
4.1	BEARING GROUND PRESSURE CALCULATION	42
4.1.1	CALCULATIONS FOR UNITS WITH WHEELS.....	42
4.1.2	CALCULATIONS FOR UNITS WITH ROLLER TRACKS	47
4.1.3	REQUIREMENTS FOR FOUNDATION MATERIAL	52
4.2	CHECK THE LIFTING CAPACITY OF THE SYSTEM.....	53
4.2.1	MAXIMUM LOAD	53
4.2.2	MINIMUM LOAD	55
4.3	SIDE SHIFT UNITS, LUGS AND SLING GUIDES	55
4.3.1	SIDE SHIFT UNITS.....	55
4.3.2	LUGS.....	55
4.3.3	SLING GUIDES	55
4.4	THE BEARING CAPACITY OF THE HEADER BEAMS	56
4.5	SIDE LOAD	58
5	INSTALL THE SYSTEM.....	59
5.1	HOISTING INSTRUCTIONS	59
5.1.1	TRANSPORTING A UNIT IN VERTICAL POSITION	59
5.1.2	TRANSPORTING A UNIT IN HORIZONTAL POSITION (NOT FOR SBL1100).....	60
5.1.3	HOISTING SKID TRACKS	63
5.1.4	HOISTING HEADER BEAMS.....	63
5.1.5	HOISTING A SIDE SHIFT UNIT.....	64
5.1.6	HOISTING SLING GUIDES	66
5.2	PLACE THE SKID TRACKS.....	67
5.2.1	BUILD THE FOUNDATION	67
5.2.2	PUT THE SKID TRACKS IN PLACE	68
5.2.3	ALIGN THE SKID TRACKS	69
5.3	PUT THE UNITS UPON THE SKID TRACKS	71
5.4	CONNECT THE POWER CABLES	72
5.5	PUT THE BOOM IN UPRIGHT POSITION (SBL900 AND SBL1100 ONLY)	72
5.6	MOUNT THE HEADER BEAMS.....	75
5.6.1	ASSEMBLE THE MODULAR BEAM	75
5.6.2	MOUNT THE LIFTING LUGS.....	76
5.6.3	MOUNT THE HEADER BEAM ON TOP OF THE CYLINDERS	77
5.6.4	MOUNT LONGITUDINAL BEAMS	78
5.7	MOUNT THE SIDE SHIFTS ON TOP OF THE HEADER BEAMS.....	78
5.7.1	MOUNT THE CABLE GUIDING REEL	78
5.7.2	MOUNT THE ROTATION ANCHOR	79
5.7.3	MOUNT THE SSU150 AND SSU300.....	79
5.7.4	MOUNT THE SSU600	84
5.7.5	CONNECT THE CABLE OF THE SIDE SHIFT UNIT	86
5.7.6	SET THE MOVING DIRECTION	87
5.8	INSTALL THE ROTATION ANCHOR.....	88
5.9	INSTALL THE SLING GUIDES	89
5.10	INSTALL THE REMOTE-CONTROL CONSOLE	90
5.10.1	WIRELESS COMMUNICATION.....	90
5.10.2	WIRED COMMUNICATION.....	90
5.10.3	MIXED WIRELESS AND WIRED COMMUNICATION	91
5.10.4	SET UP THE COMMUNICATION FOR WIRELESS AND FOR WIRED CONNECTION	92
5.10.5	PAIRING OF THE REMOTE CONTROL CONSOLE WITH THE UNITS	93
5.10.6	PERFORM AN ALL-OVER VISUAL INSPECTION OF THE SYSTEM.....	94
6	HOW TO CONTROL THE SYSTEM	95
6.1	THE EMERGENCY BUTTONS	95
6.2	THE CONTROL PANEL OF THE UNIT	96
6.3	THE REMOTE-CONTROL CONSOLE.....	98
6.3.1	THE CONTROLS	98
6.3.2	THE DISPLAY	99
6.4	THE MECHANICAL LOCKING SYSTEM.....	100
6.5	ROTATE THE LOAD USING THE ROTATION ANCHOR	102
6.6	LIMITING DEVICES	104

7	EXECUTE A LIFTING OPERATION.....	105
7.1	MAIN DIRECTIONS.....	105
7.1.1	RISKS AND WARNINGS.....	105
7.1.2	WARNING SIGNS ON THE SYSTEM.....	106
7.2	LOCAL CONTROL OF ONE UNIT.....	106
7.3	SUSPEND THE LOAD.....	108
7.3.1	SIDE SHIFT UNITS OR LIFTING LUGS.....	108
7.3.2	SLING GUIDES.....	109
7.4	LIFT THE LOAD.....	110
7.5	MOVE THE LOAD IN LONGITUDINAL DIRECTION.....	112
7.6	SYNCHRONIZE THE POSITIONS OF THE UNITS.....	114
7.7	MOVE THE LOAD IN TRANSVERSAL DIRECTION.....	115
7.8	ROTATE THE LOAD.....	116
7.9	TILT THE LOAD.....	116
8	SOLVE PROBLEMS.....	119
8.1	MAIN PROBLEM LOCALIZATION PROCEDURE.....	119
8.2	LIST OF PROBLEMS AND SOLUTIONS.....	119
8.3	REPAIR THE WIRE STROKE SENSOR.....	122
8.3.1	REPLACE THE WIRE.....	122
8.3.2	CALIBRATE THE STROKE SENSOR.....	122
9	STORAGE.....	125
9.1	SYSTEM.....	125
9.2	HYDRAULIC HOSES.....	125
9.3	REMOTE-CONTROL UNIT.....	126
10	MAINTENANCE.....	127
10.1	RULES TO BE OBSERVED FOR MAINTENANCE.....	127
10.2	RESPONSIBILITIES.....	128
10.3	MECHANICAL.....	129
10.3.1	LUBRICATE THE DRIVING CHAINS.....	131
10.3.2	TENSION THE DRIVING CHAINS.....	132
10.3.3	TENSION THE ROLLER CHAINS (SBL1100).....	134
10.3.4	LUBRICATE THE SIDE SHIFT UNITS.....	136
10.3.5	LUBRICATE THE SWIVEL.....	137
10.3.6	LUBRICATE THE BOOMS.....	137
10.3.7	MEASURE THE WEAR OF THE GUIDING PADS.....	138
10.3.8	ADJUST THE GUIDING PADS.....	140
10.3.9	CHECK THE STROKE SENSOR.....	142
10.3.10	TENSION THE CHAIN OF THE SIDE SHIFT UNITS.....	143
10.3.11	REPLACE THE OIL OF THE GEARBOXES.....	144
10.4	HYDRAULICS.....	145
10.4.1	DRAIN THE OIL.....	148
10.4.2	FILL THE TANK.....	149
10.4.3	REPLACE THE FILTER ELEMENT.....	150
10.5	ELECTRICS.....	152
11	QUALITY.....	153
12	DISMANTLING THE SYSTEM.....	153
13	INDEX.....	154
	APPENDICES.....	155

A.	CHECKLIST FOR PLANNING	155
B.	CHECKLIST FOR INSTALLING THE SYSTEM	157
C.	FINAL CHECKS	159
D.	RECORDING A LIFTING OPERATION	160
E.	LOGGING MAINTENANCE	162
F.	WEAR OF THE PADS	165
G.	HYDRAULIC FLUID SAFETY INFORMATION	166
H.	TORQUE SETTINGS	174
Z.	COMPATIBILITY OF SYSTEM PARTS	176

1 Introduction

1.1 Manufacturer address

Enerpac Heavy Lifting Technology B.V.
Zuidelijke Havenweg 3,
7554 RR Hengelo (Ov)
The Netherlands
Tel. +31 74 242 20 45
Fax. +31 74 243 03 38
Email: info.hengelo@enerpac.com
Website: www.enerpac.com

1.2 Declaration

Declaration of Conformity according to Machine Directive 2006/42/EC.
For the EC Declaration of Conformity reference is made to ref [6] "EC Declaration of conformity" which is part of the product delivery.



1.3 Referenced documents

The following documents are referred to in this manual:

Ref	Name	Identification	Manufacturer
1.	Operation of electrical installations - Low voltage	NEN 3140	NEN
2.	Operation of electrical installations	NEN-EN 50110-1	NEN
3.	General rules and safety requirements for systems and their components	NEN-EN-ISO 4413	NEN
4.	Wind calculations	NEN-EN 1991-1-4 Eurocode 1: Belastingen op constructies – Deel 1-4: Algemene belastingen – Windbelasting. (<i>Loads on structures - Part 1-4: General loads - Wind load</i>)	NEN
5.	Technical handbook		Enerpac
6.	EC Declaration of conformity		Enerpac
7.	ASME B30.1-2015	Jacks, Industrial Rollers, Air Casters, and Hydraulic Gantries. (<i>Safety Standard for Cableways, Cranes, Derricks, Hoists, Hooks, Jacks and Slings</i>)	American Society of Mechanical Engineers

1.4 Identification

Each main component is fitted with a name plate as shown below.

ENERPAC  	
Type	<input type="text"/>
Drawing	<input type="text"/> Rev. <input type="text"/>
Order nr.	<input type="text"/>
Machinery part	<input type="text"/> of <input type="text"/>
Description	<input type="text"/>
Year of manufacture	<input type="text"/>
Self weight	<input type="text"/>
<p>Enerpac Heavy Lifting Technology B.V. Zuidelijke Havenweg 3 7554RR Hengelo - The Netherlands Tel. +31(0)74 24 22 045 Service tel. +31(0)74 85 04 777</p>	



NB: Name plates are official documents. It is not permitted to alter them or render them illegible.

1.5 Liability

- Personnel as well as other people involved in the usage of the System are expected to have read and understood this manual.
- In cases of doubt about the use or application of this machine, always contact Enerpac for advice and recommendations.
- Unauthorised alterations to the machine may have a deleterious effect on the characteristics of the machine and may disrupt the control functions. Unauthorised alterations therefore annul any resultant damage claims against Enerpac.
- The risk analysis conducted by Enerpac, intended usage and reasonably foreseeable incorrect usage of the System were assessed. The instructions in this manual were drawn up based on this analysis.

1.6 Intended use

The definition of 'intended use' excludes any and all uses which do not meet the descriptions, including use that exceeds the machine's technical limitations. Enerpac shall not accept any liability for damage resulting from use that is not in accordance with the machine's intended use. The user shall bear any and all risks. The definition of 'intended use' also includes strict compliance with the instructions in the user manual and assumes that the equipment is inspected and maintained at the indicated times.

- The System should only be used in the **intended manner** as described in the instructions in this manual.
- The System should only be operated by **operators** with full knowledge of the applicable safety regulations and the hazards which may arise during use.
- The System was developed and built according to the officially recognized safety **regulations**. However, if the machine is not used as intended:
 - This may pose a **risk** to the health and lives of operators and bystanders.
 - The System may not function properly or may create **hazardous** situations.
- The System should only be used if the machine is in perfect technical **condition**.
- Faults which may result in hazardous situations must be **resolved** immediately.
- The machine must not be used in potentially **explosive** environments.

The System is intended to move a heavy load in three directions:

- In vertical direction.
- In longitudinal direction.
- In transversal direction (optional).

1.7 Modifications

Never make any **modifications** or additions which could have an adverse impact on safety without prior approval from Enerpac. This also applies to the installation and adjustment of safety devices and valves and welding work on the System.

Spare parts should meet the technical specifications given by Enerpac. Apply **original spare parts** as these parts are made according to the technical specifications of Enerpac. In cases of doubt, please contact Enerpac.

1.8 Personnel and responsibilities

- Only qualified personnel are allowed to operate the System. Qualified personnel are those who have certified skills to operate the System. They should preferably have received training from Enerpac, or else from the customer.
- Only qualified personnel are allowed to maintain the System. Qualified personnel are those who have certified main education for the jobs they have to perform, either mechanical, hydraulically or electrical. They should preferably have received training from Enerpac, or else from the customer.
- Qualification of the personnel is a responsibility of the customer.
- Always comply with legal minimum age stipulations.
- The System should only be used, maintained and repaired by properly instructed and trained personnel. Clearly describe the qualifications of the relevant employees with regard to use, commissioning, assembly, disassembly and all maintenance and repair work. If work must be performed by third parties, they must receive clear instructions so both the client and the contractor are up-to-date on the agreements reached.
- The supervisor and operator are authorized to refrain from following any instructions from third parties that may pose a risk to the machines or bystanders.
- Personnel who have not been fully trained and instructed in the use of the machine, or personnel who have only received general training, may only perform work on the System under continuous supervision of a qualified person.
- Work on the electrical and the hydraulic systems must be performed by competent, qualified personnel, or by trained personnel under the direct supervision of qualified personnel, in compliance with all applicable rules and regulations.
- Assembly and disassembly may only be performed by trained installers under the supervision of an authorized person who has adequate knowledge of the System.

The responsibilities listed in the following sub-sections are in accordance with the standard as referred to in Ref [7] ASME B30.1-2015.

In some situations, the owner and the user may be the same entity and is therefore accountable for all of the following responsibilities listed in this chapter.

In other cases, the user may lease or rent the system without supervisory, operational, maintenance, support personnel, or services from the system owner. In these situations, sections 1.8.1 “The owner of the system” and 1.8.2 “The user of the system” shall apply.

1.8.1 The owner of the system

The responsibilities of the owner of the system are:

- a) to make sure the system meets the requirements as given in this manual as well as specific job requirements defined by the user,
- b) to make sure the system and all necessary components, specified by the manufacturer, meet the user's requested configuration and capacity,
- c) to provide the applicable capacity charts to the user,
- d) to provide this manual to the user to enable correct assembly, disassembly, operation and maintenance information,
- e) to make sure all inspections and maintenance activities are performed,
- f) to designate personnel for maintenance, repair, transport, assembly, and disassembly,

- g) and to designate personnel for inspections as required in the applicable chapters.

1.8.2 The user of the system

The responsibilities of the user of the system are:

- a) to comply with the requirements of this manual and all regulations applicable at the work site,
- b) to use supervisors for activities,
- c) to ensure that the system is in proper operating condition, prior to initial use at the worksite by
 - verifying that the Owner has provided this manual,
 - and verifying that a frequent inspection has been performed,
- d) to verify that the system has the necessary capacity to perform the proposed operations in the planned configuration,
- e) to ensure the assigned operators have been notified of adjustments or repairs that have not yet been completed, prior to commencing operations,
- f) to designate personnel for inspections as required in the applicable chapter,
- g) to designate personnel for maintenance, repair, transport, assembly, and disassembly,
- h) to ensure that all personnel involved in maintenance, repair, transport, assembly, disassembly, and inspection are aware of their responsibilities, assigned duties, and the associated hazards,
- i) and to ensure that the inspection, testing, and maintenance programs specified by owner are followed.

1.8.3 The site supervisor

In some cases, the site supervisor and the system director may be the same person.

The responsibilities of the site supervisor shall include the following:

1. ensuring that the system meets the requirements prior to initial site usage.
2. determining if additional regulations or requirements are applicable.
3. ensuring that a qualified person is designated as the system director.
4. ensuring that the operations are coordinated with other jobsite activities that will be affected by or will affect the operations.
5. ensuring that the area for the system is adequately prepared. The preparation includes, but is not limited to, the following:
 - a. access for the system and associated equipment.
 - b. sufficient room to assemble and disassemble the system.
 - c. an operating area that is suitable for the system with respect to levelness, surface conditions, support capability, proximity to power lines, excavations, slopes, underground utilities, subsurface construction, and obstructions to operation.
 - d. traffic control as necessary to restrict unauthorized access to the system's working area.
 - e. ensuring that work involving the assembly and disassembly of system is supervised by a qualified person.
 - f. ensuring that operators meet the physical, knowledge, and skill requirements as described in this manual.
 - g. ensuring that conditions that may adversely affect the operations are addressed. Such conditions include, but are not limited to, the following:
 - poor soil or support conditions
 - wind velocity or gusting wind
 - weather conditions
 - extreme temperatures
 - inadequate lighting
 - operating surface conditions
 - excessive noise proximity to energized sources (e.g., power lines, pressurized lines)
 - ensuring that work performed by the rigging crew is supervised by a qualified person
 - ensuring that maintenance is performed by a designated person

1.8.4 The system director

The system Director's responsibilities shall include the following:

- a. being present at the job site during the operations.
- b. stopping the operations if alerted to an unsafe condition.

- c. ensuring that the preparation of the area needed to support the operation has been completed before the operation starts.
- d. ensuring necessary traffic controls are in place to restrict unauthorized access to the system's work area.
- e. ensuring that personnel involved in the operations understand their responsibilities, assigned duties, and the associated hazards.
- f. addressing safety concerns raised by the system operator or other personnel and being responsible if he decides to overrule those concerns and directs the operation to continue. In all cases the manufacturer's criteria for safe operation and the requirements of this manual shall be followed.
- g. designating the signal person(s) and conveying that information to the system operator.
- h. evaluating the operation in proximity to energized sources.
- i. ensuring precautions are implemented when hazards associated with special load handling operations are present. Such operations may include, but are not limited to, the following:
 - multiple types of system used simultaneously
 - shifting centre(s) of gravity or lifting below the centre of gravity
 - shifting, inclined, or moving surfaces
 - operating barges
 - informing the system operator of the weight and planned movement of the loads to be handled.
 - obtaining the system operator's verification that this weight does not exceed the system's rated load.
 - ensuring that load rigging personnel have been designated for the system.
 - ensuring that the load is properly rigged and stable.

1.8.5 The operators

The system Operator shall be responsible for the following listed items.

The system Operator shall not be responsible for hazards or conditions that are not under his direct control and that adversely affect the system operations.

Whenever the system Operator has doubt as to the safety of operation, the system Operator shall stop the system functions in a controlled manner. System operations shall resume only after safety concerns have been addressed and the continuation of the operation is directed by the system Director.







The system Operator's responsibilities shall include the following:



- a. reviewing the requirements for the system with the Director before the operations.
- b. knowing what types of site conditions could adversely affect the operation of the system and consulting with the system Director concerning the possible presence of those conditions.
- c. understanding and applying the information contained in this manual.
- d. understanding the system's functions and limitations as well as its particular operating characteristics.
- e. using the system's load/capacity chart(s) and diagrams and applying all notes and warnings related to the charts to confirm the correct system configuration to suit the load, site, and load handling conditions.
- f. refusing to operate the system when any portion of the load or the system could be adversely affected by proximity to energized sources until evaluated and approved by a qualified person.
- g. performing inspections as specified in the applicable chapter.
- h. promptly reporting the need for any adjustments or repairs.
- i. following applicable lock out/tag out procedures,
- j. not operating the system when physically or mentally unfit.
- k. ensuring that all controls are in the off or neutral position and that all personnel are in the clear before energizing the system.
- l. not engaging in any practice that will divert his attention while actually operating the system controls.
- m. testing the system function controls that will be used and operating the system only if those function controls respond properly.
- n. operating the system's functions, under normal operating conditions, in a smooth and controlled manner.
- o. knowing and following the procedures specified by the system manufacturer or approved by a qualified person for assembly, disassembly, and setting up the system.
- p. knowing how to travel the system, if applicable.
- q. ensuring that the load and rigging weight(s) have been provided.

- r. calculating or determining the rated load for all configurations that will be used and verifying, using the capacity chart(s), that the system has sufficient capacity for the proposed operation.
- s. considering all factors known that might affect the system capacity and informing the system Director of the need to make appropriate adjustments.
- t. knowing the standard and special signals as specified in the applicable chapter and responding to such signals from the signalperson. When a signalperson is not required, the system Operator is then responsible for the movement of the system. However, the system Operator shall obey a stop signal at all times, no matter who gives it.
- u. Understanding of rigging and basic rigging procedures. Ensuring that the load is properly secured and will be lifted safely.
- v. if power fails during the operations
 - set all locking devices
 - move all power controls to the OFF or neutral position
 - secure and stabilize the load, if practical
- w. before leaving the system unattended
 - secure and stabilize the load
 - set all locking devices
 - put the system controls in the OFF or neutral position
 - turn off the system power source
 - follow the recommendations as given in this manual or given by a qualified person for securing the system

1.9 Hand signals

The following hand signals are applicable when using the system:

<p>RAISE.</p> <p>With forearm vertical, forefinger pointing up, move hand in small horizontal circle.</p>		<p>LOWER.</p> <p>With arm extended downward, forefinger pointing down, move hand in small horizontal circle.</p>	
<p>GANTRY TRAVEL.</p> <p>Arm extended forward, hand open and slightly raised, make pushing motion in direction of travel.</p>		<p>SIDE SHIFT.</p> <p>Palm up, fingers closed, thumb pointing in direction of motion, jerk hand horizontally.</p>	
<p>STOP.</p> <p>Arm extended, palm down, move arm back and forth horizontally.</p>		<p>EMERGENCY STOP.</p> <p>Both arms extended, palms down, move arms back and forth horizontally.</p>	

<p>END EVERYTHING.</p> <p>Clasp hands in front of body.</p>		<p>INDIVIDUAL BOOMS.</p> <p>Hold up: one finger for boom marked: "1," two fingers for boom marked "2".</p> <p>Regular signals follow.</p>	
---	---	---	---

1.10 Lifetime

No lifetime of the System is specified, since its safe and effective lifetime strongly depends on

- the intensity of use,
- the quality of the maintenance,
- the service conditions the system is exposed to, like wet or salty environments,
- and the load to which the system is exposed.

1.11 Warning symbols used within this document

In this manual warnings and symbols are used to draw your attention to important safety information. The table below shows the applied warnings and symbols:



NB is used to highlight important **work activities** and for **additional information**



Caution is used if failure to heed the given instructions may result in **damage to the system**.



Attention is a general warning to the operator of potential damage to **equipment** and the **environment**.



Hazard draws the user's attention to potential **hazards to personnel** if work instructions are not followed precisely.

2 General safety aspects

This chapter contains general safety aspects.
Specific safety directions are mentioned in other chapters.

2.1 Mandatory protective gear

While using the System ensure that the locally applicable safety regulations are observed

Make sure that all people on the working place observe the following safety regulations:



Always wear safety goggles and a safety helmet



Always wear safety footwear



Wear safety gloves. But we strongly advise not to wear them when operating handheld control consoles



Wear a safety harness when working at heights more than 2 meters

2.2 General safety regulations

Special safety regulations are given in the relevant national legislations or company regulations for accident prevention. Compliance with these rules and regulations is a legal requirement and a condition of employment. In addition to the safety regulations set out under the law, also observe the following points:

- Keep the worksite **clean**.
- Before every start-up, always check that there are no **persons** in an unsafe situation or position with respect to the System. Stop working if, despite warnings, there are still employees in an unsafe situation.
- Only use the System on an adequately stable and robust **subsurface**.
- Keep all equipment out of the area of above-ground **power lines**.
- The **coverings** must be closed (this does not apply to the covering on control panels).
- The operator must switch off the System before leaving it **unattended**.
- Use all required **Personal Protection** Equipment (PPE).
- Do not wear any loose **clothing or jewellery**. Long hair must be tied back.
- **Tools** and equipment, necessary for (dis-)assembly of the System as well as for maintenance have to be in good condition. Badly maintained equipment can cause time wastage and lead to permanent damage to the equipment and/or its surroundings
- Keep the hydraulic and moving equipment of the System **clean** to prevent it from jamming or causing damage to itself or other equipment.
- Do not use the System, whether loaded or not, while unauthorized people are in its **vicinity**. The System can be operated remotely.
- Maintain **focus** during the work. Carelessness may result in serious injuries.
- Additional **lifting gear** and accessories such as hawsers, shackles, lugs, slings etc. must comply with the legal requirements imposed in the country of use.
- **Inspect** the condition of the System before *every* individual start-up, given the fact that the slightest defect may have severe consequences.
- Personnel shall not place any **part of their body** under the load.
- Personnel shall **remain clear** of the system during operation.
- Personnel shall **not ride** on the system while it is moving or being moved.
- Remove loose tools or components from the load or the System if the load will be moved as they might fall down during moving, which can lead to fatal accidents.

Enerpac is not liable for improper use of accessories in combination with the System.

2.3 Symbols applied to the System

The System can be labelled with

- warning symbols,
- mandatory signs.

The table below shows the most commonly used **warning symbols** in industrial environments:



Danger of contact with moving machine parts



Danger of lethal voltage in the control panels



Danger of **parts of hands** getting trapped/caught



Danger of **parts of feet** getting trapped/caught



Danger of **falling**



Danger Exercise extreme attention and caution when **under moving loads**.



Danger of getting **trapped**/caught between moving parts.

The table below shows the most common symbols of **mandatory signs** in industrial environments:



Read the instruction manual.



Wear **gloves** to prevent injury from and/or exposure to chemicals.



Wear safety **glasses** to prevent eye injuries.



Wear safety **shoes** to prevent injuries caused by falling objects and/or feet getting caught in machinery.



Wear **hearing** protection.



Wear a safety **helmet** to prevent injuries caused by falling objects.



Wear a safety **harness**



Hoisting point



Strapping point for transport

**NB:**

- The stickers on the machine are official documents and it is not permitted to alter them or render them illegible
- It is strictly obligatory to observe the warning symbols and the mandatory signs applied to the machine.

2.4 Welding work

- Welding, cutting and grinding work on the System is only permitted with the **prior written consent** of Enerpac.
- Welders must be properly qualified and must have a valid welding certificate.
- If welding work needs to be performed on the System, then
- Switch the machine off
- Disconnect all power cables and communications cables
- Connect the system to a direct earth line.



NB: welding, cutting, grinding or any other structural adjustment work on the System is not permitted without Enerpac's prior written permission.

2.5 Working on the electrical system

- In the event of an electrical fault in the electric control system, you must bring all connected devices into a safe condition. **Switch off** the System.
- Work on the electrical system must be performed by a competent, **qualified electrician** or by trained personnel under the direct supervision of a qualified electrician, in compliance with all applicable rules and regulations such as
 - Ref 1 "Operation of electrical installations - Low voltage"
 - Ref 2 "Operation of electrical installations".
- **Switch the power off** before inspection, maintenance or repair of the System. Make sure that there is no power on the relevant parts. If necessary, connect the machine to earth. Insulate any adjacent component that is still under voltage.
- Check and inspect the electrical system of the System at **regular intervals**. Problems, such as loose connections and damaged or stuck wiring, must be resolved immediately. Only use original fuses and circuit breakers with the correct current value.
- If work does need to be performed on components which are under **voltage**, then cordon off the work zone and only use certified and properly insulated tools.

2.6 Working on the hydraulic system

- Work on the hydraulics system or other components in a pressurized system must be performed by a **competent, qualified installer** or by trained personnel under the direct supervision of a qualified installer, in compliance with all applicable rules and regulations.
- Check all pipes, hoses, quick-release couplings and screw joints **regularly** for leaks and visible external damage. Repair damage immediately. Pressurized hydraulic fluid leaks may cause serious injury, and it may cause fire and damage to the environment.
- If parts need to be removed from the hydraulic system, the **hydraulic pressure must be released** according to the instructions in this manual before beginning work.
- Expand and install pressurized hydraulic pipes, tubes and lines in accordance with professional standards.
- Make sure that no ports have been **switched** during re-installation work.
- All parts and the length and quality of hoses meet the requirements of Ref 3 "General rules and safety requirements for systems and their components".

2.7 Fire

The course of action in the event of an emergency is determined by the rules and regulations applicable on the worksite. Every company has its own special rules. So make sure you are up-to-date on these rules.

In any case, the following actions are necessary in the event of a fire:

- Keep **calm**.
- **Report** the emergency to the employee responsible for in-house emergency services (IHES). Tell who you are, where you are located and describe the emergency situation. (The IHES employee will notify external emergency services.)
- **Warn** your colleagues.
- **Extinguish** the fire if it is still in its early stage, using the extinguishing means available onsite.
- If possible, **switch off** the electrical power supply.
- Leave **the scene** of the emergency situation and report to the rendezvous point.



Caution: Never use water to put out an electrical fire or a fluid fire

2.8 Working with hazardous substances

It is thought that special first aid procedures are required in cases of accidents with chemicals. But in cases of small quantities, standard measures suffice:

1. rinse thoroughly with water
2. wash with soap
3. provide fresh air
4. remove any contaminated clothing

In common the following rules are applicable:

- Contact with **skin**:
 - rinse thoroughly with water
 - remove any contaminated clothing
 - wash the relevant body parts with soap.
- Contact with **eyes**:
 - rinse thoroughly with water (10 till 15 minutes) using eye wash fountain
 - consult a doctor.
- Ingestion:
 - rinse the mouth out with water.
 - If necessary, dilute the substance by drinking water.
 - If a corrosive substance has been ingested, do not induce vomiting. This is to prevent the substance coming into contact with the sensitive oesophagus again.
 - If the victim is unconscious, never attempt to induce vomiting or have the victim drink anything.










Using a 'neutralizing solution' (such as a base for an acid) can actually make the situation **worse**. In addition to this, it is advisable to consult the safety information (TREM CARD book, safety information sheets and the catalogue) and report everything that is relevant to the accident to a doctor.

When work has to be done in confined spaces:

- Wear personal protection equipment
- ventilate according to the relevant regulations
- Ask a colleague to remain by the entrance in order to provide assistance in the event of an emergency.
- You are legally required to be **familiar with the potential hazards** of the product. The safety information sheets are intended to provide adequate, correct and up-to-date information on all substances used on the worksite.
- Relevant safety information sheets are given in G "Hydraulic fluid safety information".

During maintenance, you may work with substances fitted with **GHS symbols**. These GHS symbols are explained in the next below.¹

¹ CLP is the Regulation on Classification, Labelling and Packaging of substances and mixtures (EC No 1272/2008). This regulation brings European legislation on the classification, labelling and packaging of chemical substances into accordance with the GHS (Global Harmonised System for classification and labelling of chemical substances). The GHS is a United Nations system used to identify chemical substances and inform users of their hazards using standard symbols and phrases on labels, packaging

Symbol	General hazard indication	Possible precautionary measures
	May cause an allergic reaction on the skin.	Contaminated work clothing must not leave the workspace.
	Harmful to aquatic organisms, with long term effects	Do not discharge into the environment.
	Causes serious eye injury and/or damage to the skin.	Wear eye protection and skin protection (such as protective gloves).
	Fire hazard when heated and/or in presence of sparks.	Keep away from heat, sparks, open flames and/or hot surfaces. No smoking!
	May cause fire (oxidising agent).	Take the necessary precautionary measures to prevent mixture with flammable substances.
	Toxic in cases of ingestion and/or skin penetration	Do not eat, drink or smoke when using this product.
	May cause hypersensitivity of the airways or heritable mutations in male reproductive cells, is a potential carcinogen and/or is toxic to human reproduction	Apply a strict hygiene/health policy and wear suitable personal protection equipment.
	Explosion hazard when heated and/or in presence of sparks	Keep away from heat, sparks, open flames and/or hot surfaces. No smoking!
	Contains a gas under pressure. May explode if heated	Keep out of sunlight. Store in a well-ventilated space.

2.9 Assembly and disassembly

- **Assembly** and disassembly of the System has to be performed by properly trained operators
- Only use **certified lifting** and hoisting equipment.
Check the validity of these certificates and qualifications.
- Only use lifting and hoisting equipment with **suitable capacity** for the loads in question.
- Before commissioning, any parts that were disassembled for transport must be **re-assembled**, re-installed, checked and approved by qualified personnel.
- Make sure that the **instructions in this manual** have been followed precisely before commissioning the System.
- **Lift** loads as described in the user manual (connection points for lifting hooks) and observe the professional standards.



Hazard: Any components that are blocked or stuck in any way (and any parts connected to these components) will be under mechanical tension. If you release these parts, they could change position suddenly and seriously injure you

2.10 Transport, loading and unloading of the System

- Loading and unloading has to be performed by properly trained operators
- Only use lifting and hoisting equipment with suitable capacity for the loads in question.
- Lift loads as described in the user manual (connection points for lifting hooks) and observe the professional standards.

and Safety Information Sheets (SIS).



- Only use suitable containers with adequate load-bearing capacity for transport purposes.
- Secure the load properly using suitable connection points and twist locks (for the containers). When using twist locks secure them properly and check that the locking mechanism is working correctly.
- Disconnect all electrical and hydraulic connections when the System has to be moved, even if it is for only a short distance.
- To avoid damage during transport use timbers, rubber pads and plastic for packaging.
- Containers may be used for transport, since they provide rigid protection against and avoid weather influences. Make sure that all parts are secured against sliding around.

2.11 Dealing with hoses

2.11.1 Common directions

- Make sure the **maximum** permitted pressure is never exceeded:
 - Do not change any safety setting.
- Ensure that the **accumulators** and by-pass hoses are in good condition.
- Do not **drive over** or stand on the hoses:
 - Standing on and driving over the hoses causes damage to the hose fabric, which causes leaks.
 - A sudden increase in pressure caused by squeezing the hose causes serious damage to other components.
- Do not **pull** on a hose that is connected:
 - If pulling forces are exerted on a hydraulic coupling the hose and coupling interface will weaken which may result in the hose bursting out of the coupling.
 - Always lift a hose by the hose itself, whilst supporting the coupling.
 - Stow hoses in such a way that no forces (gravitational force) are exerted on the coupling.
- While moving the hoses, prevent the couplings **being dragged** over the ground:
 - Prevent excessive wear on the couplings and hoses by transporting them on pallets, if possible.
 - During assembly the hose must be supported by necessary use bend guides to prevent twisting of the hose.
- Protect the hose **sleeve** in places where chafing etc. cannot be avoided:
 - Wear spots can be prevented by sliding protective sleeves over areas where wear is expected or by covering sharp edges.
- Change **worn or damaged hoses** immediately:
 - If a hose is pressurized continuously by more than 20% above working pressure it must be replaced.
- Do not use **dirty** or corroded couplings.
 - They are less reliable
 - They will cause leaks over time.
 - They pollute the hydraulic system
- **Disconnecting** hydraulic tubing and hoses shall be done with utmost care.
 - The system is designed in such a way that hydraulic pressure drops to zero when the system is switched off. Nevertheless, pressure can remain due to
 - The presence of load on the system
 - Raise of temperature
 - But the hydraulic connections have been designed in such a way that either
 - they cannot be uncoupled when they're under pressure, or
 - they can be uncoupled under pressure of only a few bars, but measures have been taken that no oil can come out
 - Always use the manometers of the System to verify that the pressure is zero.

2.11.2 Main procedure for connecting hoses

1.	Inspect the couplings. Clean the coupling if dirty. Replace the coupling if damaged.
2.	Clean the inner and outer side of the couplings before they are mounted; dirt might get in the system causing damage. Use degreaser.
3.	Dry the couplings with paper and visually check them for dirt.  Caution: Do not use any brake cleaner or other detergents; they might affect the couplings.
4.	<div style="display: flex; align-items: flex-start;"> <div style="flex: 1;"> <p>Hoses which are not mounted may be under pressure though, due to exposure to warmth. If so, it is hard to connect the couplings. To reduce the pressure in the hose:</p> <ol style="list-style-type: none"> 1. Twist the coupling off the hose. <i>A little until oil will come out</i> 2. Turn the coupling tight again. </div> <div style="flex: 1; text-align: center;"> <p>Unscrew</p>  </div> </div>
5.	Screw the screw-coupling together to the end. <i>While tightening the couplings, the oil passage is opened up</i>



Hazard: Careless handling of hydraulics can cause serious injuries


3 System Overview

This chapter describes the main functions and components of the System.

3.1 General

The System is intended to move a heavy load:


- In vertical direction by extending the booms.
- In longitudinal direction by travelling along tracks.
- In transversal direction by moving the side shift units along the header beams. This is optional.



3.2 Main parts



NB: Pictures may differ for the different systems.



The system is a four-point lifting system which can move a heavy load in three directions:

- Vertical direction, by extending the four **booms**. The booms move computer controlled and are synchronized.
- Longitudinal direction, by moving the units along the **skid tracks**.

Each unit has its own on-board hydraulic power; no hydraulic hoses are used on the working scene. Only electricity has to be connected to each unit.

The system is controlled remotely by a handheld **remote-control console**. This enables operating the system on a safe distance.

The load can be moved in transversal direction by **side shift units** which run along the **header beams**. Side shift units are provided with electro motors.

Different types of side shift units are available.



SSU300



SSU150




SSU600


Optionally, the side shift units can be provided with

- A top swivel. This enables mounting header beams on top of the side shift units.
- A rotation anchor. This enables rotating the load by manpower while the load is lifted.
- Sling anchors. This enables the use of slings for lifting.


Top swivel



Sling anchor




Rotation anchor



The load can be suspended by **lifting lugs** as well.


Lifting lug




3.2.1 The unit

Common characteristics of the SBL500, SBL900 and SBL1100 are explained in a common section. Specific details are given in separate sections.

3.2.1.1 Specific SBL 500 details




- The HPU powers the lifting cylinder and wheel drives.
- The boom consists of a telescopic cylinder system, extending in two (SBL900) or three (SBL500, SBL1100) stages
- Each unit is provided with a sensor which measures the travelling distance. The sensor is located at the axis of the unit.




3.2.1.2 Specific SBL900, SBL1100 details

The HPU powers the tilting cylinders, the lifting cylinder and the wheel drives.




- The unit is provided with roller tracks.
- Each unit is provided with a sensor which measures the travelling distance. The sensor is located at the axis of the unit.



- The tilting cylinders rotate the boom to upright position.
- The boom consists of a telescopic cylinder system, extending in two (SBL900) or three (SBL1100) stages

3.2.1.3 Commonalities SBL500, SBL900, SBL1100

- The units have to be provided with electrical power.
- The swivel enables flexible mounting of the header beam.
- The side shift, if applied, is provided with power by the power cable.
- In order to synchronise the lifting heights of all units, each unit is provided with a stroke sensor, which is connected by a line to the top of the cylinder.



- Using the remote-control unit, all units can be controlled individually or simultaneously on a safe distance. The remote-control unit is a wireless device.
- At the front side of the electrical cabinet, which contains all electronics of the unit. On the front side of the cabinet the local control panel is located. Using the buttons and controls of the control panel, the unit can be controlled locally. Other units cannot be controlled by the control panel. Local control is intended for installation and maintenance purposes only.




SBL500




SBL900, SBL1100

- The boom is provided with guiding pads at the inner side, which
 - guide the nested stages of the boom.
 - enable smooth moving of the stages into each other
 - make sure that the sections are centralized with minimal clearance but without being clamped.



The guiding pads, which are mounted inside the booms, are adjustable in order to centralise the stages precisely. Since guiding pads are made of plastic fabric, they are subject to wear.

- Mechanical locking systems are provided to prevent the load from lowering when the power is switched off. The system is implemented as a set of wedges which prevent lowering of the stages.



3.2.2 Header beams

The header beams across the top of the Units create a portal. They can consist of more sections.



Header beams of various lengths and capacities can be applied; reference is made to Appendix Z “Compatibility of system parts”. The header beams have to be applied in accordance with the capacity charts of the specific header beam.

Header beams of different brand may be applied if


- the material properties are the same,
- made from similar web, and
- flange dimensions match with the Enerpac beams



Attention: Header beams of foreign make can be applied if their capacity is sufficient, but Enerpac will not take any responsibility for it.

3.2.3 The skid tracks

The Skid tracks form a railway on which the system travels.
Skid tracks are provided with a longitudinal ridge to guide the units while travelling.



Attention: Skid tracks of foreign make can be applied if their capacity is sufficient, but Enerpac will not take any responsibility for it.

3.2.4 Side shift units


The load can be affixed to the header beam by means of side shift units.
The side shift units enables the load to be moved in transverse direction.
Each side shift is provided with an electrical drive which propels rollers. The rollers run on the header beams. The drive has a single speed.

The side shift units can be controlled


- by the remote-control device
- by the control panel on the electrical cabinet.; this is intended for maintenance and setup purposes.

The next section shows the types of side shift units which can be applied. Their principles are equal; just the construction and the lifting capacities differ.


3.2.4.1 Type SSU150



3.2.4.2 Type SSU300




3.2.4.3 SSU600




3.2.5 Options for side shift units

3.2.5.1 Transporting frames


Frames for transport and storage are available for all types of side shift units.



SSU150




SSU300




SSU600

3.2.5.2 Sling anchors

Sling anchors enable usage of slings for lifting. The sling anchors are positioned over the anchor plate of the side shift unit. Sling anchors are available for all types of side shift units.




SSU150, SSU300



SSU600


3.2.5.3 Extended anchor plates

Anchor plates with extended length are available for all types of side shift units.




3.2.5.4 Top swivels

Top swivels are available for all types of side shift units.



SSU150, SSU300



SSU600


3.2.5.5 Rotation anchor

The rotation anchor is a device which enables you to rotate a heavy load. It is attached to a side shift unit, which on its turn is attached to a gantry system.

The rotation anchor is a passive device; it does not contain any electrics or hydraulics.

Rotation is done by hand force.

The rotation anchor can be applied for all types of side shift units.




3.2.5.6 Sling guides

Sling guides enable suspending a load to a header beam using slings.


Two types of sling guides are available:

- Type HBBSG (Header Beam Box Sling Guide)
- Type HBHSG (Header Beam H Sling Guide)

They differ in bearing capacity and header beam width.




Both Sling guide types are to be mounted over the header beam.
The slings are mounted over the sling guides.




3.2.6 The lifting lugs

If there is no need to move the load in transverse direction, you can make use of simple lifting lugs to affix the load to the header beam.



Depending on the mass of the load to be lifted you can apply lifting lugs

- in double-plate type
- in single-plate type



Attention: Lifting lugs of foreign make can be applied if their capacity is sufficient, but Enerpac will not take any responsibility for it.

3.2.7 The remote-control console

The remote-control console enables the operator to control the complete system (all four units simultaneously) on a safe distance. Connection with the system can be made either by a radio link or by wire.



The remote-control console enables the operator to control the system on a safe distance. The device is able to control

- one single unit,
- two or more units in a synchronised way.


The remote-control console can be connected to the system

- by radio
- by wire

3.3 System specifications

3.3.1 Main specifications

The specifications shown below are applicable for SBL500, SBL900 and SBL1100.

Specification of the power source			
Voltage	380 to 480 VAC/ 3-phase. The units feature automatic phase detection according to the rotation direction of the electric.		
Frequency	50-60 Hz		
Plug	5 pins		
Current per unit	SBL500: 16 A SBL900: 16 A SBL1100: 16 A		
Power per unit	SBL500: 7,5 kW SBL900: 7,5 kW SBL1100: 7,5 kW		
Fuse	Connected two by two	32 A	
	Connected individually	16 A	
Temperatures			
Operating	System incl Remote-Control unit	Min	-10 °C  NB: Below 0° the battery of remote-control device has half capacity.
		Max	+50 °C
	Hydraulic oil	Min start up	-20 °C
		Min operation	+10 °C
	Max in operation	+70 °C	
Storage	System	Min	-25 °C
		Max	+60 °C
	Remote-Control device	Min	-25 °C
		Max	+45 °C
Charging of Remote control	Min	0 °C	
	Max	+45 °C	
Hydraulic oil			
Type	Enerpac Shell Tellus S4V46		
Minimum requirement	The purity of the medium is in accordance with: - class 10 of NAS 1638 - class 21/19/16 of ISO DIS 4406		
Volume	SBL500: 427 litres, SBL900: 750 litres, SBL1100: 750 litres		
Noise pressure			
Measured at ear height at nominal loading one metre away from any Unit's electric motor. <i>(The C-weighted instantaneous sound pressure of 130 dB is never exceeded)</i>			77 dB (A)



Caution: There is a risk of ice accretion at temperatures below 0°C. If ice has accreted on machine components, they cannot be used since they may lock up



NB: Consult Enerpac if you want to apply the system by other temperatures.

3.3.2 Functional specifications

3.3.2.1 Units

The table shows the functional specifications of the systems.

Moving directions of the load			
Horizontally	Lateral direction	By using side shifts	
	Longitudinal direction	By moving along the skid tracks	
Vertically	By extending the cylinders		
Velocities			
SBL500	Travelling speed		31.0 m/h
	Lifting speed	Low speed	Stage 1: 8.5 m/h Stage 2: 12.5 m/h Stage 3: 21.2 m/h
		High speed	Stage 1: 16.5 m/h
	Lowering speed		Stage 1: 34.1 m/h Stage 2: 28.8 m/h Stage 3: 29.3 m/h
SBL900	Travelling speed		18.0 m/h
	Lifting speed	Low speed	Stage 1: 5.0 m/h Stage 2: 7.6 m/h
		High speed	Stage 1: 10.1 m/h
	Lowering speed		Stage 1: 20.9 m/h Stage 2: 13.5 m/h
SBL1100	Travelling speed		18.0 m/h
	Lifting speed	Low speed	Stage 1: 5.0 m/h Stage 2: 7.7 m/h Stage 3: 13.0 m/h
		High speed	Stage 1: 10.4 m/h
	Lowering speed		Stage 1: 20.0 m/h (unloaded 7.5) Stage 2: 17.6 m/h (unloaded 15.8) Stage 3: 18.0 m/h (unloaded 17.5)
Lift capacities per unit			
SBL500	Stage 1	1300 kN	0 mm - 1960 mm
	Stage 2	1300 kN	1960 mm - 3870 mm
	Stage 3	750 kN	3870 mm - 5580 mm
SBL900	Stage 1	2224 kN	5060 mm - 8372 mm
	Stage 2	1480 kN	8372 mm - 11360 mm
SBL1100	Stage 1	2621 kN	4409 mm - 7060 mm
	Stage 2	1689 kN	7060 mm - 9724 mm
	Stage 3	945 kN	9724 mm - 12016 mm

For bearing capacities of header beams and lifting lugs reference is made to Ref 5 "Technical handbook".

3.3.3 Side shift units

Velocities		
Side shift	SSU125	515 mm / minute
	SSU150	515 mm / minute
	SSU300	900 mm / minute
	SSU600	900 mm / minute
Bearing capacities		
Side shift	SSU125	312.2 kN
	SSU150	375.0 kN
	SSU300	750.0 kN
	SSU600	1500.0 kN

3.3.4 Mechanical locking system

Mechanical locking system		
Maximum bearing capacity	SBL500	180 tons
	SBL900	
	SBL1100	

3.3.5 Rotation anchor

Safe workload	750 kN
Rotation	360° both clockwise and counter clockwise

3.3.6 Sling guides




HBHSG	500 kN
HBBSG	2500 kN


3.3.7 Dimensions and masses

For dimensions and masses of the parts of the systems reference is made to Ref 5 "Technical handbook".

3.4 System configurations

3.4.1 Header beam configurations

<p>Commonly used configuration. Two header beams are applied, each of them connecting two units.</p> <p>Transverse stability is provided by the beams.</p> <p>The units contribute to the longitudinal stability.</p>	
<p>Configuration with two header beams and one longitudinal beam.</p> <p>Three-point lifting is possible. Using three-point lifting it is easier to spread the force on the lifting slings equally.</p>	
<p>Configuration with two header beams and two longitudinal beams.</p> <p>The configuration offers increased rotational stability.</p>	

<p>Configuration with header beams mounted on top of the side shift units.</p> <p>Use is made of top swivel units which are mounted on top of the side shift units.</p> <p>The configuration enables transversal moving of the header beams.</p>	
--	--





NB: Observe the following:




- The use of other components than purchased by Enerpac is possible as long as those components are used in accordance with their own specifications.
- When you deviate from the configurations as proposed, make sure the correct calculations are made. Enerpac may advise.
- Enerpac cannot be held responsible for the use of other configurations than the proposed.
- Contact Enerpac if you want to use other configurations than the depicted
- A configuration, in which foreign lifting equipment such as strand-jacks and skidding systems is applied, is allowed as long as all static requirements with reference to strength, deflections and stability are fulfilled.

3.4.2 Side shift units and header beams

For possible combinations of units, header beams, side shift units and lifting lugs reference is made to Appendix Z "Compatibility of system parts".

3.5 Position of the load

<p>The system can lift a load if it is suspended from the header beams.</p>	
<p>If you want to put the load on top of the header beams, contact Enerpac for advice.</p>	

<p>The system is able to tilt (rotate) a load. Two units are lifting the load upwards and travel simultaneously. The other two unit stays passive.</p>	
<p>The system is exclusively suitable for four leg lifting.</p> <p> Hazard: Using the system with only two legs may cause instability.</p>	



NB: Enerpac can advise you when you want to use the System in other configurations than the proposed ones.

3.6 Service conditions

- The System is intended for hoisting loads. Do not use the system for any other purpose.
- No alterations may be made to the System. Only use the system as it was delivered.



NB: The system is explicitly **not intended** for hoisting people.



Hazard: using the system for other purposes than the intended use may cause hazards to personnel and may cause damage to the equipment.



Hazard: Lifting a load with **less than four units** is a high-risk operation. The system with its load can tip-over due to

- out of centre of gravity
- swinging of the load
- large sling angles

4 Plan an operation

In this chapter, the planning activities for a lifting operation are described.

Record the preparation in the checklist given in Appendix A “Checklist for planning”.

- Type of operation
 - Lift / lower
 - Move in longitudinal direction
 - Move in transversal direction
- The system
 - Lifting capacity of the most heavily loaded unit.
 - Capacity of the header beams
 - Minimum force on each unit is sufficient
 - Maximum force per anchor or side shift does not exceed the max
 - The force on the header beam does not exceed the max.
- Lifting lug
 - Single plate or double plate
- Side shift unit
 - Required capacity
 - Rotation anchor applied? If so, can the load be turned without hitting any obstacle?
 - Is there enough space for personnel to pull the load around?
 - Top swivels applied?
 - Extended anchor plates for side shift units applied?
- The load
 - Mass of the load
 - Centre of gravity of the load with respect to the units
 - Dimensions of the load.
- The operation
 - Determine the lifting height
 - The travelling distance
 - Stage extension
 - Capacity in highest stage
- The environment
 - Bearing capacity of the subsoil
 - Is additional supporting material underneath the skid tracks necessary?
 - The wind load:
 - X direction
 - Y direction



NB: It is of the utmost importance to read this whole chapter carefully before starting the lifting operation.



Hazard: failure to prepare a lifting operation correctly may result in loss of System stability.

4.1 Bearing ground pressure calculation

For bearing ground calculations use is made of the effect that pressure spreads down in an angle of 45°.


The calculations are different for units with wheels (SBL500) and for units with roller tracks (SBL900, SBL1100).

4.1.1 Calculations for units with wheels


The skid tracks can be put

- directly on the subsoil.

The bearing surface in length direction for one wheel is two times the height of the skid track, as shown in the picture below.



- on a foundation:
- to compensate unevenness in the subsoil
- to reduce the bearing pressure. Use is made of the effect that pressure spreads down in an angle of 45°, as shown below. So, the higher the foundation, the lower the ground bearing pressure.
- The bearing surface in length direction for one wheel is two times the height of the skid track + height of the foundation), as shown in the picture below.



NB: The pressure on the subsoil is inverse proportional with the height of the foundation


The following sections describe in detail how ground bearing pressure can be calculated.



NB: Feel free to apply your own calculation methods for ground bearing pressure.

4.1.1.1 No foundation applied

The dimensions of the bearing surface are as follows:



To calculate the bearing pressure, you *might* use the following procedure:

Parameter	Abbrev	Value
Skid track	height	Skid height
	width	Skid width
Own mass of one unit	Unit mass	2.13 metric ton
Mass of auxiliary material (beams, shackles etc)	Aux mass	15
Safety factor	S	1.65
Maximum force on one unit which can occur during the operation [kN]	F	Depends on the operation

1.	Bearing surface, including the spreading effect in length direction, of one unit	<p>4 wheels * 0.2 * 0.4 = 0.32</p>
2.	Pressure on the ground [metric tonnes / m ²]	$\sigma = \frac{F + Mass_{unit} + aux_{mass}/4}{Bearing_surface} * Safety_factor$

Example:

Load to be lifted

125 metric tons

Ground pressure

$$\sigma = \frac{125/4 + 2.13 + 15/4}{0.32} * 1.65 = \mathbf{191.5 \text{ metric tons / m}^2}$$



NB: Complete the checklist in appendix A “Checklist for planning”.




Attention: the exerted ground pressure may never exceed the bearing capacity of the subsoil.

4.1.1.2 Foundation applied


In order to reduce the bearing ground pressure, timbers of hard wood can be applied as foundation material. Steel plates have to be mounted on top of the timbers.

The dimensions of the bearing surface are as follows:



To calculate the bearing pressure, you might use the following procedure:

Parameter		Abbrev	Value
Skid track	height	Skid height	0.2 [m]
	width	Skid width	0.2 [m]
Timber	height	Timber height	Depends on the operation
	width	Timber width	
	gap	Timber gap	
Own mass of one Unit		Unit mass	2.13 metric tons (see section 3.2.3)
Mass of auxiliary material (beams, shackles etc)		Aux mass	15
Safety factor		S	1.65
Maximum force on one Unit which can occur during the operation [kN]		F	Depends on the operation

1.	Surface of one footprint = width * length	$(\text{Skid width} + 2 * \text{Timber height}) * [2 * (\text{Skid height} + \text{Timber height})]$
2.	The bearing surface of one Unit is formed by four footprints	
3.	Support ratio, to correct for the gaps between the timbers	Support_Ratio = $\text{Timber width} / (\text{Timber width} + \text{Timber gap})$
4.	Pressure on the ground [metric tonnes / m ²]	$\sigma = \frac{F + \text{Unit_mass} + \text{Aux_mass}/4}{\text{Bearing_surface} * \text{Support_Ratio}} * S$

Example:

Load to be lifted 125 metric tons

Timbers: Width 0.10 m
 Height 0.10 m
 Gap 0.05 m

Measures of one footprint:

Width: $\text{Skid width} + 2 * \text{Timber height} = 0.2 + 2 * 0.1 = 0.4 \text{ m}$

Length: $2 * (\text{Skid height} + \text{Timber height}) = 2 * (0.2 + 0.1) = 0.6 \text{ m}$

Surface: $0.4 * 0.6 = 0.24 \text{ m}^2$

Four footprints $4 * 0.24 = 0.96 \text{ m}^2$

Support ratio $0.10 / (0.10 + 0.05) = 0.67$

Ground pressure $\sigma = \frac{125/4 + 2.13 + 15/4}{0.96 * 0.67} * 1.65 = \mathbf{95 \text{ metric tons / m}^2}$



NB: Complete the checklist in appendix A “Checklist for planning”.




Attention: the exerted ground pressure may never exceed the bearing capacity of the subsoil.

4.1.2 Calculations for units with roller tracks

Skid tracks can be put

- directly on the ground, if the bearing capacity of the ground is sufficient.
- on a foundation:
- to compensate unevenness in the ground
- to reduce the bearing pressure.

Use is made of the effect that pressure spreads down in an angle of 45°, as shown below. So the higher the foundation, the lower the ground bearing pressure.



NB: The pressure on the subsoil is inverse proportional with the height of the foundation


The following sections describe in detail how ground bearing pressure can be calculated.



NB: Feel free to apply your own calculation methods for ground bearing pressure.


4.1.2.1 No foundation applied

The dimensions of the bearing surface are as follows:



To calculate the bearing pressure, you *may* use the following procedure:

Parameter		Abbrev	Value
Unit	Length	Unit length	2.76 m
	Own mass	Unit mass	12 metric tons
Skid track	Height	Skid height	0.3 m
	Width	Skid width	0.3 m
Auxiliary material (beams, shackles etc)		Aux mass	20 metric tons
Safety factor		S	1.7
Maximum force on one unit which can occur during the operation		F	t.b.s.

1.	Bearing surface, including the spreading effect in length direction, of one unit	 <p style="text-align: center;">Unit length + 2 * Skid height</p> <p style="text-align: center;">Skid width</p> <p>Bearing_surface = 2 tracks * [(Unit length + 2 * Skid height) * Skid width]</p>
2.	Pressure on the ground [metric tonnes / m ²]	$\sigma = \frac{F / 4 + \text{Unit_mass} + \text{Aux_mass} / 4}{\text{Bearing_surface}} * S$

Example:
 Load to be lifted 1068 metric tons
 Ground pressure $\sigma = \frac{1068 / 4 + 12 + 20 / 4}{2.0} * 1.7 = 241$ metric tons / m²



NB: Complete the checklist in appendix A “Checklist for planning”.




Attention: the exerted ground pressure may never exceed the bearing capacity of the subsoil.

4.1.2.2 Foundation applied


Timbers of Azobé hard wood can be used as foundation material.
 Steel plates have to be mounted between the timbers and the skid tracks.

The dimensions of the bearing surface are determined as follows:

- The width of one footprint:




- The length of one footprint:



To calculate the bearing pressure, you may use the following procedure:

Parameter		Abbrev	Value
Unit	Length	Unit length	2.76 m
	Own mass	Unit mass	12 metric tons
Skid track	Height	Skid height	0.3 m
	Width	Skid width	0.3 m
Auxiliary material (beams, shackles etc)		Aux mass	20 metric tons
Safety factor		S	1.7
Maximum force on one unit which can occur during the operation		F	Depends on the operation
Timbers	Width	Timber width	Depend on the applied timbers
	Height	Timber height	
	Gap between the timbers	Timber gap	

1.	Surface of one footprint = width * length	$(Skid\ width + 2 * Timber\ height) * [Unit\ length + 2 * (Skid\ height + Timber\ height)]$
2.	Surface on which the pressure is exerted for one unit = 2 * footprint	2 * footprint 
3.	Support ratio, to correct for the gaps between the timbers	Support_Ratio = $Timber\ width / (Timber\ width + Timber\ gap)$

4.	Pressure on the ground [metric tonnes / m ²]	$\sigma = \frac{F + Unit_mass + Aux_mass / 4}{Surface * SupportRatio} * S$
----	---	--

Example:

Load to be lifted 1068 metric tons

Timbers:	Width	0.10 m
	Height	0.10 m
	Gap	0.03 m

Measure of one footprint:

Width: Skid *width* + 2 * Timber *height* = 0.3 + 2 * 0.1 = 0.5

Length: Unit *length* + 2 * (Skid *height* + Timber *height*) = 2.76 + 2 * (0.3 + 0.1) = 3.56 m

L * W: 0.5 * 3.56 = 1.78 m²

Two footprints : 2 * 1.78 = 3.56 m²

Support ratio: 0.10 / (0.10 + 0.03) = 0.77

Ground pressure
$$\sigma = \frac{1068 / 4 + 12 + 20 / 4}{3.56 * 0.77} * 1.7 = 176 \text{ metric tons /m}^2$$




NB: Complete the checklist in appendix A “Checklist for planning”.




Attention: the exerted ground pressure may never exceed the bearing capacity of the subsoil.

4.1.3 Requirements for foundation material

The foundation material has to meet the following requirements:



Parameter		Requirement
Timbers	Timber length	> T_{min} < 612mm
	Timber width	> Timber height
	Timber gap	< Timber width < 300 mm
	mechanical compressive strength	> 8 N/mm ² without occurrence of deflection  NB: Enerpac strongly recommends adhering to 13N/mm ² , preferably Azobé wood
Steel plates	Steel length	> S_{min}
	Steel width	= Timber width
	Steel thickness	> 10 mm (Preferred)
	mechanical compressive strength	> 30 N/mm ² without occurrence of deflection
	Mounting	properly secured
Steel shims (see below)	mechanical compressive strength	> 30 N/mm ² without occurrence of deflection

Steel shims can be used to level the skid track, and to fill openings between the floor and the skid track. These openings may occur due to thickness tolerances in the timber and the track, and due to the imperfect flatness of the floor.



NB: The entire contact surface between the skid track and the floor, or the skid track and the timbers must be filled.



NB: Wood is a natural product: its quality is not assured. In order to guarantee quality, test the timbers on 125% of the expected load. For your planning keep in mind that suitable wood may not always be available immediately.



Attention: use of other wood types such as plywood, multiply, pine and compressed wood is explicitly prohibited.

4.2 Check the lifting capacity of the system

This chapter describes how to determine the lifting capacity of the system. The lifting height influences the lifting capacity.

Caution: though all limits for the capacity, lifting height, skew and environmental influences are either calculated or tested by the Enerpac consciously, during lifting operations these parameters may interfere with each other in a negative way. Test situations differ from real life situations!

4.2.1 Maximum load

The lift capacity of the system depends on the degree of extension of the Cylinders: the more extension, the less lift capacity. Observe the lifting capacities as shown in section 3.3.2 "Functional specifications".



Stage 1	Stage 2	Stage 3
<i>SBL500</i>	<i>SBL500</i>	<i>SBL500</i>
<i>SBL900,</i>	<i>SBL900,</i>	
<i>SBL1100</i>	<i>SBL1100</i>	<i>SBL1100</i>

Complete the checklist in Appendix A "Checklist for planning" under "Stage of Extension".

4.2.1.1 The maximum load per unit.



The lift capacity per stage and per unit is given in the table of section 3.3.2 "Functional specifications".



NB: The capacity of a system is four times the maximum load on one Unit.

4.2.1.2 Use of load charts

When the centre of gravity is not in the centre of the system, the capacity of the system will decrease. The figures below give the principle of it. The numbers are fictitious.

Assume <ul style="list-style-type: none"> • a load of 1000 kN • a lifting capacity per unit of 250 kN • stage 2 used 	
The centre of gravity of the load is in central position.	The centre of gravity of the load is in eccentric.
	
(The coloured bullets match with the load chart)	
The load is spread equally over the units: All Units bear $1000 / 4 = 250$ kN	The load is spread unequally over the units. The load on the rear-right unit has increased significantly and exceeds 250 kN
The system is loaded to its limits, but none of the units is overloaded.	The rear-right unit is overloaded! The system cannot lift the 1000 kN anymore but less, to avoid overload in that unit. <i>The capacity of the system has decreased due to eccentricity of the load.</i>




NB: The more eccentric the centre of gravity, the less the lift capacity of the system.

The capacity charts referred to in Appendix Z “Compatible accessories” show the lift capacity of the system in relation to the position of the load.

Use the capacity chart as follows for your side shift operations:

- Locate the position of the centre of gravity in the capacity chart, as shown at the right.
- The data on that spot shows the total capacity (4 units) of the system.



4.2.2 Minimum load

When the load is only little, the motion of the first and the second section may not be exactly smooth, due to friction of the hydraulic cylinders.

To ensure a smooth motion, the units have to bear a minimum load of 50 kN. In most cases, the weight of the header beams is sufficient.

Enter the minimum load in the checklist in appendix A “Checklist for planning”. Do such for the unit which is bearing the lightest load only.

4.3 Side Shift units, Lugs and Sling guides

4.3.1 Side shift units

When you want to move the load in transverse direction then apply the side shift units.

- Verify their lift capacity. It is given in Appendix Z “Compatibility of system parts”.
- Enter the load in the checklist given in Appendix A “Checklist for planning”.



NB: Always determine the force on the side shift unit, even for relatively light loads. In case of any doubt, consult Enerpac.



Attention: the force on the side shift units shall never exceed their lift capacity.

4.3.2 Lugs

If there is no need to move the load in transverse direction then simple lifting lugs can be applied, rather than the more complicated side shift units.

- Choose single- or double plated lifting lugs, depending on the mass of the load.
- Check the capacity of the lugs. Use the information in Appendix Z “Compatibility of system parts”.
- Enter the load in the checklist given in Appendix A “Checklist for planning”.



4.3.3 Sling guides

If you want to suspend a load directly to the header beams by using slings, then apply sling guides.



Warning: Never suspend a load to the header beam using slings without applying sling guides.

4.4 The bearing capacity of the header beams

The bearing capacity of the main header beams depends on position of the load: the closer to the centre, the less the capacity of the header beam.


The capacities of the header beams in relation to the position of the load are given in the load charts in Ref 5 "Technical handbook".

The bearing capacity of the beam is twice the indicated capacity if

- only one anchor point is used and
- the anchor point is in the centre of the beam.

This is depicted below:

Example how to determine the bearing capacity of the header beam for two anchor points. Loads within the green area are allowed.




The distance between the anchor points is (1250 + 1250) mm, so the maximum allowable load is 520 kN per anchor point.

The bearing capacity of the beam is twice the indicated capacity if

- only one anchor point is used and
- the anchor point is in the centre of the beam.

This is depicted below:

Example how to determine the bearing capacity of the header beam for one anchor point. Loads within the green area are allowed.



In this example the total allowed load is $2 \times 300 = 600$.

Enter the beam load in the checklist given in Appendix A “Checklist for planning”.

Caution: The force on each anchor point shall not increase the capacity of the header beam.

NB:

- Earlier purchased Enerpac / Hydrosplex Header Beams may be applied if their capacity is sufficient.
- Header beams of foreign make can be applied if their capacity is sufficient, but Enerpac will not take any responsibility for it.

4.5 Side load

Side load may endanger the stability of the System.

Side load can be caused by

- Wind:
- Size of the object
- Windspeed
- Height of the header beams
- Lifting height
- Bearing ground not levelled out
- System not installed plumb
- Inclination of the skid tracks
- Slings or shackles which are not mounted plumb between the side shift units (or lugs) and the load.

To calculate the permissible wind speed, reference is made to ref 4 “Wind calculations”.




Attention: the side load shall not exceed 1.5% of the actual load.

Enter the maximum expected side-load in Appendix A “Checklist for planning”.



Attention: Calculation of the side load is the **exclusive responsibility** of you as the user of the system.



NB: Always assume the most adverse situation.

Enter the maximum permissible wind speed in Appendix A “Checklist for planning”.



Hazard:

- Under no circumstances whatsoever may lifting operations be carried out when the wind speed exceeds the permissible values.
- When lifting, always assume a worst-case scenario. Wind is unpredictable and may quickly change speed and direction.

5 Install the System

This chapter describes how to install the System as well as the preparations which have to be made for the working location.

Fully complete the checklist as given in Appendix A “Checklist for planning”.

**NB:**

Verify the lifting capacity of your lifting means with reference to the weight of the parts to be hoisted. The weights are given in Ref 5 “Technical handbook”.

For torque settings reference is made to Appendix H “Torque settings”.


5.1 Hoisting Instructions


5.1.1 Transporting a unit in vertical position

Pre-conditions for moving a unit:

- no header beams mounted
- no load attached
- no electrics connected
- In case of the SBL1100: the boom is in horizontal position.

Lifting eyes and fork holes are indicated below.






Transporting a unit in vertical position can be performed by

- Using a forklift truck.
Use the fork holes of the unit.



- Attention:** In order to prevent damage to the wheels of the units:
- keep the bottom of the unit at a height of at least 300 mm
 - the unit should not lean back



- Using a crane
Use the lifting eyes of the unit.
Attention: always use four lifting eyes









5.1.2 Transporting a unit in horizontal position (not for SBL1100)







Due to the available room transporting in horizontal position may be required.


Proceed as follows.



- Attention:** Never uncouple hydraulic hoses or telescopic tubes.

<p>1.</p>	<p>Loosen and remove the four bolts of the wheel cover plate. Then remove the cover plate.</p> <p> Attention: once the screws are loose, the cover can fall out</p>	
<p>2.</p>	<p>Remove the eight head bolts which are positioned circular in the top ring.</p>	
<p>3.</p>	<p>Hoist the swivel and the top ring from the telescopic tubes.</p> <p> Attention: Make sure the swivel cannot fall</p>	
<p>4.</p>	<p>Put the lifting yoke at the position where the swivel was positioned.</p>	


	<p>Make sure the side hole is positioned right above the electric box.</p>	
<p>5.</p>	<p>Attach the lock plate to the long edges of the lowest tube. Ensure that the hole in the lock plate is positioned in line with the side hole of the lifting yoke.</p> <p>The lock plate is attached with rods:</p> <ul style="list-style-type: none"> • M20 • Threaded • Length of 100 mm • The length of the threaded rod equals 100mm. <p>Put washers between the nuts and steel plates.</p>	
<p>6.</p>	<p>Connect the lifting yoke to the lock plate by means of a the applied M20 threaded rod / 400mm.</p> <p>Put washers between the nuts and steel plates.</p>	
<p>7.</p>	<p>Remove the air vent bolt out of the hole Put the supplied vent plug in the hole.</p> <p> Attention: Make sure no oil can flow out</p>	<p>air vent </p>
<p>8.</p>	<p>Check the oil cap. Be sure the oil cap is closed and no oil can leak out of the tank.</p>	<p>oil cap </p>
<p>9.</p>	<p>Lift the unit using the indicated lifting eyes a indicated.</p>	



5.1.3 Hoisting skid tracks


The skid tracks can be hoisted:

- by a forklift truck.
Use the fork holes
- by a crane.
Use the two lifting eyes.



5.1.4 Hoisting header beams


Header beams are provided with lifting eyes, and sometimes with fork holes.




5.1.5 Hoisting a side shift unit

To hoist the SSU130 and the SSU300 side shift unit, observe the following.

5.1.5.1 SSU300



1.	Put the transportation frame next to the gantry. Preferable apply a forklift . Eventually you can use a crane and use the lifting eyes.
2.	At delivery, the side shift units are strapped to the strap-down eyes. Remove those straps.
3.	<p data-bbox="244 1216 667 1310">Make sure the locking pins are in place on both sides of the side shift unit.</p> <div data-bbox="699 1216 1391 1892" style="text-align: center;"> </div>
4.	Hoist the side shift unit out of the transportation frame

<p>5. Store the locking pin in one of the pipes</p>	
<p>6. Hoist the side shift unit out of the transportation frame. Use all lifting eyes.</p>	

For storing the side shift units in the transportation units, proceed in reverse order.




Attention:


- The height of the transportation frame is adjustable. Make sure the height is set in such a way that the side shift units cannot touch the ground.
- Strap the side shift units to the strap-down eyes.


5.1.5.2 SSU600

The side shift units shall only be hoisted using the lifting eyes. The locking pins must be used, otherwise the driven and undriven unit collapse with each other.





When not in use then put the side shift units into the transportation frames or put them down horizontally on timbers.






To take the side shift unit out of the transportation frame proceed as follows:

1.	Put the transportation frame next to the gantry. Preferable apply a forklift . Eventually you can use a crane and use the lifting eyes.	
2.	At delivery, the side shift units are strapped to the strap-down eyes. Remove those straps.	
3.	Make sure the locking pins of the side shift unit are in place on both sides of the side shift unit.	
4.	Remove the locking pins of the frame, on both sides.	
5.	Store the locking pin in one of the pipes	
6.	Hoist the side shift unit out of the transportation frame. Use all lifting eyes.	
7.	After positioning the side shift unit, remove the locking pins of the side shift unit on both sides.	

5.1.6 Hoisting sling guides

Use slings to hoist sling guides. The lifting eyes and lifting holes are indicated below.



5.2 Place the skid tracks

Correct positioning of the skid tracks ensures that the system is put level on the ground. When the ground is not flat then grade it in advance, to create a solid foundation on which the system can operate safely.



Attention: creating a proper foundation has to be performed with utmost care, as it is the system's primary safety issue. The foundation of the Skid tracks is the exclusive responsibility of the user.


5.2.1 Build the foundation

For building the foundation, proceed as follows:


Install the foundation material as you determined; see section 4.1 "Bearing ground pressure calculation".

Observe the following:


- If the diameter of the timbers is not square, then put them in flat position.



- If you stack timbers then leave no slack in between, to avoid risk of spring.



- Put the timbers horizontally, not vertically.




5.2.2 Put the skid tracks in place


For putting the skid tracks in place, proceed as follows:

Put the skid tracks on the foundation and mount them together.
Observe the following:


- Put steel plates between the timbers and the skid tracks




- Make sure no slack is left between the foundation and the skid tracks. Eventually use shims.



- Support the locations where the skid tracks are attached to each other.





- The gap between the timbers shall be smaller than the width of the timbers.








5.2.3 Align the skid tracks

Align the Skid tracks according to the following requirements:





Nr	Alignment requirement	Tolerance
1	The skid tracks shall be in parallel	12 mm
	 <p>(top view)</p>	

	The skid tracks shall be aligned from the start to the end	12 mm
--	--	-------




5.3 Put the units upon the skid tracks

To put the units upon the skid tracks proceed as follows:

<p>1. Make sure the travelling distance sensor is in transport position.</p>	
<p>2. Put the units on the skid tracks</p> <ul style="list-style-type: none"> • Observe the hoisting instructions as given in section 5.1.1 “Transporting a unit”. • In order to avoid the necessity of being underneath the load in case of electrical problems, position the units in such a way that the power plugs and the local control panels are accessible from the outside. • The grooves in the roller tracks match with the ridges on the skid tracks. 	
<p>3. Put the travelling distance sensor in operational position; see step 1.</p>	


5.4 Connect the power cables

Connect the power cables to units. Use the sockets on the electrical cabinet. The male-type power socket is for power input, the female type for power output.




There are two options for connecting the units. Pick one, according to your own demands.

- Connect each unit individually to the main power.



- Connect the units two-by-two to the main power. This might save cable length, depending on the relative positions of the units.



Caution: Interconnecting more than two units may damage the system.



NB: The system is provided with automatic phase detection. This assures the correct rotation direction of the electro motors.

5.5 Put the boom in upright position (SBL900 and SBL1100 only)

For putting the boom in upright position, the system is operated in local control. So, use is made of the buttons on the control panel; see section 6.2 "The control panel of the unit". The unit has to be connected to electric power.








Attention:

Never put the boom in upright position or lower it

- when something is attached to it since the tilting cylinders are not designed to bear additional weight.
- while the boom is being extended, since the unit might tumble due to the different centre of gravity



Proceed as follows:

<p>1. Remove the three shafts from the frame:</p> <ul style="list-style-type: none"> • Remove the spring clips from the three shafts. <ul style="list-style-type: none"> • Pull the three indicated shafts out until the red indicators are visible. <p> NB: Leave the fourth shaft (not provided with a clip) in place; it serves as the axe for the rotation of the boom.</p>	   <p style="text-align: right;">indicator</p>
<p>2.</p> <p> Attention:</p> <p>Check:</p> <ul style="list-style-type: none"> • nobody is close to the unit • no cables can be pinched • nothing is attached to the boom 	

3. Use the buttons on the control panel to raise the boom; see section 6.2 “The control panel of the unit”.

The tilting cylinders extend.


The boom gets in upright position.




4. Put the shafts back into position. Play with the buttons on the control panel for finepositioning the boom, to enable restoring of the shafts. Then lock them with the spring clips.



Hazard:
A missing shaft may result in an unstable unit foot and thus also an unstable system






<p>5.</p>	<p>Decompress the tilting cylinders by retracting them slightly, using the buttons on the control panel. Keep an eye on the pressure gauge; there should not be pressure built up.</p>	
-----------	--	---


5.6 Mount the header beams

5.6.1 Assemble the modular beam



Modular beams are optional.

When you apply the modular header beam then assemble it as follows:

<p>1.</p>	<p>Put two sections male / female together and align the holes</p>	
<p>2.</p>	<p>Mount the connection shaft.</p>	
<p>3.</p>	<p>Mount the flanges of the connection shaft.</p>	





4. Tighten the bolts according to the table in Appendix H "Torque settings".	
--	--



5.6.2 Mount the lifting lugs

1. Lift the header beam on top of two supports.	
2. Put the lifting lugs over the header beam symmetrically.	

5.6.3 Mount the header beam on top of the cylinders

To mount the Header Beams on top of the Units proceed as follows:

<p>1. Remove the six bolts at the top of the swivel plate</p>	
<p>2. Remove the locking strips.</p>	
<p>3. Make sure the swivels of two units are at equal height with a tolerance of 5 mm.</p>	
<p>4. Put the header beam on top of both swivels.</p>	
<p>5. Clamp the header beam to the swivel using the distance strips and the locking strips.</p> <p>Note that two types of beams can be mounted:</p> <ul style="list-style-type: none"> • Wide (480 mm) • Narrow (300 mm) 	
<p>6. Set the locking strips of the swivel according to the applied type.</p> <p>Eventually use shim plates to compensate for plate thickness of the beam.</p>	 <p style="text-align: center;">Wide Narrow</p>

7.	Level the beam. Use the buttons of the local control cabinet; see section 6.2 “The control panel of the unit”.	
8.	Tighten the bolts <u>hand tight</u> .  NB: <ul style="list-style-type: none"> • Make sure that all bolts are tightened properly. • Always apply all bolts. 	

5.6.4 Mount longitudinal beams



When you apply longitudinal beams (see section 3.4.1 “Header beam configurations”), make sure that those longitudinal beams are securely fastened to the header beams. Enerpac provides a solution for mounting the longitudinal beams. Contact Enerpac if you are going to use longitudinal beams.

5.7 Mount the side shifts on top of the header beams

To mount the side shift units, perform the following steps:



- Mount the cable guiding wheel.
- Mount the side shift.
- Connect the cable.

5.7.1 Mount the cable guiding reel.


1.	<p>Mount the cable-guiding wheel at the header beam at the side where the cable reel is mounted.</p> <p> Caution: When mounting on the rear side, the cable may get pinched.</p>	 <p>The diagram illustrates the assembly process. A yellow Enerpac side shift unit is mounted on a black header beam. A cable guide is being attached to the side of the beam. A red circle highlights the cable guide, and another red circle highlights the cable reel on the base unit. Labels 'Cable guide' and 'Cable reel' are present with arrows pointing to the respective components.</p>
2.	Mount the cable reel (option).	




5.7.2 Mount the rotation anchor





If you apply the rotation anchor, then proceed as follows:




<p>1. Use the locking pins and the safety clips to attach the rotation anchor to the side shift unit.</p>	 <p>Locking pin and safety clip</p>
<p>2. Use the lifting hole to suspend the load to the rotation anchor.</p>	 <p>Lifting hole</p>
<p>3. Install a drop zone. The drop zone had to be cordoned off with barriers, tapes etc. in such a way that no-one can enter the area. Also, the operators shall not enter the drop zone during the operation.</p>	



5.7.3 Mount the SSU150 and SSU300

<p>1. Hoist the side shift unit out of the transportation frame.</p>	<p>See section 5.1.5 "Hoisting a side shift unit"</p>	
<p>2. If you apply the SSU300 together with the narrow header beam then mount alignment strips.</p>	 <p>Alignment strips</p>	



<p>3.</p>	<p>Put the side shift over the header beam.</p> <p>NB: Preferably put the side shift units with their chain-boxes at the same side of the header beam. This makes setting of the running direction of the side shift units more logical.</p>	
<p>4.</p>	<p>Place the anchor block</p>	
<p>5.</p>	<p>Lock the anchor with the locking strips or locking pins.</p>	





6.	Remove the locking pins on both sides	
7.	If you're going to apply a rotation anchor, then mount the rotation anchor	
8.	If you're going to apply slings then mount the sling anchor.	
9.	<p>If you're going to apply a top swivel kit then mount the kit.</p> <p>The top swivel kit can be mounted directly on top of the side shift unit</p>	

<p>10. Remove pins before use. Otherwise the system cannot hinge around the anchor plate pins.</p> <p> Attention: ensure that the cable is mounted in such a way that it cannot get pinched.</p>	
<p>11. Hoist the side shift unit out of the transportation frame.</p>	<p>See section 5.1.5 "Hoisting a side shift unit"</p>
<p>12. Put the side shift over the header beam.</p>	




<p>13. Place the anchor bloc.</p>	
<p>14. Lock the anchor with the locking strips or locking pins.</p>	



5.7.4 Mount the SSU600

<p>1. If you want to apply the top swivel:</p> <ol style="list-style-type: none"> 1. Unscrew the top plates from the side shift unit and remove the top plates. 2. Put the top swivel on top of the unit and fix the bolts. Use the lifting lugs of the top swivel to hoist. 3. Set the locking strips of the swivel according to the applied type header beam. 	 <p>The diagram illustrates the assembly process for the top swivel. At the top, two yellow plates are shown with blue arrows pointing upwards, indicating they are to be removed. Below them is the main yellow side shift unit with 'ENERPAC 750kN' printed on it. In the middle, a top swivel assembly is shown being placed onto the unit. At the bottom, two locking strips are shown, labeled 'Wide' and 'Narrow', which are used to secure the swivel to the header beam.</p>
<p>2. Hoist the side shift unit out of the transportation frame.</p>	<p>See section 5.1.5 "Hoisting a side shift unit"</p>
<p>3. If you apply the narrow header beam then mount alignment strips.</p>	 <p>The diagram shows a close-up of the side shift unit's internal rollers and header beam. Two red arrows point to the 'Alignment strips' which are being mounted to the narrow header beam to ensure proper alignment of the rollers.</p>




<p>4. Put the side shift on the header beam.</p> <p>NB: Preferably put the side shift units with their chain-boxes at the same side of the header beam. This makes setting of the running direction of the side shift units more logical.</p>	
<p>5. Place the anchor block</p>	
<p>6. Lock the anchor with the locking pins</p>	
<p>7. If you're going to apply slings, then mount the sling tool. Lock with the pin.</p>	

5.7.5 Connect the cable of the side shift unit

<p>1. Connect the cable on the cable reel with the side shift.</p>	
<p>2. Connect the cable on the cable reel with the side shift.</p> <p>Connect the strain relief of the cable to the connection eye</p> <p> Attention: ensure that the cable is mounted in such a way that it cannot get pinched.</p>	 <p>Connection eye</p> <p>ENERPAC 750 kN</p> <p>Cable plug</p>



<p>3. Feed the cable it through the guiding guide.</p> <p>Use the provided strain relief.</p> <div data-bbox="244 353 347 443" style="display: inline-block; vertical-align: middle;">  </div> <p>Attention: ensure that the cable is mounted in such a way that it cannot get pinched.</p>	
---	--

5.7.6 Set the moving direction

<p>1. Set the moving direction in such a way that side shift units will move in the same direction.</p> <p>Use the control panel; see section 6.2 “The control panel of the unit”.</p> <div data-bbox="244 1328 347 1417" style="display: inline-block; vertical-align: middle;">  </div> <p>Attention: The side shift units are not provided with automatic phase detection. Therefore, always check the running direction after installing.</p>	
<p>2. Once the power has been switched on, use the remote-control console to test whether the side shifts move in equal direction. See section 6.3 “The remote-control console”.</p> <div data-bbox="244 1574 347 1664" style="display: inline-block; vertical-align: middle;">  </div> <p>Attention: wrong setting of the moving direction may cause dangerous situations during lifting.</p>	



5.8 Install the rotation anchor

If you apply the rotation anchor, then proceed as follows:

1.	Use the locking pins and the safety clips to attach the rotation anchor to the side shift unit.	 <p>Locking pin and safety clip</p>
2.	Use the lifting hole to suspend the load to the rotation anchor.	 <p>Lifting hole</p>
3.	Install a drop zone. The drop zone had to be cordoned off with barriers, tapes etc. in such a way that no-one can enter the area. Also, the operators shall not enter the drop zone during the operation.	







Attention: Make sure the centre of gravity of the load is perpendicular underneath the lifting hole of the rotation anchor, in order to prevent swinging of the load while it comes free from the ground.



5.9 Install the sling guides

To install the sling guides, proceed as follows.

Hazard: fingers and hands can be crushed between sling guide and header beam.

<p>1. Remove the cleats and shimming plates from the sling guide.</p>	
<p>2. Position the sling guide on top of the header beam.</p>	
<p>3. Lock the sling guide to the header beam with bolts. Use shimming plates according to the thickness of the flange of the header beam.</p> <p> Caution: If the sling guides are not well locked to the header beam, they may move, causing misalignment of the load.</p>	 <p>Shimming plates</p> <p>Cleat</p>

5.10 Install the remote-control console

The remote-control console can communicate with the units:

- Wireless, using radio connection.
No cables have to be used on the working area, but the radio communication can be disturbed.
- Wired, using data cables.
Preferable when the radio link is disturbed.
- Hybrid communication: some units are controlled by wire, other units wireless.

5.10.1 Wireless communication

The communication operates on a radio frequency of 2.4 GHz.


If connection may be disturbed by radio reflections or 'dead' areas. Walking to another position may help.

If the connection fails:


- A report is given on the LCD of the remote-control: "**** Communication-time-out ****"
- If the communication fails for 2 seconds, then all movements of the units and the side shifts are stopped.
- If the communication fails for 10 seconds, then the Emergency stop is activated.
For recovering from this situation reference is made to section 6.1. "The Emergency buttons".




5.10.2 Wired communication

To enable wired communication between the remote-control console and the four units, set up the following configuration:




Proceed as follows.

1.	Make sure the remote-control console is switched off	
2.	Make sure the power of all units is switched off	
3.	Connect the data cable to the RS-485 socket of the remote-control console.	

4.	Connect the data cable to one of the units. Each units are provided with two RS485 sockets. Use one of them; the sockets are functionally identical.	 
5.	Connect another data cable to the other socket of the unit and connect it to the next unit.	
6.	Carry on connecting until all units are connected. The sequence in which you interconnect the units does not matter since the units will identify themselves automatically.	
7.	Provide the unused socket of the last connected unit with the dongle.	

5.10.3 Mixed wireless and wired communication

Some units are controlled by wire, while other unit(s) are controlled wireless. An example of a possible configuration is shown below.



Follow the procedures as given in section 5.10.1 “Wireless communication” and section 5.10.2 “Wired communication”.






NB: During operation you can change a unit from wireless to wired communication and vice versa, just by connecting and disconnecting the cable. The system will automatically set up the connection. Don't forget to mount the dongle for wired connection.




5.10.4 Set up the communication for wireless and for wired connection

To set up the communication between the remote-control console and the four units to work, proceed as follows.

Reference is made to

- the controls on the remote-control console.
The layout of the remote-control console is given in section 6.3 “The remote-control console”.
- the controls and indicators of the units.
The layout of the control panel of the unit”.

1.	Connect data cables or do not so. The system will automatically detect their presence.	
2.	Ensure that the “Emergency stop” button on the remote-control console is in the non-activated position.	
3.	Make sure that the “Emergency stop” buttons on all units’ are in the non-activated position.	
4.	Switch the main power switches on the control panels of all units to “on”. <i>The “power on” indicator on the control panel of the Units will be lit.</i>	
5.	Make sure the unit is set to Remote.	

<p>6. Verify that the blue indicator is off.</p> <p>It is set to off as soon as the communication with the unit is established.</p>	
<p>7. Select the Units you want to operate with. The remote-control console can now detect the units. <i>If the connection with a unit is fine than the "emergency active" indicator on the control panel of that unit is dimmed.</i></p>	
<p>8. Set the same switches to off again</p>	
<p>9. Switch the remote-control console off and then to on.</p> <p><i>As soon as the communication is established:</i></p> <ul style="list-style-type: none"> • the text "Engine still" is displayed • an 'infinite' symbol is displayed in case of wired communication <p><i>If the remote-control console detects data cables then the wireless means are switched to off.</i></p> <p><i>Now it is possible to control the units.</i></p>	

5.10.5 Pairing of the remote control console with the units


Only when the remote-control console or one of the units was replaced, reprogramming is required.







Each remote-control console is provided with a unique code. This code is known by the receivers of the units, so they can recognize their Master's Voice.



NB: Enerpac has set this communication configuration initially. The setting is persistent and remains after switching off the power.

The pairing procedure has to be performed for each unit individually.
Proceed as follows:

<p>1. Make sure the battery of the remote-control console is charged</p>	
<p>2. Switch the units off.</p>	

3.	Deselect all units.	
4.	Switch the unit which has to be programmed on.	
5.	Select the concerned unit	
6.	Open the electro cabinet of the unit. Look for the receiver.	
7.	Press "LEARN" for two seconds <i>When the text "NO ANSWER" disappears from the display of the remote-control console, the remote-control console and the unit are connected.</i>	
8.	Eventually repeat [2] .. [8] for the other units	
9.	Verify that the number on the remote-control console match with the numbers on the units, by travelling with the units individually.	

5.10.6 Perform an all-over visual inspection of the System

Inspect the system visually.
Enter the result of the inspection in the checklist given in Appendix B "Checklist for installing the System".


6 How to control the System

6.1 The emergency buttons

The system is provided with emergency buttons. Press an emergency button when you want to stop all movements of the system immediately.

Available emergency buttons:

- on the control panels of all four units.



When the emergency button is pressed:

- The unit is switched off.
- The blue indicator “Emergency active” is on.
- If the unit is in remote-control, then other units in remote control are switched off as well.

To recover the system from an Emergency situation:

- Investigate why the button was pressed.
- Turn and pull the emergency button.

- The remote-control device is provided with an emergency button.



When the button is pressed, all units which are in remote-control are switched off and all movements stop.

To recover the system from an Emergency situation:

- investigate why the button was pressed
- switch off the main power of all units for at least 20 seconds
- restart the system

6.2 The control panel of the unit

The control panel of each unit is provided with controls and indicators. Using the controls, the unit can be operated. Other units cannot be controlled. This mode is called 'local control'.

Local control is meant to be used during the setting-to-work phase of the system.

You use local control:

- To manoeuvre the units into position. Use the control panel on the unit.
- To manoeuvre the side shifts into position. Use the control panel on the unit to move the side shifts.
- To synchronise the moving directions of the units. Use the control panel on the unit.
- To synchronise the moving directions of the side shifts. Use the control panel on the unit.




Attention: Do never use the travel, lifting and lowering function in local control when the **header beams are mounted**, since:

- the units are not controlled simultaneously.
- no automatic levelling is performed.
- no load detection is performed.



Hazard: Usage of local control when there is load on the system may cause instability of the system.



*) ad 2:
Applicable for SBL500 and SBL1100 only.

*) ad 11:
The button is only effective when the unit is in local control.
When a load is detected or when the cylinders are extended in more than one stage, the speed is set to low automatically.

6.3 The remote-control console

The remote-control console enables the operator

- to execute a lifting operation on a safe distance
 - to control all units simultaneously
- This mode is called "Remote-control".


Applying the remote-control console ensures that

- the moving speeds of the units is synchronized
- the heights of the booms are kept equal within a tolerance of 24 mm.



NB: System start up is faster when the remote-control console is switched on before the units are switched on.

6.3.1 The controls



*) ad 6: The system will only move fast if the load on all units <10% of max load, and no cylinders are extended in stage 2. Otherwise the system automatically operates in 'Slow' mode.

*) ad 9: **Caution:** Side shift is a separate system. Side shifting is not stopped when overload in one of the units occurs.




6.3.2 The display

A. Height of the cylinders with reference to the unit.

B. Load on the complete system

C. Direction of the arrow:
 ↑↓ : Lifting, lowering
 →← : Travelling direction
 ↙↘ : Side shift








D. Height of the cylinders with reference to the "zero lift" point.

E. The load per unit

F. Power status of the battery

The following information is visible on the screen:

Tot.	The total load on the selected units.
Position	The height of the selected cylinders with reference to the unit itself.
Lift	The height of the selected cylinders with reference to the point where the "zero lift" button was pressed. When wired communication with the Units is OK, a "∞" symbol is shown behind the Lift value.
	
Load per unit	The load of the selected cylinders,  NB: The load is a calculated value, based on the height. So, changes in the indicated position may cause a jump in the load indication. The values indicated for the non-selected cylinders are invalid
Warnings and errors	Warnings and errors are shown in the top line.
	
	A list of possible errors and warnings is given in section 8.2 "List of problems and solutions".

Emergency pressed	 <p>The report "****Emergency pressed****" is shown:</p> <ul style="list-style-type: none"> • When the emergency button on the remote-control console was pressed • When the emergency button on a unit was pressed, but only when that unit was on Remote-control. See section 6.1 "The emergency buttons". • When the communication with one of the units was interrupted for more than 10 seconds.
Power status of the battery	<p>The display shows the power level of the battery. The console can operate approximately 8 hours on a fully charged battery. Switch the console off after use and connect it with the 12V loader.</p> <p> NB: Only apply the delivered loader.</p>

6.4 The mechanical locking system

If there is a delay of hours during a lifting operation, unintended lowering due to minimal flow-back of oil out of the lifting cylinders might happen. The mechanical locking system provides additional safety by preventing unintended lowering.

The mechanical locking system is available for SBL500, SBL900 and SBL1100.


The system makes use of wedges, which are mounted on each stage of the boom. The wedges are mounted manually. To mount the mechanical locking system, the load has to be at height already.



Attention: The mechanical locking system is not suitable to be applied during full load of the system. For the maximum bearing capacity see section 3.3.2 "Functional specifications".

For mounting and dismounting the wedges, the sequence of extension of the sections matters.

- When lifting, by nature the top stage extends first. Only when the top stage is fully extended, the middle stage follows, and then the lower stage.






- When lowering the system, the sequence is reverse: the lower stage retracts first.


The principle of mounting and unmounting is as follows.

- To mount the wedges, put the wedges at the lower stage first. Then slightly lower the system. The wedges will lock. Then carry on with the middle stage, and then with the top stage.
- To unmount the wedges, slightly extend the system. The top stage extends and its wedges are released. Remove them. Extend the system again and remove the wedges from the middle stage. Then do the same for the lower section.

Proceed as follows:

1.	<p>Lower the gantry for 100 mm. <i>The top sections lower.</i></p> <p> NB: <i>The 100 mm space is used to enable releasing the wedges afterwards.</i></p> <p> Caution: <i>If there is not enough space is left for extension, the wedges cannot be released anymore.</i></p>	
2.	<p>Insert the wedges at the lower sections.</p> <p>You may make use of the ladder.</p>	
3.	<p>Lower the gantry a bit. <i>The lower sections retract.</i> <i>The force on the cylinder of the lower sections is transferred towards the wedges.</i></p>	
4.	<p>Lower the gantry for another 100 mm.</p>	
5.	<p>Insert the wedges at the middle sections.</p>	
6.	<p>Lower the gantry again for another 100 mm. <i>The middle sections retract.</i> <i>The force on the cylinder of the middle section is transferred towards the wedges.</i></p>	
7.	<p>Lower the gantry for another 100 mm</p>	
8.	<p>Insert the wedges at the top sections.</p>	
9.	<p>Lower the gantry again for another 100 mm. <i>The top section retracts.</i> <i>The force on the cylinder of the top section is transferred towards the wedges.</i></p>	
10.	<p>It is now safe to switch off the system.</p>	

To unmount the wedges, proceed as follows:

1.	<p>Start the system</p>	
2.	<p>Raise the gantry for 100 mm. <i>The top sections extend first. The wedges unlock and can be removed.</i></p>	
3.		
4.	<p>Raise the gantry for another 100 mm. <i>The middle sections extend. The wedges unlock and can be removed.</i></p>	
5.	<p>Remove the wedges from the middle sections</p>	
6.	<p>Raise the gantry again for another 100 mm. <i>The lower sections extend. Their wedges are unlocked and can be removed.</i></p>	
7.	<p>Remove the wedges from the lower sections.</p>	

6.5 Rotate the load using the rotation anchor




Attention: Rotating the load is a potentially dangerous operation, due to the fact that the load is suspended to one single point.




Hazard: Not following the rules given in this section may cause damage to the lifting system and to the load.

Observe the following rules:


- Always rotate load slowly.
- Use guide wires for rotating.
- The guide wires shall be used all the time while the load is lifted, in order to keep the load in correct position.
- Apply symmetrical forces to the load by the guiding wires:





- Always pull in the horizontal plane





- Have guide wires in place to stop the load from moving. Those guide wires have to be symmetrically attached to the load as well. The guide wires have to be manned during the operation.




- Preferably put the load in low position while it is rotated.



- Make sure the centre of gravity of the load is perpendicular underneath the lifting hole of the rotation anchor, in order to prevent swinging of the load while it comes free from the ground.



- Be aware that wind may rotate the load if the centre of gravity of the load is not at the same position as its geometrical centre.



6.6 Limiting devices

- When the system is in remote-control, it will stop moving when the difference of height of the cylinders exceeds 24 mm.
- When the system is in remote-control, it will stop moving when the difference of travelled distance of the units exceeds 24 mm.
- In local control the cylinder can only be extended if there is no load on the system.

7 Execute a lifting operation

This section describes how to perform a lifting operation.

Precondition is, that the system has been set to work completely, and that you are familiar with the operation if the system.



NB: Operation of the system is only allowed for personnel certified by Enerpac as authorised operator.

7.1 Main directions

7.1.1 Risks and Warnings

Proper handling of the System is essential for safety.

Observe the System while operating.

Make sure the working area is fenced off.

Address the following subjects:



Hazard

- **Improper use** of the machine may result in accidents causing damage not only to the machine itself, but also to objects and goods in its vicinity or mounted to the machine, as well as injuries to people in the immediate area, and possibly even death.
- Failure to adhere to the **checklists** may result in serious injury to the user, possibly even death.
- Even if all safety measures are taken and the system is operated correctly, there will remain a **residual risk** of falling of the system.



Caution

- Failure to **prepare correctly** for a lifting operation may result in total loss of machine stability during use.
- When lifting, always assume a **worst-case scenario**. The wind can be unpredictable, quickly changing speed and direction. Do not take any chances: if the wind is strong, that means it's a 'no go'!
- Never attempt to extend or retract masts to which something is attached or which are fitted with a buffer beam. The extension cylinders are not designed to bear additional weight.
- Do not operate the system when a **person is close** to it.



Attention

- It is of the utmost importance to **read this manual** carefully before setting up the machine. Failure to prepare correctly for a lifting operation may result in total loss of machine stability during use.
- Adhere to the **checklists** during all work activities: during preparation for the lifting operation, system construction, and for lifting the load.
- Local control is only permitted if there is a beam attached to the unit.
- A unit is only part of the central emergency stop system if the control selector switch is in the remote position.
- Ensure that the load avoids contact with a boom or any obstructions while lifting, side shifting, or traveling.
- Ensure that the booms, header beams, and other components of the gantry system avoid contact with any obstructions while traveling.
- Ensure that the load avoids contact with any obstructions while lifting.
- The operator should have an unobstructed view of the system and load during operation of the system. If this is not possible, a signalperson shall be used with an effective means of communication to provide directions to the operator.
- Communication among personnel involved in the operation shall be maintained continuously during all movement of the load. If at any time communication is disrupted, the operator shall stop all movements until communication is restored.
- Signals to the operator should be in accordance with the standards prescribed in section 1.9 "Hand signals". If special signals are required, they shall be agreed upon by the operator and support


personnel prior to the lifting operation. Signals shall always be visible or audible. No action shall be taken unless signs are clearly understood.

- Load handling personnel shall obey any stop signal.



NB: Pay attention to the “Hydraulic fluid safety information” as listed in Appendix G “Hydraulic fluid safety information”.

7.1.2 Warning signs on the System



NB: Follow the instructions on labels applied to the system, without question.

The legend of the symbols is given in section 2.3 “Symbols applied to the System”.

7.2 Local control of one unit

This section describes how to control one single unit.








Attention: Never use local control when header beams are mounted, since:

- the units are not controlled simultaneously.
- no automatic levelling (“hysteresis”) is performed
- no load detection is performed.

For the buttons, switches and indicators reference is made to 6.2 “The control panel of the unit”.

To use local control proceed as follows:

<ol style="list-style-type: none"> 1. Switch the unit on. Switch the motor on. 	
---	---

2.	Verify that power on is lit, and motor failure and side shift overload are dimmed.	
3.	Set the unit to Local Control	
4.	Select the required speed	
5.	<p>Perform the operation you want to:</p> <ul style="list-style-type: none"> • Extend or retract the cylinder • Move the unit • Move the side shifts 	


7.3 Suspend the load

7.3.1 Side shift units or lifting lugs



To suspend the load, use side shift or lifting lugs.


Attention: Do not place the sling directly over the header beam.



The anchors on the header beam have to be in line with the hoisting points of the load.




Hazard: if the anchors are not in line with the hoisting points, the load will sway as soon as it gets free from the ground. The resulting lateral force may endanger the stability of the System.



Keep the lifting straps as short as possible.




Hazard: long slings may enable swinging of the load, causing dangerous lateral forces.



The header beam has to be kept level at any time, with a tolerance of 0.2°.

Level the header beam at installation time.

During operation the header beam is kept level automatically.



Lifting slings have to be plumb within a tolerance of 0.2°. This is especially applicable for tilting operations; see section 7.9 “Tilt the load”.



Hazard: exceeding the limit of 0.2° will cause dangerous lateral forces.


7.3.2 Sling guides

To suspend the load using sling guides, proceed as follows:

1. Position the slings over the sling guides. Make sure the slings are in parallel. Make sure the slings do not run over the flanges of the sling guide.



Hazard: If the slings are incorrect placed, they might fall from the sling guide, injuring the operator.








7.4 Lift the load






This section describes how to lift the load.

In the procedure below reference is made to

- the controls on the remote-control console; see section 6.3 “The remote-control console”.
- the controls and indicators of the units; see section 6.2 “The control panel of the unit”.

Proceed as follows:






1.	Record all activities during the operation using the form given in Appendix D “Recording a lifting operation”.	
2.	Verify that the checklists are completed and signed off: <ul style="list-style-type: none"> • Appendix A “Checklist for planning” • Appendix B “Checklist for installing the System” • Appendix C “Final checks” 	
3.	Switch the remote-control console on. <i>The remote-control console starts up.</i> <i>The software version number is displayed</i>	
4.	Verify the battery of the remote-control console is fully charged <i>The battery status is shown at the display.</i> <i>A full battery has a capacity of approximately 8 hours.</i>	
5.	Switch all four units on. Switch all motors on.	
6.	Verify that Power on is lit, and motor failure and side shift overload are dimmed.	
7.	Set all units to Remote-control	






8.	<p>Activate all four units on the remote-control console.</p>																									
9.	<p>Reset the measured heights of all units by pressing “zero lift”.</p> <p><i>The current heights of the cylinders will be taken as the new reference points.</i></p> <p><i>The height counters on the display will start counting from zero.</i></p>																									
10.	<p>Select the travelling speed of your choice. Select “low” if the system is carrying a load.</p> <p><i>If the system detects a load, or if the units are extended for more than the first stage then “Low” is selected automatically.</i></p>																									
11.	<p>Lift the load using the remote-control console.</p>																									
12.	<p>While lifting, monitor the display (shown below).</p> <ul style="list-style-type: none"> • Monitor the lifting heights. The heights of the cylinders are measured continuously. The remote-control console automatically levels the heights of all cylinders within a bandwidth (‘hysteresis’) of 24 mm. When the difference of height exceeds 24 mm, the system stops moving. Technical investigations of the problem have to be made. Follow the main problem-solving procedure as described in 8.1 “Main problem localization procedure”. • Monitor the individual loads on the units. • Monitor the total load on the system. • Monitor the direction of vertical movement. • Monitor the power status of the battery. <div data-bbox="264 1688 1195 1883" style="background-color: #d4edda; border: 1px solid #c3e6cb; border-radius: 10px; padding: 10px;"> <table border="1"> <thead> <tr> <th>Tot.</th> <th>4614 kN</th> <th>Ram_1</th> <th>Ram_2</th> <th>Ram_3</th> <th>Ram_4</th> </tr> </thead> <tbody> <tr> <td>Position</td> <td>mm</td> <td>6285 ↑</td> <td>6287 ↑</td> <td>6289 ↑</td> <td>6272 ↑</td> </tr> <tr> <td>Lift</td> <td>mm</td> <td>6282</td> <td>6287</td> <td>6289</td> <td>6272</td> </tr> <tr> <td>Load</td> <td>kN</td> <td>1175</td> <td>1135</td> <td>1147</td> <td>1157</td> </tr> </tbody> </table>  </div>		Tot.	4614 kN	Ram_1	Ram_2	Ram_3	Ram_4	Position	mm	6285 ↑	6287 ↑	6289 ↑	6272 ↑	Lift	mm	6282	6287	6289	6272	Load	kN	1175	1135	1147	1157
Tot.	4614 kN	Ram_1	Ram_2	Ram_3	Ram_4																					
Position	mm	6285 ↑	6287 ↑	6289 ↑	6272 ↑																					
Lift	mm	6282	6287	6289	6272																					
Load	kN	1175	1135	1147	1157																					
13.	<p>Switch the unit off</p>																									
14.	<p>Switch the remote-control console off</p>																									

7.5 Move the load in longitudinal direction

To move the load, all units travel synchronously.
The remote-control console is to be used.


Proceed as follows:

1.	Record all activities during the operation using the form given in Appendix D "Recording a lifting operation".	
2.	Verify that the checklists are completed and signed off. <ul style="list-style-type: none"> • Appendix A "Checklist for planning" and • Appendix B "Checklist for installing the System" • Appendix C "Final checks" 	
3.	Switch the remote-control console on. <i>The remote-control console starts up.</i> <i>The software version number is displayed</i>	
4.	Verify the battery of the remote-control console is fully charged <i>The battery status is shown at the display.</i> <i>A full battery has a capacity of approximately 8 hours.</i>	
5.	Switch all four units on. Switch all motors on.	
6.	Verify that Power on is lit, and motor failure and side shift overload are dimmed.	
7.	Set all units to Remote-control	


8.	<p>Activate all four units on the remote-control console.</p>																									
9.	<p>Select the travelling speed of your choice. Select "low" if the system is carrying a load.</p> <p><i>If the system detects a load, or if the units are extended for more than the first stage then "Low" is selected automatically.</i></p>																									
10.	<p>Move the units into the direction according to your own requirements.</p> <div style="display: flex; align-items: center;">  <p>Attention: When you have stopped the system four times then you have to synchronize the positions of the units. See section 7.6 "Synchronize the positions of the units"</p> </div>																									
11.	<p>While travelling, keep monitoring the position and the lifting heights.</p> <div style="background-color: #d4d4d4; padding: 10px; border-radius: 10px; margin: 10px 0;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: left;">Tot.</th> <th style="text-align: right;">4614 kN</th> <th style="text-align: center;">Ram 1</th> <th style="text-align: center;">Ram 2</th> <th style="text-align: center;">Ram 3</th> <th style="text-align: center;">Ram 4</th> </tr> </thead> <tbody> <tr> <td>Position</td> <td style="text-align: right;">mm</td> <td style="text-align: center;">6285 ↑</td> <td style="text-align: center;">6287 ↑</td> <td style="text-align: center;">6289 ↑</td> <td style="text-align: center;">6272 ↑</td> </tr> <tr> <td>Lift</td> <td style="text-align: right;">mm</td> <td style="text-align: center;">6282</td> <td style="text-align: center;">6287</td> <td style="text-align: center;">6289</td> <td style="text-align: center;">6272</td> </tr> <tr> <td>Load</td> <td style="text-align: right;">kN</td> <td style="text-align: center;">1175</td> <td style="text-align: center;">1135</td> <td style="text-align: center;">1147</td> <td style="text-align: center;">1157</td> </tr> </tbody> </table>  </div>		Tot.	4614 kN	Ram 1	Ram 2	Ram 3	Ram 4	Position	mm	6285 ↑	6287 ↑	6289 ↑	6272 ↑	Lift	mm	6282	6287	6289	6272	Load	kN	1175	1135	1147	1157
Tot.	4614 kN	Ram 1	Ram 2	Ram 3	Ram 4																					
Position	mm	6285 ↑	6287 ↑	6289 ↑	6272 ↑																					
Lift	mm	6282	6287	6289	6272																					
Load	kN	1175	1135	1147	1157																					
12.	Switch the unit off																									
13.	Switch the remote-control console off																									

7.6 Synchronize the positions of the units


While the units travel, their relative positions are kept constant automatically by regulating their individual travelling speeds. Use is made of a sensor which measures the travelling movements of the unit.



The sensor starts measuring from zero every start. Therefore, a unit may get out of rectangular position when the system has stopped moving several times. Such is illustrated below.



To synchronise the positions of the units, proceed as follows:

<p>1.</p>	<p>Measure the relative positions of the units.</p> <p>The units are in rectangular formation if</p> <ul style="list-style-type: none"> • $B1 = B2$ • $A1 = A2$. <p>To measure the positions of the units you might apply</p> <ul style="list-style-type: none"> • a tape-measure • optical measuring means, if you want to stay away from the System while it is bearing a load <p>Feel free to apply your own measuring methods.</p>	
<p>2.</p>	<p>If you detect misalignment then move the concerned unit (or units) to restore the rectangular formation. Apply local control or remote-control to move the unit.</p> <p> Attention: To prevent worsening the situation:</p> <ul style="list-style-type: none"> • make sure you move the correct Unit(s) • make sure you move it in the correct direction. The stability of the system is at stake! 	

7.7 Move the load in transversal direction








For moving the load in transversal direction, the moving capability of the side shift is applied.



Caution: Side shift is a separate system. Side shifting will not stop when overload in one of the units occurs.



NB: the side shift units do run simultaneously, but they are not synchronised.

To operate the side shifts simultaneously, proceed as follows:

1.	Record all activities during the operation using the form given in Appendix D "Recording a lifting operation".	
2.	Verify that the checklists are completed and signed off. <ul style="list-style-type: none"> • Appendix A "Checklist for planning" and • Appendix B "Checklist for installing the System" • Appendix C "Final checks" 	
3.	Switch the remote-control console on. The remote-control console starts up. <i>The software version number is displayed</i>	
4.	Verify the battery of the remote-control console is fully charged <i>The battery status is shown at the display.</i> <i>A full battery has a capacity of approximately 8 hours.</i>	
5.	Switch all four Units on. Switch all motors on.	
6.	Verify that Power on it lit, and Motor failure and Side shift overload are dimmed.	
7.	Set all units to Remote-control	


8.	Activate all four units on the remote-control console.	
9.	Move the selected side shift units.	
10.	Switch the unit off	
11.	Switch the remote-control console off	

7.8 Rotate the load

1.	Be sure all personnel is outside the declared safety zone.	
2.	Lift the load using the gantry system.	
3.	Make sure stop-guide wires are in place and manned.	
4.	Rotate the load by pulling the guide wires.	See section 6.5 "Rotate the load using the rotation anchor".

7.9 Tilt the load

Tilting a load is illustrated below.



Observe the following:

- Unlike the normal lifting operations, here the slings should be kept as long as possible, to minimize lateral forces.
- Always apply four units.
- Only move two units at a time. Keep the other two units passive.
In the illustration above the red unit is the active one: it moves towards the blue unit. The blue unit is passive and stands still.







Hazard: This operation has an increased risk of dangerous lateral forces.






NB: If you want to perform a tilting operation, first contact Enerpac.

An illustrative video of a tilting operation is available on

<https://www.youtube.com/watch?v=rC1toW6ECfU>

To tilt a load, proceed as follows:

1.	Record all activities during the operation using the form given in Appendix D “Recording a lifting operation”.	
2.	Verify that the checklists are completed and signed off. <ul style="list-style-type: none"> • Appendix A “Checklist for planning” and • Appendix B “Checklist for installing the System” • Appendix C “Final checks” 	
3.	Switch the remote-control console on. <i>The remote-control console starts up. The software version number is displayed</i>	
4.	Verify the battery of the remote-control console is fully charged <i>The battery status is shown at the display. A full battery has a capacity of approximately 8 hours.</i>	
5.	Switch the two active Units on. Switch the motors on.	
6.	Verify that Power on is lit, Motor failure and Side shift overload are dimmed.	

<p>7. Set all units to Remote-control</p>	
<p>8. Set the speed on the remote-control console to slow.</p>	
<p>9. Select the two 'passive' units on the remote-control console</p>	
<p>10. Manoeuvre the header beam of the units attached to the (future) bottom of the load right above the load.</p>	
<p>11. Attach the bottom of the load to the header beam.</p>	
<p>12. De-select the passive units on the remote-control console</p>	
<p>13. Manoeuvre the header beam of the active units right upon the (future) top of the load.</p>	
<p>14. Attach the header beam to the load</p>	
<p>15. Extend the cylinder for 5 cm.</p>	
<p>16. Let the units travel towards the passive units for 5 cm in such a way that the lifting eyes of the load are once again directly underneath the header beam.</p> <p>Verify that the lifting eyes are straight underneath the header beam with in tolerance of 0.2°. Use a plumb line, a laser or a theodolite</p>	
<p>17. Repeat the steps 14 .. 16 until the load has been tilted completely</p>	
<p>18. Switch the unit off</p>	
<p>19. Switch the remote-control console off</p>	



8 Solve problems

This chapter describes localization and solving of problems.

- A main problem localization procedure is given.
- A list of possible problems is given, together with causes and possible solutions.

8.1 Main problem localization procedure




When during lifting or other use of the System problems occur, follow the steps below to solve the problem.





1.	Verify that no Emergency button is activated: Is the indicator on the control panel lit?	
2.	Is there a technical problem in one of the units? Check the Control Panel of all units. <ul style="list-style-type: none"> • Power on should be lit • Motor failure should be dimmed • Side shift overload should be dimmed 	
3.	Is there an overload problem? Check the displayed loads on the remote-control console.	
4.	Are hydraulic leakages visible?	

8.2 List of problems and solutions

The table below lists a number of errors and problems which may appear during the use of the System, together with possible causes and solutions.

Symptom	Possible cause	What to do...
Main problems		
Load value “-300” displayed <i>(large negative)</i>	Faulty or loose wiring	Check the wiring Call Enerpac
All units selected, but none moves up	Cylinder at end position?	-
	One of the hydraulic motors stopped	Press the START button on the Control Panel to restart
	Emergency pressed?	Reset the Emergency. See section 6.1 “The emergency buttons”

Symptom	Possible cause	What to do...
All units selected, but only one moves up	Height measurement was not zeroed.	Zero the height measurements. Use the remote-control console. 
After switching on the Control Panel of a Unit, the error "communication timeout" is displayed on the remote-control console	This is normal behaviour due to time needed by the starting-up processes.	Wait for approximately 30 seconds
No display indication after switching on the remote-control console	Battery is low	<ul style="list-style-type: none"> • Charge the battery for at least 4 hours, or • Connect the power supply
Reports on the display of the remote-control console		
"Emergency pressed"	An Emergency button was pressed, either on one of the unit or on the remote-control console.	Reset the emergency
"Communication timeout"	Radio disturbed	Use cable connection
"**" visible behind the RAMs"	No problem	Appears when the cable connection is used
"System not ready"	Initiation message	Wait 20 seconds
"Stroke measurement out of range"	Measurement counter defect	Replace the device
	Fault in the wiring	Repair the wiring
	Height measurement cable snapped	Check the cable
"Load measurements out of range"	Sensor defect	Replace the sensor or contact Enerpac.
	Fault in the wiring	Check the wiring
"Drive sensor error" (All Units stop driving)	One of the travelling distance measuring devices is defect.	Change the sensor or contact Enerpac.  Caution: If you do not have a spare sensor, you might remove all driving sensors of all Units. The System will be operational again, BUT WITHOUT DRIVING SAFETY! IT IS ON YOUR OWN RISK.
		Too long misalignment between the Units
	One of the units is obstructed	
"Engine still"	Electro motor of the indicated unit is not running	Start the motor. 
"Overload"	Too much weight on one of the booms	If on one cylinder: the load is not divided equally over the System. Else: reconsider your lifting operation with reference to the weight of the Load

Symptom	Possible cause	What to do...
Mechanical and electrical problems		
The System does not travel	The two Bolts of the driving motors of the Units are loose	Fasten the bolts
	One of the hydraulic valves is defect	Repair the valve; Contact Enerpac.
The System does not lift	Hydraulic valve defect	Call Enerpac
	unit is switched off	Switch the unit on. 
The cylinders raise unequally	Problem with oil flow or leakage.	Contact Enerpac
The System cannot lower the load	Problem with oil flow or leakage.	Contact Enerpac
The Side Shift does not move	Side shift not connected	Connect the Side Shift
	Thermic safety relays tripped 	Open the Electrical Cabinet and reset the relays indicated with 10QF2. See the picture. If not successful then Contact Enerpac.
Indicator "Invertor Failure" on the Electrical Cabinet is lit		Try to start the motor. 
Indicator "Side Shift Overload" on the Electrical Cabinet is lit		If not successful the open the Electrical Cabinet and reset the relays indicated with 11QF2; see the picture. If not successful then Contact Enerpac.
Indicator "Side Shift Overload" on the Electrical Cabinet is lit		Try to start the motor. 
		If not successful then open the Electrical Cabinet and reset the relays indicated with 10QF2; see the picture. If not successful then Contact Enerpac.
Vibrations of the boom	Boom not lubricated well, or contaminated	Clean and lubricate. See section 10.3.6 "Lubricate the booms"



Hazard: Performing repairs on the system may cause dangerous effects when not executed by well-skilled personnel.



NB: The table is meant as a first aid kit. Contact Enerpac if you need assistance.




8.3 Repair the wire stroke sensor

If the wire has to be replaced, the stroke sensor has to be calibrated as well. This section describes both activities.



NB: The wire is mounted permanently. The procedure is only applicable for reparation purposes. After the wire was mounted, the system has to be calibrated.

8.3.1 Replace the wire

<p>1. Check whether the plate is clean, and the runner can move light and freely.</p>	 <p style="text-align: right;">runner</p>
<p>2. Attach the wire on the runner on the plate.</p> <p> Caution: don't let snap. It may damage the sensor.</p>	 <p style="text-align: right;">wire</p>

8.3.2 Calibrate the stroke sensor

This paragraph describes how to calibrate the stroke sensor, which measures the height of the boom.



NB: Calibration has to be performed when stroke sensors were changed, so calibration is not part of the daily routine.






The main principle of calibration is as follows:




The computer continuously receives the values of all four stroke sensors. During calibration the cylinders are retracted to the very minimum, and then extended to the very maximum. The computer relates the lowest received value to the minimum height of the unit, and the highest received value to the maximum height.



NB: More units can be calibrated simultaneously.

To calibrate, proceed as follows:

1.	<p>Preconditions:</p> <ul style="list-style-type: none"> • The remote-control is switched off • All units are switched off. 	
2.	Switch the remote-control console on.	
3.	Set "Speed" on the remote-control console to the 'hare' (high speed)	
4.	<p>Press "Zero lift" and keep it pressed while you switch the remote-control console on.</p> <p>Keep "Zero lift" pressed until the message "System not ready" is shown</p> <p>Then release the button.</p> <p>The remote-control console is now in calibration mode.</p>	
5.	<p>Release the "Zero lift" button.</p> <p>The "Calibration mode" message appears on the display.</p>	
6.	<p>You can calibrate more units simultaneously.</p> <p>Switch all unit which you want to calibrate, to on.</p> <p>Start their motors.</p>	
7.	Select the unit(s) on the remote-control console.	
8.	Retract the cylinders to their very minimum position.	

9.	Extend the cylinders to the very maximum position	
10.	<p>Deselect the units.</p> <p><i>The stroke sensors have been calibrated. The message "Calibration succeeded" is shown.</i></p> <p>Attention: <i>If communication was poor during calibration, the following message appears: "Calibration failure". If so, then restart the procedure.</i></p> 	
11.	Switch the remote-control console off.	
12.	Switch the remote-control console on.	
13.	Verify the displayed height. It should be the maximum position.	
14.	Retract the cylinder to the very minimum position.	
15.	Verify the displayed position. It should be approximately zero.	

9 Storage


9.1 System

When the system is stored then retract all jacks.


Requirements for storage of the System:

- During short-term storage, especially in the open air, cover the units with a tarpaulin in order keep electrical and other moisture-sensitive components dry.
The tarpaulin is not included in the delivery, but can be added as an option.
- Long-term storage:
For long-term storage a dry and closed space is recommended.

For storage temperature of the system see section 3.3.1 “Main specifications”.


 **NB:** During storage in the open air, cover the units with a tarpaulin in order keep electrical and other moisture-sensitive components dry.
The tarpaulin is not included in the delivery but can be added as an option.

Make sure to keep the electronics dry.
Pay special attention to the stroke sensor.



9.2 Hydraulic hoses

- Store hoses in a **frost-free**, cool, dry space with medium air humidity (condensation free).
- Keep hoses out of direct **sunlight** (UV radiation).
- Keep hoses out of the outlet flow of ventilators (drying effect).
- Protect hoses against exposure to **ozone** (released during welding work).
- Ozone causes accelerated ageing of hoses (splitting due to dryness).
- Protect hoses against dirt and **moisture**.
- Preferably store hoses in a **horizontal** position.
When you store the hoses in **vertical** position use hose brackets with a bend **radius** of at least 200 mm, or more for larger hose diameters, as shown below.



9.3 Remote-control unit

Store the remote-control with a maximum charged battery in case of storage for more than one month. After six months of storage the battery will still be charged for approximately 40% in case of an ambient temperature of 25°C.



Attention: During storage in the open air, cover the units with a tarpaulin in order keep electrical and other moisture-sensitive components dry.

If the stroke meter gets wet, its functioning may be impaired. So pay special attention to the encoder box.

The tarpaulin is not included in the delivery but can be added as an option.

10 Maintenance

Keep the machine in good condition to obtain optimum performance from your machine and to guarantee the safety of the users.

This chapter describes

- the maintenance jobs to be carried out
- the required skills for the maintenance jobs
- the time-intervals the jobs have to be performed in.

The time intervals are given for regular frequency of use and normal severity of service conditions.

The time intervals have to be taken proportionally shorter when

- the system is applied more often than regular, which is once per month.
- the system is used in exceptional service conditions, like wet or salty environments
- the system is applied to the limits of its capacity
- the system is applied for special service. The time interval has to be discussed with Enerpac.

The time intervals may be varied based on experience gained on the service life of systems used in similar circumstances.

- If the system was idle for at least 6 months, all inspections as listed in the following section with a prescribed frequency of at least 6 months have to be performed.
- Prior to use, all new, altered, modified, or repaired hydraulic gantry systems shall be inspected to verify compliance with the applicable provisions of this section. Written records are not required.



NB:

- Only perform maintenance on the units if they are not under load
- Only perform maintenance on the units if the header beams have been removed.
- Any maintenance procedures not detailed in this section can only be performed by or in consultation with Enerpac.
- Only apply spare parts provided by Enerpac. If non-Enerpac parts are applied, all guarantees will be void.



NB: If the system has been idle for more than 12 months than it shall be inspected prior to use completely.

10.1 Rules to be observed for maintenance

Due to the regulations as stated in Ref 7 "ASME B30.1-2015" observe the following rules for maintenance:

1. If the system was **idle** for at least 12 months, all inspections as listed in the following section with a prescribed frequency of at least 12 months have to be performed.
2. Prior to use, all **new, altered, modified, or repaired** hydraulic components shall be inspected to verify compliance with the applicable provisions of this section. Written records are not required.
3. Only perform maintenance if the system is **not under load**.
4. Any maintenance procedures **not detailed** in this section can only be performed by or in consultation with Enerpac.
5. Only apply **spare parts** provided by Enerpac. If parts of foreign make are applied, all guarantees will be void.
6. The warranty shall void if any **modifications** are made to the powerpack without the consent of the manufacturer.
7. Make certain that you are **familiar** with the powerpack and its use. Read the user manual carefully and in full and request instructions from the operator where needed.
8. Only perform maintenance work if you are **qualified** to do so. Unauthorized personnel may not open the Power pack.
9. Follow all instructions given on the **warning symbols** on the powerpack.
10. Follow all **safety instructions** in this manual.
11. When working with **flammable liquids**, take the applicable safety regulations into account.

12. Only perform maintenance work after the powerpack has been **shut down**. Before starting maintenance, make sure the powerpack is secured against unauthorized use. Put up warning signs.
13. Make certain that the hydraulic system is **not under pressure**. Use the manometer.
14. If maintenance has to be executed while the system is **running** then a person has to be present to supervise, and to stop the machine if needed. This also applies for work on the electrical system if the system needs to be powered.
15. Do not **spill** any oil and similar fluids. Be mindful of the environment and the costs of cleaning up.
16. Make certain that you apply personal protection equipment (**PPE**) and take any other safety precautions required by the working conditions.
17. Make sure that you know the location of **fire alarms**, firefighting facilities and fire extinguishers.
18. Only use suitable work **equipment**. Prevent damage due to use of unsuitable equipment.
19. Without the express consent of the manufacturer, you are not allowed to make any **changes**, additions or adjustments to the Powerpack which affect the safety of the machine. This also applies to installation and adjustment of safety devices, covers and valves and to welding work on load-bearing parts.
20. Make certain that the powerpack is made **ready for operation** after the maintenance work was been completed. Inform the operator.

10.2 Responsibilities

Due to the regulations as stated in Ref 7 "ASME B30.1-2015" observe the following rules for responsibilities.

The maintenance tables indicate for each maintenance job whether it has to be performed either by the owner or by the manufacturer.

Contact the manufacturer for the following maintenance work:


- Adjusting the pressure in the hydraulic system.
- Adjusting and repairing hydraulic pumps and setting up hydraulic pumps.
- Adjusting and repairing control valves for all main functions.
- Adjusting the electrical system and repairs to the control system.
- Replacing parts.

In these cases, the maintenance work for the owner is limited to identification of a fault.

10.3 Mechanical

Perform maintenance on the mechanical part according to the list as shown below.
Record all activities in Appendix E “Logging Maintenance”.



Subject	Action	Person O (owner) EE (Enerpac expert)	First 40 hours	8 hours Daily	40 hours Weekly	Each 500 hours Every year	2000 hours Every 2 years	10000 hours Every 10 year	Remarks
1. Main construction									
1.1. Main construction	Visual check of all welding	O				X			
	Visual check painting	O				X			
	Visual check on corrosion and damages	O			X				
	Check all bolts.	O				X			
	Visual check of the lifting lugs	O				X			
	Inspect the readability of the warning signs. Clean if obscured by dirt. Restore if damaged or even no longer present	O			X				
1.2. Test the oil of the gearboxes	Test the oil of the gearboxes See section 10.3.11 “Replace the oil of the gearboxes”	O					X		
1.3. Measure the guiding pads	Measure the guiding pads. See section 10.3.7 “Measure the wear of the guiding pads”	O				X			or 50 lifting hours
1.4. Adjust the guiding pads	Adjust the guiding pads. See section 10.3.8 “Adjust the guiding pads”.	EE	X			X			or 50 lifting hours
1.5. Lubricate the swivel	Lubricate the swivel. See section 10.3.5 “Lubricate the swivel”.	O	X			X			or 50 lifting hours
1.6. Lubricate the booms	Lubricate the booms. See section 10.3.6 “Lubricate the booms”.	O	X			X			or 50 lifting hours
1.7. Travelling distance sensor	Check the travelling distance sensor. Does it run fine? No dirt?	O			X				

									
<p>1.8. Stroke sensor</p>	<p>Check the stroke sensor. See section 10.3.9 "Check the stroke sensor".</p>	<p>O</p>			<p>X</p>				
<p>1.9. Replace the oil of the gearboxes</p>	<p>Replace the oil fo the gearboxes. See section 10.3.11 "Replace the oil of the gearboxes".</p>	<p>O</p>				<p>X</p>			
<p>2. Chain of the units</p>									
<p>2.1. Lubricate the chain</p>	<p>Lubricate the driving chains. See section 10.3.1 "Lubricate the driving chains"</p>	<p>O</p>			<p>X</p>				
<p>2.2. Tension the chain</p>	<p>Tension the driving chains. See section 10.3.2 "Tension the driving chains".</p>	<p>O</p>			<p>X</p>				
<p>2.3. Tension the roller chains</p>	<p>Tension the roller chains See section 10.3.3Tension the roller chains (SBL1100)</p>	<p>O</p>			<p>X</p>				
<p>3. Side shift unit</p>									
<p>3.1. Lubricate the chain</p>	<p>Lubricate the chain See section 10.3.4 "Lubricate the side shift units".</p>	<p>O</p>			<p>X</p>				<p>or 25 lifting hours</p>
<p>3.2. Tension the chain</p>	<p>Tenson the chain of the side shift units. See section 10.3.10 "Tension the chain of the side shift units".</p>	<p>O</p>			<p>X</p>				


10.3.1 Lubricate the driving chains



10.3.1.1 SBL500

The chain connects the gearbox with the driving shafts.
To lubricate the chains proceed as follows:

1.	Make sure the power supply has been switched of	
2.	Unlock the front doors and open them	
3.	Visually inspect the chains and the gears	
4.	Clean the chains	
5.	Lubricate the chain with Kroon Oil multi-purpose grease 3	
6.	Close and lock the front door	

10.3.1.2 SBL900, SBL1100


1.	Make sure the power supply has been switched of	
2.	Unlock the front doors and open them	

3.	Visually inspect the chains and the gears	
4.	Clean the chains	
5.	Lubricate the chain with Kroon Oil multi-purpose grease 3	
6.	Close the front doors and lock them	
7.	Verify that the wheel of the travelling distance measuring device runs fine	






10.3.2 Tension the driving chains

10.3.2.1 SBL500

The motor is mounted on a subframe which can move in slotted holes.





To tension the chain, proceed as follows:

<p>1. Loosen the four bolts of the subframe</p>	
<p>2. Tension the chain by moving the subframe.</p> <p>The slack in the middle of the chain shall be 10 mm. Use hand power.</p> <div style="display: flex; align-items: center; margin-top: 10px;">  <p>Caution: tensioning the chains too tight might harm the driving mechanism</p> </div>	
<p>3. Tighten the bolts of the shaft.</p> <div style="display: flex; align-items: center; margin-top: 10px;">  <p>Make sure the sub frame is kept parallel</p> </div>	
<p>4. Close the front door</p>	

10.3.2.2 SBL900, SBL1100

To tension the drive-chain, proceed as follows:

1.	<ul style="list-style-type: none"> The gearbox is affixed to the frame of the unit with 6 bolts which can move in slotted holes. The bearings of the intermediate shaft are affixed to the frame of the unit with 6 bolts, which can move in slotted holes 	
2.	Loosen the bolts of the shaft	
3.	Tension the lower chain. The slack in the middle of the chain shall be 10 mm. Use hand power.	
4.	Tighten the bolts of the shaft	
5.	Loosen the bolts of the gearbox	
6.	Tension the upper chain until the slack is 10 mm in the middle of the chain. Use hand power.	
7.	Tighten the bolts of the gearbox. Use 430 Nm.  Caution: tensioning the chains too tight might harm the driving mechanism	
8.	Close the front door	






10.3.3 Tension the roller chains (SBL1100)



To tension the roller chains proceed as follows:

Caution:

During the adjustment, you are underneath the unit. Use lawful hoisting and lifting equipment.

- | | |
|----|---|
| 1. | Make sure the power supply has been switched of |
|----|---|

<p>2. Lift the unit.</p>	
<p>3. Verify the slack between the upside of the middle roller and the frame of the unit.</p> <p><i>If the clearance exceeds 10 mm then continue with the next steps.</i></p>	
<p>4. Unscrew the four bolts [1] at the rear side of the unit (so the side of the stairs) ...</p> <p>... both at the left- and the right hand side of the track. So, eight bolts in total.</p>	
<p>5. Tension the chains by turning the bolts. Use hand power. Make sure the shaft is kept parallel.</p> <p>Carry on turning until the top of the roll is flush with the frame</p> <p> Caution: Tensioning the chain too tight might harm the driving mechanism</p>	

6.	Tighten the bolts.	
7.	Inspect the roller chain: <ul style="list-style-type: none">• Check he bolts on damage• Make sure the bolts of the chain are tightened (45 Nm)	


10.3.4 Lubricate the side shift units


The side shift units are provided with chains, which have to be lubricated.

Use “Kroon Oil multi-purpose grease 3”.

All types of side shift units are shown below.


(The bearings of the side shift units were greased for lifetime.)





10.3.5 Lubricate the swivel

Lubricate the nipples of the swivel; two at both sides. Use 10 strokes of Kroon Oil multi-purpose grease 3.






10.3.6 Lubricate the booms

Perform this procedure:

- At the regular maintenance intervals
- In case of vibration of the booms during operation.
- In case of contamination of the running surface(s) by for instance sand, clean the running surfaces and lubricate the booms again.
- When new guiding pads were mounted. Before mounting the new pads, activate them by rubbing them with a rag saturated with synthetic oil.




Proceed as follows:

<p>1. Use personal protection means</p>	
---	--

<p>2. Remove dirt. You might apply a filler knife.</p>	
<p>3. Clean the ram with cleaning spirit</p>	
<p>4. Wipe the ram dry. Use a lint free cloth.</p>	
<p>5. Saturate a rag and lubricate the booms on their running surfaces (the mating surface of the guide pads) with synthetic motor oil, for instance 10W40.</p>	

10.3.7 Measure the wear of the guiding pads


Guiding pads are mounted inside the booms.



The wear of the guiding pads has to be measured regularly. The maximum permissible wear is given in Appendix F "Wear of the pads".

The principle of measuring and adjusting is as follows:

- The pads are fixed to the fixing plate.
- As the pads wear, you have to move the fixing plate inwards by turning the adjusting bolts. In this way the pads stay in touch with the inner boom.
- The distance the fixing plate moved ($d_2 - d_1$) is a measure of the wear of the pads.



Record the wear of the pads in Appendix F “Wear of the pads”.





NB: To be able to calculate the wear of the pads, measure their thickness

- before first use of the system
- when new pads are mounted.

To measure the wear of the guiding pads, proceed as follows:

<p>1.</p>	<p>Measure the distance of the fixing plate of the lowest section. Use the indicated wholes.</p>	
-----------	--	--

		
2.	Enter the result of the inspection in the checklist given in F “Wear of the pads”.	
3.	Continue for the pads of the other sections	
4.	When the pads are worn out, replace them. See also section 10.3.6 “Lubricate the booms”.	


10.3.8 Adjust the guiding pads


Guiding pads are of plastic fabric and are subject to wear. Therefore, they have to be adjusted periodically.

At each stage, the inner side of the boom is provided with four sets of steel plates on which guiding pads are mounted.

One set of steel plates consists of a two plates which abut against each other.

- Two guiding pads are mounted on the inner plate: one on the top and one on the bottom.
- The distance between the inner- and the outer plate can be adjusted by adjusting bolts.
- Those bolts can be reached through holes in the boom.
- The plates are affixed to the boom by a mounting element.







Adjusting the guiding pads is done stage by stage, by tensioning the adjusting bolts. The procedure has to be executed preferably by two persons.

NB: This accurate job should preferably be executed by Enerpac people.



<ol style="list-style-type: none"> Put the unit horizontally with a tolerance of 0.2° Position yourself close to top of the unit. Use the platform or your own means. <div style="display: flex; align-items: center; margin-top: 10px;">  <p>Hazard Wear a safety harness. You're working at height.</p> </div>	
<ol style="list-style-type: none"> The adjusting bolts of the guiding pads are located behind the holes in the boom. <p>Loosen the 8 upper bolts and the 8 lower bolts of the four sides by turning them clockwise. Turn them as far as possible.</p>	

<p>4. Turn only a half turn counter clockwise:</p> <ol style="list-style-type: none"> 1. the two upper bolts of side one 2. the two upper bolts of side two 3. the two upper bolts of side three 4. the two upper bolts of side four <p>Use little force. Turn the bolts simultaneously. (Therefore, two persons are required.)</p>	 <p>(top view)</p>
<p>5. Repeat step [4] until 25 Nm is reached.</p>	
<p>6. Turn only a half turn counter clockwise:</p> <ol style="list-style-type: none"> 1. the two lower bolts of side one 2. the two lower bolts of side two 3. the two lower bolts of side three 4. the two lower bolts of side four 	
<p>7. Repeat step [6] until 100 Nm is reached <i>The inner beam is now centred inside the outer beam without being clamped</i></p>	
<p>8. Extend the boom until the four holes of the next section are visible</p>	
<p>9. Repeat the steps [2] .. [8] for the new stages</p>	
<p>10. Repeat the steps [1] .. [9] for all units</p>	




NB: Mounting, adjusting and dismantling of the guiding pads should preferably be done by Enerpac people.





Caution: Incorrect mounting or adjusting of the guiding pads may cause severe risks for the stability of the System.

10.3.9 Check the stroke sensor



Though the wire of the stroke sensor is not a removable part, its presence and the correct mounting has to be checked due to its vulnerability. Proceed as follows:

<p>1. Verify that the wire is connected to the strip on top of the boom</p>	
---	--

<p>2. Verify that the wire is attached to the electrical box as indicated.</p>	
<p>3. Check whether the wheels run fine. No dirt? No rust?</p>	



10.3.10 Tension the chain of the side shift units





Tension of the side shift units.

NB: The following procedure describes tensioning of the chain of the SSU150. Tensioning of the SSU600 and SSU600 is similar.

Proceed as follows:

<p>1. Make sure the power supply has been switched of</p>		
<p>2. Remove the chain cover</p>		
<p>3. Loosen the bolts of the gearbox and clamping ring</p>		


<p>4.</p>	<p>Tension the chain by turning the tensioning bolts or moving the gearbox backwards.</p>	
<p>5.</p>	<p>Tighten the bolts of the gearbox and clamping ring according to Appendix H "Torque settings".</p>	
<p>6.</p>	<p>Keep the gearbox level.</p>	

10.3.11 Replace the oil of the gearboxes

Perform a purity test on the oil of the gearbox.

Change the oil of the gearbox

If the yearly purity test points out or with a periodicity as given in the maintenance table.

<p>1.</p>	<p>Perform a purity test on the oil of the gearboxes</p> 
<p>2.</p>	<p>Change the oil of the gearbox</p> <ul style="list-style-type: none"> • If the yearly purity test points out, or • According to the maintenance schedule. <p>Use 2.6 litres of oil type "ISO VG 320 Mineral oil".</p>

10.4 Hydraulics

This section lists all maintenance jobs for the hydraulics.

Record all activities in Appendix E "Logging Maintenance".

For hydraulic fluid safety information sheet, see Appendix G "Hydraulic fluid safety information".

Regard the following:

- Before starting maintenance, make sure no pressure is present in the hydraulic system.
- All inspections up to yearly have to be performed if the system has been idle for at least 12 months. The system shall only be returned to service when approved by a qualified person as described that section.
- All replacement parts including the ram, hoses, couplings, seals, valves, and caps shall meet or exceed the original equipment manufacturer's specifications.



NB: Enerpac strongly advises to apply parts as bought from Enerpac.



Hazard:

Applying parts which do not apply to the specifications may cause hazards to personnel and the system. Before removing a component of the hydraulic system, check if there is no hydraulic pressure left within the hydraulic system.



Hazard: High pressured hydraulic oil spray can cause physical injuries, fire or death of personnel

Perform maintenance on the hydraulics of the system according to the list below
Record all activities in Appendix E "Logging Maintenance".

Subject	Action	Person O (Owner) EE (Enerpac expert)	First 40 hours	8 hours Daily	40 hours Weekly	500 hours yearly	2000 hours 2 years	10000 hours 10 years	Remarks
1. Hydraulic pump and tank									
1.1. Pump	Check on oil leakage	O		X					
	Check if the bolts are still tightened	O	X			X			
	Check on damages. Check the paintwork.	O		X					
	Wipe it clean and free from dust	O		X					
1.2. Hydraulic tank	Check on oil leakage, damages and paint work	O		X					
	Check if the bolts are still tightened	O	X			X			
	Replace all seals	EE						X	
	Replace the level gauges	EE						X	
1.3. Valves	Drain the tank (water and sludge)	EE					X		
	Check on oil leakage and damages	O		X					
	Check if the bolts are still tightened	O	X			X			
	Replace all seals	EE						X	
1.4. Manifolds	Check all valve settings	O					X		
	Check on oil leakage and damages	O		X					
1.5. Oil	Check if the bolts are still tightened	O				X			
	Take an oil sample to analyze	EE					X		Change oil if necessary
	Replace the hydraulic oil. See setion 10.4.1 "Drain the oil". See section 10.4.2 "Fill the tank"	EE						X	
1.6. Hydraulic filter	Check the oil level	O		X					
	Replace the filter element. See section 10.4.3 "Replace the filter element"	EE				X		X	And if indicated
1.7. Breathers	Replace the seals of the filter housing	EE						X	
	Replace the breather	EE				X			







1.8. Bellhousing	Check on damages	O					X	
	Check if the bolts are still tightened	O	X					X
	Replace motor pump coupling	EE						X
2. Hydraulic connections								
2.1. Pipes, hoses and brackets	Check on oil leakage and damages	O		X				
	Check if the couplings are tightened well.	O	X			X		
	Replace all seals within the piping (Walform)	EE						X
	Replace all hoses	EE					X	
	Replace all plastic brackets	EE					X	
2.2. Couplings and quick-screw couplings	Check on oil leakage and damages	O		X				
	Check if the couplings are tightened well.	O		X		X		
	Replace all seals of the couplings	EE						X
	Replace fast couplings and screw couplings	EE					X	
2.3. Gauges, measurement sensors	Check on damages	O		X				
	Check the tightening bolts, nuts and components	O		X		X		
	Replace all seals	EE						X
	Replace all gauges	EE						X
3. Housing								
3.1. Common	Check on damages and paint	O		X				
	Check if the bolts are still tightened	O	X			X		
	Replace all seals, door seals and inspection hatches	EE						X
	Grease the hinges and locks	O				X		
	Replace engine feet	EE						X
4. Cylinders								
4.1. Common	Check on leakages	O		X				
	Check if the bolts are still tightened	O	X			X		
	Replace all seals	EE						X
	Grease the bearings	EE			X			

10.4.1 Drain the oil

The oil in the sump has either to be refreshed or a purity test has to be performed. For minimum requirements reference is made to section 3.3.1 "Main specifications".




10.4.1.1 SBL500

Proceed as follows:

<ol style="list-style-type: none"> 1. Ensure that the cylinder is completely pulled in 2. Disconnect the hose from to the ball valve 	 <p>Draining the oil by the large ball valve is faster than as using the drain plug</p>	
<ol style="list-style-type: none"> 3. Connect your own hose to the ball valve 4. Remove the air vent 		
<ol style="list-style-type: none"> 5. Drain the oil. <p>While draining, keep an eye on the oil level gauges</p>		
<ol style="list-style-type: none"> 6. Drain the final portion of the oil by using the drain plug. 	 <p>Attention: Dispose the oil responsibly</p>	

10.4.1.2 SBL900, SBL1100


Proceed as follows:


	<p>Ensure that the cylinder is completely pulled in Disconnect the hose from to the ball valve</p>	
	<p>Connect your own hose to the ball valve Drain the oil. While draining, keep an eye on the oil level gauges.</p> <p> Attention: Dispose the oil responsibly</p>	

10.4.2 Fill the tank

10.4.2.1 SBL500



To fill the tank, proceed as follows:

1.	<p>Make sure</p> <ul style="list-style-type: none"> the cylinder of the unit is fully pulled in the drain plug underneath the tank has been mounted 	
2.	<p>Remove the filler cap</p>	

3.	Fill the tank until the maximum level of 50mm below the top of the tank is reached. Use oil type "Shell Tellus T32 or Shell Tellus Artic".
	 Attention: Do not fill the tank over the maximum.
4.	Make sure that the oil is free of air by circulating the oil through the system. Just start the System and let it run for 10 minutes.

10.4.2.2 SBL900, SBL1100

To fill the tank, proceed as follows:

	Make sure the cylinder of the unit is fully pulled in	
	Use the fill/bleed opening to fill the tank with oil. Use oil type "Shell Tellus T32 or Shell Tellus Artic".	
	 Attention: Do not fill the tank over the maximum.	
	Make sure that the oil is free of air by circulating the oil through the system. Just start the System and let it run for 10 minutes.	

10.4.3 Replace the filter element

The return filter cleans the oil that flows back into the tank.

Due to contamination of the oil, the permeability of the filter will decrease, which causes a raise of the pressure of the return flow of the oil. The pressure is shown on the clogging indicator.




Clogging indicator

- Green: the pressure is 0 .. 2 bar
The filter is fine.
- Yellow: the pressure is 2..3 bar
The filter is still working, but has to be replaced as soon as possible.
- Red: the pressure is over 3 bar.
Oil is no longer filtered.
Replace the filter element immediately.

The filter element has to be replaced

- when the oil is refreshed
- when the clogging indicator shows yellow or red
- according to the maintenance scheme


10.4.3.1 SBL500



To replace the filter element, proceed as follows:

1.	Unscrew the return filter cap
2.	Remove the internal filter element
3.	Put a new filter element. To ensure correct operation, only replace with an element with equal brand and type. Use <i>Hydac</i> return filters. The exact type is listed on the parts list of the machine.

10.4.3.2 SBL900, SBL1100



To replace the filter element, proceed as follows:

1.	Unscrew the return filter cap
2.	Remove the internal filter element
3.	Put a new filter element. To ensure correct operation, only replace with an element with equal brand and type. Use <i>Hydac</i> return filters. The exact type is listed on the parts list of the machine.

10.5 Electrics

Perform maintenance on the electrics of the system according to the list below.
Record all activities in Appendix E "Logging Maintenance".

Subject	Action	Person O (owner) EE (Enerpac expert)	First 40 hours	8 hours Daily	40 hours Weekly	Each 500 hours Each year	2000 hours Every 2 years	10000 hours Every 10 year	Remarks
1. Electro motor									
1.1. General	Check on damages	O		X					
	Wipe it clean and free from dust	O	X			X			
2. Cables and connectors									
2.1. General	Check on damages	O		X					
3. Devices and cabinets									
3.1. General	Check on damages	O		X				X	
	Check if the bolts and nuts are still tightened	O	X			X			
	Replace all seals	EE						X	
3.2. Main switch	Replace the main switch	EE						X	
3.3. Remote-control device	Replace the battery	O					X		

11 Quality

Not applicable.

12 Dismantling the system

To dismantle the system at the end of its lifetime, proceed as follows:

- Drain the fluids like:
 - hydraulic oil,
 - lubricating oil,
 - coolant,
 - fuel.
- Remove the batteries.
- Dismount the electric components and electric wiring.
- Dismount rubber and plastic components.
- Dismount the metal components.

Collect all material, sort it and let it be recycled by a specialized company.



Attention: Dispose of all material in a responsible manner.

13 Index

accident	15, 18	hoisting	19, 40, 71, 108, 134, 159, 163
accretion	35	hydraulic	10, 15, 17, 20, 23, 55, 60, 119, 121, 127, 128, 145, 146, 153, 158, 159, 162
address	8	interval	127
aerosols	168	legislation	18, 168, 169, 171, 172
airways	19, 172	lifting capacity	53, 54
alterations	9, 40	manufacturer	10, 12, 127, 128, 145
anaesthetics	167	modifications	10, 127
ASME	8, 10, 127, 128	moisture	125, 126
batteries	153	oesophagus	18
battery	35, 93, 100, 110, 111, 112, 115, 117, 120, 126, 152, 157, 164	overload	54, 98, 107, 110, 112, 115, 117, 119
Bioaccumulation	171	power cable	17, 26, 72
boom	14, 25, 26, 27, 40, 59, 72, 73, 74, 100, 105, 121, 122, 139, 140, 141, 142	pressure	17, 19, 20, 21, 35, 42, 43, 45, 47, 48, 75, 128, 145, 150, 166, 167, 169, 170
cable reel	86	remote-control console	23, 34, 87, 90, 92, 93, 94, 98, 100, 110, 111, 112, 113, 115, 116, 117, 118, 119, 120, 123, 124, 157, 159
calculation	42, 47, 67	secure	13, 20, 52, 128
certificate	17	side shift unit	22, 23, 39, 55, 58, 64, 65, 66, 78, 79, 80, 82, 84, 85, 86, 87, 116, 130, 136, 143
checklist	41, 44, 46, 49, 51, 53, 55, 57, 59, 94, 140, 160	skid track	23, 29, 36, 42, 49, 58, 63, 67, 68, 69, 70, 71, 156, 157, 158, 159
chemical	18, 167, 168, 169	sling guides	32, 55, 66, 89, 109
configuration	10, 11, 12, 38, 39, 90, 93	Sling guides	32, 155
contamination	137, 150, 167, 169	sling tool	81, 85
coupling	20, 21, 147, 162	solvents	169
couplings	17, 20, 21, 145, 147, 162	SSU125	37
cylinder	25, 26, 101, 107, 118, 120, 124, 148, 149, 150	SSU150	37, 79
electrical	8, 10, 17, 18, 20, 26, 27, 72, 121, 125, 126, 128, 143, 158	SSU300	30, 37, 64, 79
electrical cabinet	27, 72	SSU600	30, 37, 65, 84
emergency button	95, 100, 119	stroke sensor	26, 122, 124, 125, 130, 142, 157, 163
emission	169	supervision	10, 17
environment	14, 17, 19, 128, 156, 167, 169, 170, 171	swivel	26, 61, 77, 84, 129, 137, 157, 163
extinguishers	128	temperature	20, 125, 126, 168, 169
fire	17, 18, 19, 128, 145, 167	tilt	40, 117
first-aid	167	time-intervals	127
foundation	42, 43, 45, 47, 48, 49, 52, 67, 68, 157	toxicant	170
foundation material	45, 49, 52, 67	transporting	20, 60
gloves	15, 16, 19, 167, 168	unit	23, 25, 26, 27, 34, 35, 36, 40, 43, 53, 54, 55, 59, 60, 62, 71, 72, 73, 74, 78, 87, 91, 92, 93, 94, 95, 96, 99, 100, 105, 106, 107, 110, 111, 113, 114, 116, 117, 118, 120, 121, 122, 123, 126, 130, 134, 135, 141, 149, 150, 155, 163, 176
goggles	15	warranty	127
ground pressure	42, 44, 45, 46, 49, 51, 67	wired communication	90, 93, 99
guiding wheel	78, 87		
header beam	22, 23, 26, 33, 36, 38, 39, 55, 56, 57, 59, 63, 75, 76, 77, 78, 80, 82, 85, 105, 106, 108, 118, 127, 155, 159		

Appendices

A. Checklist for planning

1. Project

Project	
Customer	
Location	
Date	

2. Planning operation

Type of operation		
<input type="checkbox"/>	Lift / lower	
<input type="checkbox"/>	Move in longitudinal direction	
<input type="checkbox"/>	Move in transversal direction	
The system		
<input type="checkbox"/>	Lifting capacity of the most heavily loaded unit	
<input type="checkbox"/>	Capacity of the header beams	
<input type="checkbox"/>	Minimum force on each unit is sufficient	
<input type="checkbox"/>	Maximum force per anchor or side shift does not exceed the max	
<input type="checkbox"/>	The force on the header beam does not exceed the max	
Lifting lug		
<input type="checkbox"/>	Lugs: single-plate or double-plate type	
Side shift unit		
<input type="checkbox"/>	Required capacity	
<input type="checkbox"/>	Rotation anchor applied? If so, can the load be turned without hitting any obstacle? Is there enough space for personnel to pull the load around?	
<input type="checkbox"/>	Top swivels applied?	
<input type="checkbox"/>	Extended anchor plates for side shift units applied?	
Sling guides		
<input type="checkbox"/>	Are sling guides applied?	
<input type="checkbox"/>	Is the capacity of applied sling guide type sufficient?	
The load		
<input type="checkbox"/>	Mass of the load	
<input type="checkbox"/>	Centre of gravity of the load with respect to the units	
<input type="checkbox"/>	Dimensions of the load.	
Side load		
<input type="checkbox"/>	Max side load	
The operation		
<input type="checkbox"/>	Determine the lifting height	... mm
<input type="checkbox"/>	The travelling distance	... m

<input type="checkbox"/>	Stage extension	1 / 2 / 3	
<input type="checkbox"/>	Capacity in highest stage	... kN	
The environment			
<input type="checkbox"/>	Bearing capacity of the subsoil Tonne/ m ²	
<input type="checkbox"/>	Is additional supporting material under the skid tracks necessary?		
<input type="checkbox"/>	The wind load	Maximum permissible wind speed X-direction	... m/s
		Maximum permissible wind speed Y-direction	... m/s

3. Commitment

Preparations by:

Date:

Signature:

Approved by:

Date:

Signature:

B. Checklist for installing the System

1. Project

Project	
Customer	
Location	
Date	

2. Planning

<input type="checkbox"/>	Checklist A “Checklist for planning” is completed and signed off.
--------------------------	---

3. Foundation

<input type="checkbox"/>	Foundation underneath skid tracks has been put in accordance with the instructions in this manual. If foundation is applied
--------------------------	---

4. Skid tracks

<input type="checkbox"/>	Skid tracks placed according to instructions in manual
<input type="checkbox"/>	Skid tracks aligned according to instructions in manual.
<input type="checkbox"/>	Skid tracks connected according to instructions in manual.

5. Units

<input type="checkbox"/>	Move all units forwards and backwards over a short distance using the remote-control console, to ensure you have set the positive driving direction correctly.
<input type="checkbox"/>	Move all cylinders in and out over a short distance, to assure the communication functions properly.
<input type="checkbox"/>	Check the status of the battery of the remote-control console
<input type="checkbox"/>	Verify that the stroke sensors and the travelling distance sensors are undamaged

6. Header beams

<input type="checkbox"/>	Bolts on the swivel tightened to torque in accordance with instructions in manual
<input type="checkbox"/>	Beam is horizontal (level) on the two units

7. Side shifts

<input type="checkbox"/>	Side shift mounted in accordance with instructions in manual <i>(If applicable)</i>
<input type="checkbox"/>	Move the Side Shifts to the right and the left over a short distance, to assure the correct positive driving direction

8. Visual inspection

<input type="checkbox"/>	Visual inspection: no excessive rust.
<input type="checkbox"/>	No parts of the system are damaged
<input type="checkbox"/>	Visual inspection of the hydraulic components: no oil leakages
<input type="checkbox"/>	Running surfaces of the skid tracks are clean. (Dirt may cause the units to slip)
<input type="checkbox"/>	The units can run freely and are not obstructed.
<input type="checkbox"/>	Inspection of the electrics: - electrical cables are undamaged - electrical cables cannot be pinched

9. Other equipment

<i>What</i>	<i>Length</i>	<i>Capacity</i>	<i>Mass</i>
Lifting straps			
Chains			
Other			

10. Commitment

Installations by:

Date:

Signature:

Approved by:

Date:

Signature:

C. Final checks

1. Project

Project	
Customer	
Location	
Date	

2. Checks

<input type="checkbox"/>	Checklist B “Checklist for installing the System” is completed and signed off.
<input type="checkbox"/>	No parts of the portal lift are damaged
<input type="checkbox"/>	No leakages of the hydraulic components are visible
<input type="checkbox"/>	Drop-zone is cordoned off. No people are inside the unsafe zone. Barriers and tape is used.
<input type="checkbox"/>	Running surfaces of the skid tracks are clean.
<input type="checkbox"/>	The units can run freely and un-obstructed.
<input type="checkbox"/>	The weight of the load is indicated on the remote-control console correctly.
<input type="checkbox"/>	The side-load does not exceed 1.5 % of the vertical load

3. Suspension of the load

<input type="checkbox"/>	The anchors on the header beam are in line with the hoisting points of the load.
<input type="checkbox"/>	The lifting straps are short.
<input type="checkbox"/>	The header beams are level
<input type="checkbox"/>	Lifting slings are plumb.

4. Commitment

Installations by:

Date:

Signature:

Approved by:

Date:

Signature:

D. Recording a lifting operation

1. Project

Project	
Customer	
Location	
Date	

2. Recording of activities

	Activity	Time
<input type="checkbox"/>	The checklist in Appendix A "Checklist for planning" has been completed and signed off	
<input type="checkbox"/>	Checklist B "Checklist for installing the System" completed and signed off	
<input type="checkbox"/>	Checklist C "Final checks" completed and signed off	
1		
2		
3		
4		
5		
6		
7		
8		

	Activity	Time
9		
10		
11		
12		
13		
14		
15		
16		
19		

3. Commitment

Executed by:

Date:

Signature:

Approved by:

Date:

Signature:

E.Logging Maintenance

Hydraulics

Subject	Action	Person	Date
1. Hydraulic pump and tank			
1.1. Pump	Check on oil leakage, damages and paint work		
	Check if the bolts are still tightened		
	Check on damages		
	Wipe it clean and free from dust		
1.2. Hydraulic tank	Check on oil leakage, damages and paint work		
	Check if the bolts are still tightened		
	Replace all seals		
	Replace the level gauges		
1.3. Valves	Drain the tank (water and sludge)		
	Check on oil leakage and damages		
	Check if the bolts are still tightened		
	Replace all seals		
1.4. Manifolds	Check all valve settings		
	Check on oil leakage and damages		
1.5. Oil	Check if the bolts are still tightened		
	Take an oil sample to analyze		
1.6. Hydraulic filter	Replace the hydraulic oil.		
	Check the oil level		
	Replace the filter element.		
1.7. Breathers	Replace the seals of the filter housing		
	Replace the breather		
1.8. Bellhousing	Check on damages		
	Check if the bolts are still tightened		
	Replace motor pump coupling		
2. Hydraulic connections			
2.1. Pipes, hoses and brackets	Check on oil leakage and damages		
	Check if the couplings are tightened well.		
	Replace all seals within the piping (Waldform)		
	Replace all hoses		
2.2. Couplings and quick-screw couplings	Replace all plastic brackets		
	Check on oil leakage and damages		
	Check if the couplings are tightened well.		
	Replace all seals of the couplings		
2.3. Gauges, measurement sensors	Replace fast couplings and screw couplings		
	Check on damages		
	Check the tightening bolts, nuts and components		
	Replace all seals		
3. Housing	Replace all gauges		
	Check on damages and paint		
	Check if the bolts are still tightened		
	Replace all seals, door seals and inspection hatches		
3.1. Common	Grease the hinges and locks		
	Replace engine feet		

4. Cylinders			
4.1. Common	Check on leakages		
	Check if the bolts are still tightened		
	Replace all seals		
	Grease the bearings		

Mechanical

Subject	Action	Person	Date
1. Main construction			
1.1. Main construction	Visual check of all welding		
	Visual check painting		
	Visual check on corrosion and damages		
	Check all bolts.		
	Visual check of the hoisting lugs		
	Inspect the readability of the warning signs.		
1.2. Test the oil of the gearboxes	Test the oil of the gearboxes		
1.3. Measure the guiding pads	Measure the guiding pads		
1.4. Adjust the guiding pads	Adjust the guiding pads		
1.5. Lubricate the swivel	Lubricate the swivel		
1.6. Lubricate the booms	Lubricate the booms		
1.7. Travelling distance sensor	Check the travelling distance sensor		
1.8. Stroke sensor	Check the stroke sensor		
1.9. Replace the oil of the gearboxes	Replace the oil of the gearboxes		
2. Chain of the units			
2.1. Lubricate the chain	Lubricate the chain		
2.2. Tension the chain	Tension the chain		
2.3. Tension the roller chains	Tension the roller chains		
3. Side shift unit			
3.1. Lubricate the chain	Lubricate the chain		
3.2. Tension the chain	Tension the chain		

Electrics:

Subject	Action	Person	Date
1. Cables and connectors			
1.1. General	Check on damages		
2. Devices and cabinets			
2.1. General	Check on leakages and damages		
	Check if the bolts and nuts are still tightened		
	Replace all seals		
2.2. Main switch	Replace the main switch		
2.3. Remote-control device	Replace the battery		

F. Wear of the pads



NB: To be able to calculate the wear of the pads, measure their thickness:

- before first use of the System
- when new pads are mounted.
-

Attention: Replace the pads when the wear exceeds 1.5 mm.



All units in [mm]		Boom 1	Boom 2	Boom3
Initial thickness of the Pads				
	Wear of the most worn pad	Lower section		
		Middle section		
		Upper section		
<input type="checkbox"/>	Maximum wear not exceeded			
	Wear of the most worn pad	Lower section		
		Middle section		
		Upper section		
<input type="checkbox"/>	Maximum wear not exceeded			
	Wear of the most worn pad	Lower section		
		Middle section		
		Upper section		
<input type="checkbox"/>	Maximum wear not exceeded			
	Wear of the most worn pad	Lower section		
		Middle section		
		Upper section		
<input type="checkbox"/>	Maximum wear not exceeded			
	Wear of the most worn pad	Lower section		
		Middle section		
		Upper section		
<input type="checkbox"/>	Maximum wear not exceeded			
	Wear of the most worn pad	Lower section		
		Middle section		
		Upper section		
<input type="checkbox"/>	Maximum wear not exceeded			
	Wear of the most worn pad	Lower section		
		Middle section		
		Upper section		
<input type="checkbox"/>	Maximum wear not exceeded			
	Wear of the most worn pad	Lower section		
		Middle section		
		Upper section		
<input type="checkbox"/>	Maximum wear not exceeded			

G. Hydraulic fluid safety information

SAFETY DATA SHEET

According to EC No 1907/2006 as amended as at the date of this SDS

Shell Tellus S4 VE 46

Version 1.2 Revision Date 02.01.2020 Print Date 03.01.2020

1. Identification of the substance/mixture and of the company/undertaking

- 1.1. Product identifier
 Trade name Shell Tellus S4 VE 46
 Product code 001F8443
- 1.2. Relevant identified uses of the substance or mixture and uses advised against
 Use of the Hydraulic oil
 Substance/Mixture This product must not be used in applications other than those
 Uses advised against listed in Section 1 without first seeking the advice of the
 supplier.
- 1.3. Details of the supplier of the safety data sheet
 Manufacturer/Supplier Shell Nederland Verkoopmaatschappij B.V.
 Weena 70
 3012 CM Rotterdam
 Netherlands
 Telephone (+31) 0900 202 2710
 Telefax -
 Email Contact for Safety Data sheet If you have any enquiries about the content of this SDS please email
 lubricantSDS@shell.com
- 1.4. Emergency telephone number
 National Poison Information Centre (NVIC): Tel. nr. +31 30 - 2748888 (24 hrs a day
 and 7 days a week). Only for the purpose of informing medical personnel in cases of
 accidental intoxications.
 +31 (0)10 4313233
 National Poison Information Centre (NVIC): Tel. nr. +31 30 - 2748888 (24 hrs a day
 and 7 days a week). Only for the purpose of informing medical personnel in cases of
 accidental intoxications.
 +31 (0)10 4313233

2. Identification of the substance/mixture and of the company/undertaking

- 2.1. Classification of the substance or mixture
 Classification (REGULATION (EC) No 1272/2008
 Based on available data this substance / mixture does not meet the classification criteria.
- 2.2. Label elements
 Labelling (REGULATION (EC) No 1272/2008)
 Hazard pictograms No Hazard Symbol required
 Signal word No signal word
 Hazard statements PHYSICAL HAZARDS:
 Not classified as a physical hazard according to CLP criteria.
 HEALTH HAZARDS:
 Not classified as a health hazard under CLP
 criteria.
 ENVIRONMENTAL HAZARDS:
 Not classified as environmental hazard
 according to CLP criteria.
- Precautionary statements Prevention No precautionary phrases
 Response
 Storage
 Disposal
- Safety data sheet available on request
 Sensitising components Contains triazole derivatives.
 May produce an allergic reaction
- 2.3. Other hazards
 This mixture does not contain any REACH registered substances that are assessed to be a
 PBT or a vPvB. Prolonged or repeated skin contact without proper cleaning can clog the
 pores of the skin resulting in disorders such as oil acne/folliculitis. Used oil may contain
 harmful impurities. High-pressure injection under the skin may cause serious damage
 including local necrosis. Not classified as flammable but will burn

3. Composition/information on ingredients

- 3.1. Mixtures
 Chemical nature Blend of polyolefins and additives
 Hazardous components

Chemical name	CAS-No. EC-No. Registration number	Classification (REGULATION (EC) No 1272/2008)	Concentration [%]
Distillates (Fischer - Tropisch), heavy, C18-50 – branched, cyclic and linear	848301-69-9 482-220-0 01-0000020163-82	Asp. Tox.1; H304	85- 95
Triazole derivative	91273-04-0 401-280-0	Skin Corr.1B; H314 Skin Sens.1A; H317 Aquatic Chronic1; H410	0,01 - 0,05

4. First aid measures

- 4.1. Description of first aid measures
- Protection of first-aiders When administering first aid, ensure that you are wearing the appropriate personal protective equipment according to the incident, injury and surroundings.
- If inhaled No treatment necessary under normal conditions of use. If symptoms persist, obtain medical advice.
- In case of skin contact Remove contaminated clothing. Flush exposed area with water and follow by washing with soap if available. If persistent irritation occurs, obtain medical attention. When using high pressure equipment, injection of product under the skin can occur. If high pressure injuries occur, the casualty should be sent immediately to a hospital. Do not wait for symptoms to develop. Obtain medical attention even in the absence of apparent wounds.
- In case of eye contact Flush eye with copious quantities of water.
 Remove contact lenses, if present and easy to do. Continue rinsing. If persistent irritation occurs, obtain medical attention.
- If swallowed In general no treatment is necessary unless large quantities are swallowed, however, get medical advice.
- 4.2. Most important symptoms and effects, both acute and delayed
 Symptoms Oil acne/folliculitis signs and symptoms may include formation of black pustules and spots on the skin of exposed areas. Ingestion may result in nausea, vomiting and/or diarrhoea. Local necrosis is evidenced by delayed onset of pain and tissue damage a few hours following injection.
- 4.3. Indication of any immediate medical attention and special treatment needed
- 4.4. Treatment
 Notes to doctor/physician:
 Treat symptomatically.
 High pressure injection injuries require prompt surgical intervention and possibly steroid therapy, to minimise tissue damage and loss of function. Because entry wounds are small and do not reflect the seriousness of the underlying damage, surgical exploration to determine the extent of involvement may be necessary. Local anaesthetics or hot soaks should be avoided because they can contribute to swelling, vasospasm and ischaemia. Prompt surgical decompression, debridement and evacuation of foreign material should be performed under general anaesthetics, and wide exploration is essential.

5. Firefighting measures

- 5.1. Extinguishing media
 Suitable extinguishing media Foam, water spray or fog. Dry chemical powder, carbon dioxide, sand or earth may be used for small fires only. Do not use water in a jet
 Unsuitable extinguishing media
- 5.2. Special hazards arising from the substance or mixture
 Specific hazards during firefighting Hazardous combustion products may include: A complex mixture of airborne solid and liquid particulates and gases (smoke). Carbon monoxide may be evolved if incomplete combustion occurs. Unidentified organic and inorganic compounds
- 5.3. Advice for firefighters
 Special protective equipment for firefighters Proper protective equipment including chemical resistant gloves are to be worn; chemical resistant suit is indicated if large contact with spilled product is expected. Self-Contained Breathing Apparatus must be worn when approaching a fire in a confined space. Select fire fighter's clothing approved to relevant Standards (e.g. Europe: EN469).
 Specific extinguishing methods Use extinguishing measures that are appropriate to local circumstances and the surrounding environment

6. Accidental release measures

- 6.1. Personal precautions, protective equipment and emergency procedures
 Personal precautions 6.1.1 For non emergency personnel: Avoid contact with skin and eyes.
 6.1.2 For emergency responders: Avoid contact with skin and eyes
- 6.2. Environmental precautions
 Environmental precautions Use appropriate containment to avoid environmental contamination. Prevent from spreading or entering drains, ditches or rivers by using sand, earth, or other appropriate barriers.
 Local authorities should be advised if significant spillages cannot be contained
- 6.3. Methods and materials for containment and cleaning up

Methods for cleaning up Slippery when spilt. Avoid accidents, clean up immediately. Prevent from spreading by making a barrier with sand, earth or other containment material.
Reclaim liquid directly or in an absorbent. Soak up residue with an absorbent such as clay, sand or other suitable material and dispose of properly

6.4. Reference to other sections
For guidance on selection of personal protective equipment see Chapter 8 of this Safety Data Sheet., For guidance on disposal of spilled material see Chapter 13 of this Safety Data Sheet

7. Handling and storage

General Use local exhaust ventilation if there is risk of inhalation of vapours, mists or aerosols. Use the information in this data sheet as input to a risk assessment of local circumstances to help determine appropriate controls for safe handling, storage and disposal of this material.
Precautions

7.1. Precautions for safe handling

Advice on safe handling Avoid prolonged or repeated contact with skin.
Avoid inhaling vapour and/or mists. When handling product in drums, safety footwear should be worn and proper handling equipment should be used. Properly dispose of any contaminated rags or cleaning materials in order to prevent fires.

7.2. Conditions for safe storage, including any incompatibilities

Other data Keep container tightly closed and in a cool, well-ventilated place. Use properly labeled and closable containers. Store at ambient temperature. Refer to section 15 for any additional specific legislation covering the packaging and storage of this product.

Packaging material Suitable material: For containers or container linings, use mild steel or high density polyethylene. Unsuitable material: PVC.

Container Advice Polyethylene containers should not be exposed to high temperatures because of possible risk of distortion.

7.3. Specific end use(s)

Specific use(s) Not applicable

8. Exposure controls/personal protection

8.1. Control parameters

Occupational Exposure Limits
Biological occupational exposure limits
No biological limit allocated.
Monitoring Methods

Monitoring of the concentration of substances in the breathing zone of workers or in the general workplace may be required to confirm compliance with an OEL and adequacy of exposure controls. For some substances biological monitoring may also be appropriate.

Validated exposure measurement methods should be applied by a competent person and samples analysed by an accredited laboratory.

Examples of sources of recommended exposure measurement methods are given below or contact the supplier. Further national methods may be available.

National Institute of Occupational Safety and Health (NIOSH), USA: Manual of Analytical Methods
<http://www.cdc.gov/niosh/>

Occupational Safety and Health Administration (OSHA), USA: Sampling and Analytical Methods <http://www.osha.gov/>
Health and Safety Executive (HSE), UK: Methods for the Determination of Hazardous Substances <http://www.hse.gov.uk/>
Institut für Arbeitsschutz Deutschen Gesetzlichen Unfallversicherung (IFA) , Germany <http://www.dguv.de/inhalt/index.jsp>
L'Institut National de Recherche et de Sécurité, (INRS), France <http://www.inrs.fr/accueil>

8.2. Exposure controls

Engineering measures

The level of protection and types of controls necessary will vary depending upon potential exposure conditions. Select controls based on a risk assessment of local circumstances. Appropriate measures include Adequate ventilation to control airborne concentrations. Where material is heated, sprayed or mist formed, there is greater potential for airborne concentrations to be generated.

General Information:

Define procedures for safe handling and maintenance of controls. Educate and train workers in the hazards and control measures relevant to normal activities associated with this product. Ensure appropriate selection, testing and maintenance of equipment used to control exposure, e.g. personal protective equipment, local exhaust ventilation. Drain down system prior to equipment break-in or maintenance. Retain drain downs in sealed storage pending disposal or subsequent recycle. Always observe good personal hygiene measures, such as washing hands after handling the material and before eating, drinking, and/or smoking. Routinely wash work clothing and protective equipment to remove contaminants. Discard contaminated clothing and footwear that cannot be cleaned. Practice good housekeeping.

8.3. Personal protective equipment

The provided information is made in consideration of the PPE directive (Council Directive 89/686/EEC) and the CEN European Committee for Standardisation (CEN) standards. Personal protective equipment (PPE) should meet recommended national standards. Check with PPE suppliers.

Eye protection If material is handled such that it could be splashed into eyes, protective eyewear is recommended.
Approved to EU Standard EN166.

Hand protection Where hand contact with the product may occur the use of gloves approved to relevant standards (e.g. Europe: EN374, US: F739) made from the following materials may provide suitable chemical protection.
PVC, neoprene or nitrile rubber gloves Suitability and durability of a glove is dependent on usage, e.g. frequency and duration of contact, chemical resistance of glove material, dexterity. Always seek advice from glove suppliers. Contaminated gloves should be replaced. Personal hygiene is a key element of effective hand care. Gloves must only be worn on clean hands. After using gloves, hands should be

- washed and dried thoroughly. Application of a non-perfumed moisturizer is recommended. For continuous contact we recommend gloves with breakthrough time of more than 240 minutes with preference for > 480 minutes where suitable gloves can be identified. For short-term/splash protection we recommend the same but recognize that suitable gloves offering this level of protection may not be available and in this case a lower breakthrough time maybe acceptable so long as appropriate maintenance and replacement regimes are followed. Glove thickness is not a good predictor of glove resistance to a chemical as it is dependent on the exact composition of the glove material. Glove thickness should be typically greater than 0.35 mm depending on the glove make and model.
- Respiratory protection** No respiratory protection is ordinarily required under normal conditions of use. In accordance with good industrial hygiene practices, precautions should be taken to avoid breathing of material. If engineering controls do not maintain airborne concentrations to a level which is adequate to protect worker health, select respiratory protection equipment suitable for the specific conditions of use and meeting relevant legislation. Check with respiratory protective equipment suppliers. Where air-filtering respirators are suitable, select an appropriate combination of mask and filter. Select a filter suitable for combined particulate/organic gases and vapours [Type A/Type P boiling point > 65°C (149°F)] meeting EN14387 and EN143.
- Thermal hazards** Not applicable
- 8.4. Environmental exposure controls**
- General advice** Take appropriate measures to fulfill the requirements of relevant environmental protection legislation. Avoid contamination of the environment by following advice given in Section 6. If necessary, prevent undissolved material from being discharged to wastewater. Wastewater should be treated in a municipal or industrial wastewater treatment plant before discharge to surface water. Local guidelines on emission limits for volatile substances must be observed for the discharge of exhaust air containing vapour.

9. Physical and chemical properties

9.1. Information on basic physical and chemical properties

Appearance	Liquid
Colour	Colourless
Odour	Slight hydrocarbon
Odour Threshold	Data not available
pH	Not applicable
pour point	: -48 °C Method: ISO 3016
Initial boiling point and boiling range	> 280 °C estimated value(s)
Flash point	260 °C, Method: ASTM D92 (COC)
Evaporation rate	Data not available
Flammability (solid, gas)	Data not available
Upper explosion limit	Typical 10 %(V)
Lower explosion limit	Typical 1 %(V)
Vapour pressure	< 0,5 Pa (20 °C) estimated value(s)
Relative vapour density	> 1 estimated value(s)
Relative density	0,832 (15,0 °C)
Density	: 832 kg/m ³ (15,0 °C) Method: ISO 12185
Solubility(ies)	
Water solubility	negligible
Solubility in other solvents	Data not available
Partition coefficient: n- octanol/water	log Pow: > 6 (based on information on similar products)
Auto-ignition temperature	> 320 °C
Decomposition temperature	Data not available
Viscosity	
Viscosity, dynamic	Data not available
Viscosity, kinematic	46 mm ² /s (40,0 °C), Method: ISO 3104 8,7 mm ² /s (100 °C), Method: ISO 3104
Explosive properties	Not classified
Oxidizing properties	Data not available

9.2. Other information

- Conductivity** This material is not expected to be a static accumulator

10. Stability and reactivity

- 10.1. Reactivity** The product does not pose any further reactivity hazards in addition to those listed in the following sub-paragraph
- 10.2. Chemical stability** Stable. No hazardous reaction is expected when handled and stored according to provisions
- 10.3. Possibility of hazardous reactions**
- Hazardous reactions** Reacts with strong oxidising agents.
- 10.4. Conditions to avoid** Extremes of temperature and direct sunlight
- 10.5. Incompatible materials**
- Materials to avoid** Strong oxidising agents
- 10.6. Hazardous decomposition products** No decomposition if stored and applied as directed
- Hazardous decomposition products**

11. Toxicological information

11.1. Information on toxicological effects

Basis for assessment	Information given is based on data on the components and the toxicology of similar products. Unless indicated otherwise, the data presented is representative of the product as a whole, rather than for individual component(s).
Information on likely routes of exposure	Skin and eye contact are the primary routes of exposure although exposure may occur following accidental ingestion
Acute oral toxicity Product	LD50 rat: > 5.000 mg/kg Remarks: Low toxicity: Based on available data, the classification criteria are not met.
Acute inhalation toxicity	Remarks: Based on available data, the classification criteria are not met.
Acute dermal toxicity	LD50 Rabbit: > 5.000 mg/kg Remarks: Low toxicity: Based on available data, the classification criteria are not met.
Skin corrosion/irritation Product	Remarks: Slightly irritating to skin., Prolonged or repeated skin contact without proper cleaning can clog the pores of the skin resulting in disorders such as oil acne/folliculitis., Based on available data, the classification criteria are not met.
Serious eye damage/eye irritation Product	Remarks: Slightly irritating to the eye., Based on available data, the classification criteria are not met.
Respiratory or skin sensitisation Product	Remarks: For respiratory and skin sensitisation; Not a sensitiser. Based on available data, the classification criteria are not met.
Components	Triazole derivative: Remarks: May cause an allergic skin reaction in sensitive individuals.
Germ cell mutagenicity Product	Remarks: Non mutagenic, based on available data, the classification criteria are not met.
Reproductive toxicity Product	Remarks: Not a developmental toxicant., Does not impair fertility. Based on available data, the classification criteria are not met.
STOT - single exposure Product	Remarks: Based on available data, the classification criteria are not met.
STOT - repeated exposure Product	Remarks: Based on available data, the classification criteria are not met.
Aspiration toxicity Product	Not an aspiration hazard.
Further information Product	Remarks: Used oils may contain harmful impurities that have accumulated during use. The concentration of such impurities will depend on use and they may present risks to health and the environment on disposal., ALL used oil should be handled with caution and skin contact avoided as far as possible. Remarks: High pressure injection of product into the skin may lead to local necrosis if the product is not surgically removed. Remarks: Slightly irritating to respiratory system. Remarks: Classifications by other authorities under varying regulatory frameworks may exist.
Summary on evaluation of the CMR properties	
Germ cell mutagenicity-Assessment	This product does not meet the criteria for classification in categories 1A/1B.
Carcinogenicity-Assessment	This product does not meet the criteria for classification in categories 1A/1B.
Reproductive toxicity - Assessment	This product does not meet the criteria for classification in categories 1A/1B.

12. Ecological information

12.1. Toxicity

Basis for assessment	Ecotoxicological data have not been determined specifically for this product. Information given is based on a knowledge of the components and the ecotoxicology of similar products. Unless indicated otherwise, the data presented is representative of the product as a whole, rather than for individual component(s).(LL/EL/IL50 expressed as the nominal amount of product required to prepare aqueous test extract).
Product:	
Toxicity to fish (Acute toxicity)	Remarks: LL/EL/IL50 > 100 mg/l Practically non toxic: Based on available data, the classification criteria are not met.
Toxicity to crustacean (Acute toxicity)	Remarks: LL/EL/IL50 > 100 mg/l Practically non toxic: Based on available data, the classification criteria are not met.
Toxicity to algae/aquatic plants (Acute toxicity)	Remarks: LL/EL/IL50 > 100 mg/l Practically non toxic: Based on available data, the classification criteria are not met.
Toxicity to fish (Chronic toxicity)	Remarks: Data not available
Toxicity to crustacean (Chronic toxicity)	Remarks: Data not available
Toxicity to microorganisms (Acute toxicity)	Remarks: Data not available
Components:	Triazole derivative
M-Factor (Short-term (acute) aquatic hazard)	1

- 12.2. Persistence and degradability
 Product: Biodegradability
 Remarks: Not readily biodegradable., Major constituents are inherently biodegradable, but contains components that may persist in the environment.
- 12.3. Bioaccumulative potential
 Product: Bioaccumulation
 Partition coefficient: n-octanol/water
 Remarks: Contains components with the potential to bioaccumulate.
 log Pow: > 6
 Remarks: (based on information on similar products)
- 12.4. Mobility in soil
 Product: Mobility
 Remarks: Liquid under most environmental conditions. If it enters soil, it will adsorb to soil particles and will not be mobile. Remarks: Floats on water.
- 12.5. Results of PBT and vPvB assessment
 Product: assessment
 This mixture does not contain any REACH registered substances that are assessed to be a PBT or a vPvB.
- 12.6. Other adverse effects
 Product: Additional ecological information
 Does not have ozone depletion potential, photochemical ozone creation potential or global warming potential., Product is a mixture of non-volatile components, which will not be released to air in any significant quantities under normal conditions of use.
 Poorly soluble mixture. Causes physical fouling of aquatic organisms

13. Disposal considerations

- 13.1. Waste treatment methods
 Product
 Recover or recycle if possible. It is the responsibility of the waste generator to determine the toxicity and physical properties of the material generated to determine the proper waste classification and disposal methods in compliance with applicable regulations. Do not dispose into the environment, in drains or in water courses. Waste product should not be allowed to contaminate soil or ground water, or be disposed of into the environment. Waste, spills or used product is dangerous waste.
 Contaminated packaging
 Dispose in accordance with prevailing regulations, preferably to a recognized collector or contractor. The competence of the collector or contractor should be established beforehand. Disposal should be in accordance with applicable regional, national, and local laws and regulations.
 Local legislation
 Waste catalogue
 Waste Code
 Remarks
 EU Waste Disposal Code (EWC):
 13 01 11*
 Disposal should be in accordance with applicable regional, national, and local laws and regulations.
 Classification of waste is always the responsibility of the end user.

14. Transport information

- 14.1. UN
 ADN
 ADR
 RID
 IMDG
 IATA
 Not regulated as a dangerous good
 Not regulated as a dangerous good
 Not regulated as a dangerous good
 Not regulated as a dangerous good
 Not regulated as a dangerous good
 Not regulated as a dangerous good
- 14.2. Proper shipping name
 ADN
 ADR
 RID
 IMDG
 IATA
 Not regulated as a dangerous good
 Not regulated as a dangerous good
 Not regulated as a dangerous good
 Not regulated as a dangerous good
 Not regulated as a dangerous good
- 14.3. Transport hazard class
 ADN
 ADR
 RID
 IMDG
 IATA
 Not regulated as a dangerous good
 Not regulated as a dangerous good
 Not regulated as a dangerous good
 Not regulated as a dangerous good
 Not regulated as a dangerous good
- 14.4. Packing group
 ADN
 CDNI Inland Water
 Waste Agreement
 ADR
 RID
 IMDG
 IATA
 Not regulated as a dangerous good
 NST 3411 Mineral Lubricating Oils
 Not regulated as a dangerous good
 Not regulated as a dangerous good
 Not regulated as a dangerous good
 Not regulated as a dangerous good
- 14.5. Environmental hazards
 ADN
 ADR
 RID
 IMDG
 Not regulated as a dangerous good
 Not regulated as a dangerous good
 Not regulated as a dangerous good
 Not regulated as a dangerous good
- 14.6. Special precautions for user
 Remarks
 Special Precautions: Refer to Section 7, Handling & Storage, for special precautions which a user needs to be aware of or needs to comply with in connection with transport.
- 14.7. Transport in bulk according to Annex II of MARPOL 73/78 and the IBC Code

Not applicable for product as supplied. MARPOL Annex 1 rules apply for bulk shipments by sea.

15. Regulatory information

15.1. Safety, health and environmental regulations/legislation specific for the substance or mixture

REACH - List of Product is not subject to Authorisation under REACH

substances subject to authorisation (Annex XIV)

Volatile organic compounds 0 %

Other regulations

The regulatory information is not intended to be comprehensive. Other regulations may apply to this material. Regulation (EC) No 1907/2006 of the European Parliament and of the Council of 18 December 2006 concerning the Registration, Evaluation, Authorisation and Restriction of Chemicals (REACH), annex XIV. Regulation (EC) No 1907/2006 of the European Parliament and of the Council of 18 December 2006 concerning the Registration, Evaluation, Authorisation and Restriction of Chemicals (REACH), annex XVII. Directive 2004/37/EC on the protection of workers from the risks related to exposure to carcinogens or mutagens at work and its amendments. Directive 1994/33/EC on the protection of young people at work and its amendments. Council Directive 92/85/EEC on the introduction of measures to encourage improvements in the safety and health at work of pregnant workers and workers who have recently given birth or are breastfeeding and its amendments.

The components of this product are reported in the following inventories

EINECS All components listed or polymer exempt

TSC All components listed

15.2. Chemical safety assessment

No Chemical Safety Assessment has been carried out for this substance/mixture by the supplier.

16. Other information

16.1. Full text of H-Statements

H304 May be fatal if swallowed and enters airways
 H314 Causes severe skin burns and eye damage
 H317 May cause an allergic skin reaction
 H410 Very toxic to aquatic life with long lasting effects

16.2. Full text of other abbreviations

Aquatic Chronic Long-term (chronic) aquatic hazard
 Asp. Tox. Aspiration hazard
 Skin Corr. Skin corrosion
 Skin Sens. Skin sensitisation

16.3. Abbreviations and Acronyms

ACGIH	American Conference of Governmental Industrial Hygienists
ADR	European Agreement concerning the International Carriage of Dangerous Goods by Road
AICS	Australian Inventory of Chemical Substances
ASTM	American Society for Testing and Materials
BEL	Biological exposure limits
BTEX	Benzene, Toluene, Ethylbenzene, Xylenes
CAS	Chemical Abstracts Service
CEFIC	European Chemical Industry Council
CLP	Classification Packaging and Labelling
COC	Cleveland Open-Cup
DIN	Deutsches Institut für Normung
DMEL	Derived Minimal Effect Level
DNEL	Derived No Effect Level
DSL	Canada Domestic Substance List
EC	European Commission
EC50	Effective Concentration fifty
ECETOC	European Center on Ecotoxicology and Toxicology Of Chemicals
ECHA	European Chemicals Agency
EINECS	The European Inventory of Existing Commercial Chemical Substances
EL50	Effective Loading fifty
ENCS	Japanese Existing and New Chemical Substances Inventory
EWC	European Waste Code
GHS	Globally Harmonised System of Classification and Labelling of Chemicals
IARC	International Agency for Research on Cancer
IATA	International Air Transport Association
IC50	Inhibitory Concentration fifty
IL50	Inhibitory Level fifty
IMDG	International Maritime Dangerous Goods
INV	Chinese Chemicals Inventory
IP346	Institute of Petroleum test method N° 346 for the determination of polycyclic aromatics DMSO-extractables KECI = Korea Existing Chemicals Inventory LC50 = Lethal concentration fifty
LD50	Lethal Dose fifty per cent.
LL/EL/IL	Lethal Loading/Effective Loading/Inhibitory loading LL50 = Lethal Loading fifty
MARPOL	International Convention for the Prevention of Pollution From Ships

NOEC/NOEL	No Observed Effect Concentration / No Observed Effect Level
OE_HP	Occupational Exposure - High Production Volume PBT = Persistent, Bioaccumulative and Toxic
PICCS	Philippine Inventory of Chemicals and Chemical Substances
PNEC	Predicted No Effect Concentration
REACH	Registration Evaluation And Authorisation Of Chemicals
RID	Regulations Relating to International Carriage of Dangerous Goods by uail
SKIN_DES	Skin Designation
STEL	Short term exposure limit
TRA	Targeted Risk Assessment
TSCA	US Toxic Substances Control Act
TWA	Time-Weighted Average
vPvB	very Persistent and very Bioaccumulative

- 16.4. Further information
- | | |
|---|--|
| <p>Training advice</p> <p>Other information</p>

<p>Sources of key data used to compile the Safety Data Sheet</p> | <p>Provide adequate information, instruction and training for operators</p> <p>No Exposure Scenario annex is attached to this safety data sheet as it is a non-classified mixture containing no hazardous substances.</p> <p>Under Article 31 of REACH, a SDS is not required for this product. Therefore, this SDS has been created on a voluntary basis to pass on potentially relevant information required under Article 32. A vertical bar () in the left margin indicates an amendment from the previous version</p> <p>The quoted data are from, but not limited to, one or more sources of information (e.g. toxicological data from Shell Health Services, material suppliers' data, CONCAWE, EU IUCLID date base, EC 1272 regulation, etc).</p> |
|---|--|

This information is based on our current knowledge and is intended to describe the product for the purposes of health, safety and environmental requirements only. It should not therefore be construed as guaranteeing any specific property of the product.

H. Torque settings

Inspect all bolt joints which may pose a hazard to people and machines at fixed intervals and check their torque.

Apply the torque values unless indicated otherwise on the drawing.

Nominal size	Strength class	Course pitch [Nm]	Fine pitch [Nm]
		(Copper-grease)	(Copper-grease)
		0.08	0.08
M4	8.8	2.2	
	10.9	3.2	
	12.9	3.8	
M5	8.8	4.3	
	10.9	6.3	
	12.9	7.4	
M6	8.8	7.4	
	10.9	10.9	
	12.9	12.5	
M7	8.8	12.0	
	10.9	17.5	
	12.9	20.5	
M8	8.8	18	19
	10.9	26	28
	12.9	31	32
M10	8.8	36	37
	10.9	52	55
	12.9	61	64
M12	8.8	61	63
	10.9	90	93
	12.9	105	109
M14	8.8	97	103
	10.9	145	150
	12.9	165	175
M16	8.8	145	155
	10.9	215	225
	12.9	250	270
M18	8.8	210	230
	10.9	300	330
	12.9	350	380
M20	8.8	300	320
	10.9	420	460
	12.9	500	530

Nominal size	Strength class	Course pitch [Nm]	Fine pitch [Nm]
		(Copper-grease)	(Copper-grease)
		0.08	0.08
M22	8.8	400	430
	10.9	570	610
	12.9	670	710
M24	8.8	510	640
	10.9	730	900
	12.9	850	1060
M27	8.8	750	920
	10.9	1070	1310
	12.9	1250	1530
M30	8.8	1000	1280
	10.9	1450	1820
	12.9	1700	2130
M33	8.8	1400	1700
	10.9	1950	2430
	12.9	2300	2840
M36	8.8	1750	2230
	10.9	2500	3170
	12.9	3000	3710
M39	8.8	2300	2850
	10.9	3300	4050
	12.9	3800	4740

Z. Compatibility of system parts

1. Specification of system parts

a. Lifting units

For Ga-drawing and Load chart is made to Ref 5 "Technical handbook".

Lifting unit	Article number	GA Drawing	Load chart	Pitch of wheels [mm]	Height [mm]	Capacity [kN]
SBL500	03451.01.00.00	03451.50.00.00	03451.70.001	914	8618	1300
SBL900	03623.01.00.00	03623.50.00.00	03623.70.001	914	11306	2244
SBL1100	03622.01.00.00	03622.50.00.00	03622.70.001	914	12202	2621

b. Side shift units

Side Shift Unit	Article number	GA Drawing	Capacity per anchor [kN]
SSU150	03842.01.00.00	03842.50.00.00	375
SSU300	03636.01.00.00	03636.50.00.00	750
SSU600	03530.01.00.00	03530.50.00.00	1500

Obsolete systems:

Side Shift Unit	Article number	GA Drawing	Capacity per anchor [kN]
BSSL125	03697.01.00.00	03697.50.00.00	312.5

Top Swivel Kit	Article number	GA Drawing	Capacity per anchor [kN]
TSK150	03842.01.04.00	03842.01.04.00	375
TSK300	03636.01.10.00	03636.50.10.00	750
TSK600	03530.01.11.00	03530.50.11.00	1500

Side Shift Sling Guide	Article number	GA Drawing	Capacity per anchor [kN]
SSG150	03842.01.03.00	03842.50.03.00	375
SSG300	03636.01.11.00	03636.50.11.00	750
SSG600	03530.01.05.00	03530.50.05.00	1500

Rotation Anchor Kit	Article number	GA Drawing	Capacity per anchor [kN]
RAK300	03636.01.12.00	03636.50.12.00	750

c. Header beams

Standard beams

Headerbeam	Article number	GA Drawing	Load chart	Length [m]	Height [mm]	Width [mm]
HBH-6	03878.01.00.00	03878.50.00.00	ED.03878.70.001	6	432	307
HBH-8	03817.01.00.00	03817.50.00.00	ED.03817.70.001	8	527	306
HBB-8	02843.01.00.00	02843.50.00.00	ED.02843.70.001	8	600	480
HBB-10	02940.01.00.00	02940.50.00.00	ED.02940.70.001	10	600	480
HBB-12	03302.01.00.00	03302.50.01.00	ED.03302.70.001	12	950	480

Special beams (not in catalogue; maybe extended delivery time):

Headerbeam	Article number	GA Drawing	Load chart	Length [m]	Height [mm]	Width [mm]
Connectable	03672.01.00.00	03672.50.00.00	ED.03672.70.118	18	1025	480

Obsolete beams:

Headerbeam	Article number	GA Drawing	Load chart	Length [m]	Height [mm]	Width [mm]
HBSL 125-6	03645.01.00.00	03645.50.00.00	ED.03645.70.001	6	432	307
HBSL 125-8	03646.01.00.00	03646.50.00.00	ED.03646.70.001	8	524	306
HBSL 200-8	03817.01.00.00	03817.50.00.00	ED.03817.70.001	8	572	306
HBSL 125-10	03647.01.00.00	03647.50.00.00	ED.03647.70.001	10	668	305
HBSL 125-12	03648.01.00.00	03648.50.00.00	ED.03648.70.001	12	716	305
HBSBL-6	02939.01.00.00	02939.50.00.00	ED.02939.70.001	6	600	480
HBSBL-8	02843.01.00.00	02843.50.00.00	ED.02843.70.001	8	600	480
HBSBL-10	02940.01.00.00	02940.50.00.00	ED.02940.70.001	10	600	480
HBSBL-12	03302.01.00.00	03302.50.01.00	ED.03302.70.001	12	950	480

d. Lifting lugs

Standard lugs:

Lifting Lug	Article number	GA Drawing	Hole [mm]		Capacity per anchor [kN]
			height	Width	
LL200	03889.01.00.00-01	03889.50.00.00-01	582	320	500
LL500	03890.01.01.00-01	03890.50.01.00-01	1100	490	1250
LL1000	03890.01.01.00	03890.50.01.00	1100	490	2500

Obsolete lugs

Lifting Lug	Article number	GA Drawing	Hole [mm]		Capacity per anchor [kN]
			height	Width	
LLSL200-8	03817.01.00.00-03	03817.50.00.00-03	582	320	500
LLSL125-10	03647.01.00.00-03	03647.50.00.00-03	678	320	312.5
LLSL125-12	03648.01.00.00-03	03648.50.00.00-03	730	320	312.5
LLSBL125	02940.01.02.00-01	02940.50.02.00-01	1100	490	1250
LLSBL250	02940.01.02.00	02940.50.02.00	1100	490	2500

e. Skid tracks

Standard skid tracks

Skid tracks	Article number	GA Drawing	Pitch [mm]	Length [mm]
GST1100-6	03870.01.01.00	03870.50.01.00	914	5900
GST1100-3	03870.01.02.00	03870.50.02.00	914	3000

Obsolete skid tracks

Skid tracks	Article number	GA Drawing	Pitch [mm]	Length [mm]
STSBL-6	03134.01.01.00	03869.50.01.00	914	5900
STSBL-3	03134.01.03.00	03869.50.03.00	914	5900

f. Sling guides

Sling guide	Article number	GA Drawing	Header beam width [mm]	Capacity per sling guide [kN]
HBHSG	03893.01.00.00	03893.50.00.00	300 – 310 mm	500
HBBSG	03892.01.00.00	03892.50.00.00	480 mm	2500

2. Compatibility of system parts

Legend:

C	Compatible
NC	Not Compatible

a. Gantries and header beams

All gantries and header beams are compatible to each other.

b. Gantries and skid tracks

Skid track		Gantry				
		SBL500	SBL900	SBL1100	SL400N	SL400
		03451.01.00.00	03623.01.00.00	03622.01.00.00	03864.01.00.00	03442.01.00.00
GST1100-6	03870.01.01.00	C	C	C	C	C
GST1100-3	03870.01.02.00	C	C	C	C	C
STSBL-6	03134.01.01.00	C	C	C	C	C
STSBL-3	03134.01.03.00	C	C	C	C	C

c. Header beams and lifting lugs

Lifting lugs		Header beams														
		HBH-6	HBH-8	HBB-8	HBB-10	HBB-12	HBSL 125-6	HBSL 125-8	HBSL 200-8	HBSL 125-10	HBSL 125-12	HBSBL-6	HBSBL-8	HBSBL-10	HBSBL-12	Connectable
		03878.01.00.00	03817.01.00.00	02843.01.00.00	02940.01.00.00	03302.01.00.00	03645.01.00.00	03646.01.00.00	03817.01.00.00	03647.01.00.00	03648.01.00.00	02939.01.00.00	02843.01.00.00	02940.01.00.00	03302.01.00.00	03672.01.00.00
LL200	03889.01.00.00-01	C	C	NC	NC	NC	C	C	C	NC	NC	NC	NC	NC	NC	
LL500	03890.01.01.00-01	NC	NC	C	C	C	NC	NC	NC	NC	NC	C	C	C	C	
LL1000	03890.01.01.00	NC	NC	C	C	C	NC	NC	NC	NC	NC	C	C	C	C	
LLSL200-8	03817.01.00.00-03	C	C	NC	NC	NC	C	C	C	NC	NC	NC	NC	NC	NC	
LLSL125-10	03647.01.00.00-03	C	C	NC	NC	NC	C	C	C	C	NC	NC	NC	NC	NC	
LLSL125-12	03648.01.00.00-03	C	C	NC	NC	NC	C	C	C	C	C	NC	NC	NC	NC	
LLSBL125	02940.01.02.00-01	NC	NC	C	C	C	NC	NC	NC	NC	NC	C	C	C	C	
LLSBL250	02940.01.02.00	NC	NC	C	C	C	NC	NC	NC	NC	NC	C	C	C	C	

d. Lifting lugs with header beam type wide / narrow

Lifting lugs		Header beam type	
		Narrow	Wide
LL200	03889.01.00.00-01	C	NC
LL500	03890.01.01.00-01	NC	C
LL1000	03890.01.01.00	NC	C
LLSL200-8	03817.01.00.00-03	C	NC
LLSL125-10	03647.01.00.00-03	C	NC
LLSL125-12	03648.01.00.00-03	C	NC
LLSBL125	02940.01.02.00-01	NC	C
LLSBL250	02940.01.02.00	NC	C

e. Headerbeams with side shift units

Side Shift Unit		Header beam														
		HBH-6	HBH-8	HBB-8	HBB-10	HBB-12	HBSL 125-6	HBSL 125-8	HBSL 200-8	HBSL 125-10	HBSL 125-12	HBSBL-6	HBSBL-8	HBSBL-10	HBSBL-12	Connectable
		03878.01.00.00	03817.01.00.00	02843.01.00.00	02940.01.00.00	03302.01.00.00	03645.01.00.00	03646.01.00.00	03817.01.00.00	03647.01.00.00	03648.01.00.00	02939.01.00.00	02843.01.00.00	02940.01.00.00	03302.01.00.00	03672.01.00.00
SSU150	03842.01.00.00	C	C	NC	NC	NC	C	C	C	C	C	NC	NC	NC	NC	NC
SSU300	03636.01.00.00	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C
SSU600	03530.01.00.00	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C
BSSL125	03697.01.00.00	C	C	NC	NC	NC	C	C	C	C	C	NC	NC	NC	NC	NC
BSSBL600	02907.01.00.00	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C

f. Top swivel kit and side shift unit

Top swivel kit		Side shift unit				
		SSU150	SSU300	SSU600	BSSL125	BSSBL600
		03842.01.00.00	03636.01.00.00	03530.01.00.00	03697.01.00.00	02907.01.00.00
TSK150	03842.01.04.00	C	NC	NC	NC	NC
TSK300	03636.01.10.00	NC	C	NC	NC	NC
TSK600	03530.01.11.00	NC	NC	C	NC	NC

g. Side shift sling guide with side shift unit

Side shift Sling Guide		Side shift unit		
		SSU150	SSU300	SSU600
		03842.01.00.00	03636.01.00.00	03530.01.00.00
SSG150	03842.01.03.00	C	NC	NC
SSG300	03636.01.11.00	NC	C	NC
SSG600	03530.01.05.00	NC	NC	C

h. Rotation anchor kit and side shift unit

Rotation Anchor Kit		Side shift unit				
		SSU150	SSU300	SSU600	BSSL125	BSSBL600
		03842.01.00.00	03636.01.00.00	03530.01.00.00	03697.01.00.00	02907.01.00.00
RAK300	03636.01.12.00	NC	C	NC	NC	NC

i. Header beams and sling guides

Sling guide		Header beam													
		HBH-6	HBH-8	HBB-8	HBB-10	HBB-12	HBSL 125-6	HBSL 125-8	HBSL 125-10	HBSL 125-12	HBSBL-6	HBSBL-8	HBSBL-10	HBSBL-12	Connectable
		03878.01.00.00	03817.01.00.00	02843.01.00.00	02940.01.00.00	03302.01.00.00	03645.01.00.00	03646.01.00.00	03647.01.00.00	03648.01.00.00	02939.01.00.00	02843.01.00.00	02940.01.00.00	03302.01.00.00	03672.01.00.00
HBHSG	03893.01.00.00	C	C	NC	NC	NC	C	C	C	C	NC	NC	NC	NC	
HBBSG	03892.01.00.00	NC	NC	C	C	C	NC	NC	NC	NC	C	C	C	C	